

# TSIM2 Simulator User's Manual

# Table of Contents

1. Introduction .....	7
1.1. General .....	7
1.2. Supported platforms and system requirements .....	7
1.3. Obtaining TSIM .....	7
1.4. License .....	7
1.5. Evaluation version .....	7
1.6. Problem reports .....	7
2. Installation .....	9
2.1. General .....	9
2.2. License installation .....	9
2.2.1. Floating keys .....	9
3. Operation .....	10
3.1. Overview .....	10
3.2. Starting TSIM .....	10
3.3. Standalone mode commands .....	14
3.3.1. Time specification for commands .....	17
3.4. Symbolic debug information .....	17
3.5. Breakpoints and watchpoints .....	18
3.6. Profiling .....	18
3.7. Code coverage .....	18
3.8. Check-pointing .....	19
3.9. Performance .....	20
3.10. Backtrace .....	20
3.11. Connecting to gdb .....	20
3.12. Thread support .....	21
3.12.1. TSIM thread commands .....	21
3.12.2. GDB thread commands .....	22
3.13. Synchronising TSIM time to external time .....	23
4. Emulation characteristics .....	24
4.1. Common behaviour .....	24
4.1.1. Timing .....	24
4.1.2. UARTs .....	24
4.1.3. Floating point unit (FPU) .....	24
4.1.4. Delayed write to special registers .....	25
4.1.5. Idle-loop optimisation .....	25
4.1.6. Custom instruction emulation .....	25
4.1.7. Chip-specific errata .....	26
4.2. ERC32 specific emulation .....	26
4.2.1. Processor emulation .....	26
4.2.2. MEC emulation .....	26
4.2.3. Interrupt controller .....	27
4.2.4. Watchdog .....	27
4.2.5. Power-down mode .....	27
4.2.6. Memory emulation .....	27
4.2.7. EDAC operation .....	27
4.2.8. Extended RAM and I/O areas .....	28
4.2.9. SYSAB signal .....	28
4.2.10. EXTINTACK signal .....	28
4.2.11. IWDE signal .....	28
4.3. LEON2 specific emulation .....	28
4.3.1. Processor .....	28
4.3.2. Cache memories .....	28
4.3.3. LEON peripherals registers .....	29
4.3.4. Interrupt controller .....	29
4.3.5. Power-down mode .....	29

4.3.6. Memory emulation .....	29
4.3.7. SPARC V8 MUL/DIV/MAC instructions .....	29
4.3.8. FPU emulation .....	29
4.3.9. DSU and hardware breakpoints .....	29
4.4. LEON3 specific emulation .....	29
4.4.1. General .....	29
4.4.2. Processor .....	29
4.4.3. Cache memories .....	30
4.4.4. Power-down mode .....	30
4.4.5. LEON3 peripherals registers .....	30
4.4.6. Interrupt controller .....	30
4.4.7. Memory emulation .....	30
4.4.8. CASA instruction .....	30
4.4.9. SPARC V8 MUL/DIV/MAC instructions .....	30
4.4.10. FPU emulation .....	30
4.4.11. DSU and hardware breakpoints .....	31
4.4.12. AHB status registers .....	31
4.4.13. GRTIMER emulation .....	31
4.5. LEON4 specific emulation .....	31
4.5.1. General .....	31
4.5.2. Processor .....	31
4.5.3. L1 Cache memories .....	31
4.5.4. L2 Cache memory .....	31
4.5.5. Power-down mode .....	31
4.5.6. LEON4 peripherals registers .....	31
4.5.7. Interrupt controller .....	31
4.5.8. Memory emulation .....	32
4.5.9. CASA instruction .....	32
4.5.10. SPARC V8 MUL/DIV/MAC instructions .....	32
4.5.11. FPU emulation .....	32
4.5.12. DSU and hardware breakpoints .....	32
4.5.13. AHB status registers .....	32
5. Loadable modules .....	33
5.1. TSIM I/O emulation interface .....	33
5.1.1. simif structure .....	33
5.1.2. ioif structure .....	35
5.1.3. Structure to be provided by I/O device .....	35
5.1.4. Cygwin specific io_init() .....	36
5.2. LEON AHB emulation interface .....	36
5.2.1. procif structure .....	37
5.2.2. Structure to be provided by AHB module .....	37
5.2.3. Big versus little endianness .....	40
5.3. TSIM/LEON co-processor emulation .....	40
5.3.1. FPU/CP interface .....	40
5.3.2. Structure elements .....	41
5.3.3. Attaching the FPU and CP .....	41
5.3.4. Big versus little endianness .....	42
5.3.5. Additional TSIM commands .....	42
5.3.6. Example FPU .....	42
5.4. Loadable modules distributed with TSIM .....	42
5.4.1. General AHB module limitations .....	42
6. TSIM library (TLIB) .....	44
6.1. Introduction .....	44
6.2. Function interface .....	44
6.3. External I/O and AHB modules .....	45
6.4. Builtin I/O module and/or AHB module .....	45
6.5. UART handling .....	46
6.6. Linking a TLIB application .....	46

6.7. Limitations .....	46
7. Cobham UT699 emulation .....	47
7.1. Overview of the UT699 AHB module .....	47
7.2. Loading the module .....	48
7.2.1. User input module interface .....	48
7.3. Debugging .....	50
7.4. 10/100 Mbps Ethernet Media Access Controller interface .....	50
7.4.1. Start up options .....	50
7.4.2. Commands .....	50
7.4.3. Debug flags .....	50
7.4.4. Ethernet packet server .....	51
7.4.5. Ethernet packet server protocol .....	51
7.5. SpaceWire interface with RMAP support .....	51
7.5.1. Start up options .....	52
7.5.2. Commands .....	52
7.5.3. Debug flags .....	52
7.5.4. SpaceWire packet server .....	52
7.5.5. SpaceWire packet server protocol .....	52
7.6. PCI initiator/target interface .....	54
7.6.1. Connecting a user PCI model with the UT699 module .....	54
7.6.2. Commands .....	54
7.6.3. Debug flags .....	54
7.6.4. PCI bus model API .....	54
7.7. GPIO interface .....	55
7.7.1. Connecting a user GPIO model with the UT699 module .....	55
7.7.2. Commands .....	55
7.7.3. Debug flags .....	55
7.7.4. GPIO model API .....	55
7.8. CAN interface .....	56
7.8.1. Start up options .....	56
7.8.2. Commands .....	56
7.8.3. Debug flags .....	56
7.8.4. Packet server .....	57
7.8.5. CAN packet server protocol .....	57
8. Cobham UT699E emulation .....	59
8.1. Overview of the UT699E AHB module .....	59
8.2. Loading the module .....	60
8.2.1. User input module interface .....	60
8.3. Debugging .....	62
8.4. 10/100 Mbps Ethernet Media Access Controller interface .....	62
8.4.1. Start up options .....	62
8.4.2. Commands .....	62
8.4.3. Debug flags .....	62
8.4.4. Ethernet packet server .....	63
8.4.5. Ethernet packet server protocol .....	63
8.5. SpaceWire interface with RMAP support .....	63
8.5.1. Start up options .....	64
8.5.2. Commands .....	64
8.5.3. Debug flags .....	64
8.5.4. SpaceWire packet server .....	65
8.5.5. SpaceWire packet server protocol .....	65
8.5.6. Simple Mode .....	72
8.6. PCI initiator/target interface .....	73
8.6.1. Connecting a user PCI model with the UT699E module .....	73
8.6.2. Commands .....	73
8.6.3. Debug flags .....	73
8.6.4. PCI bus model API .....	73
8.7. GPIO interface .....	74

8.7.1. Connecting a user GPIO model with the UT699E module .....	74
8.7.2. Commands .....	74
8.7.3. Debug flags .....	74
8.7.4. GPIO model API .....	75
8.8. CAN interface .....	75
8.8.1. Start up options .....	75
8.8.2. Commands .....	75
8.8.3. Debug flags .....	76
8.8.4. Packet server .....	76
8.8.5. CAN packet server protocol .....	76
9. Cobham UT700 emulation .....	79
9.1. Overview of the UT700 AHB module .....	79
9.2. Loading the module .....	80
9.2.1. User input module interface .....	80
9.3. Debugging .....	82
9.4. 10/100 Mbps Ethernet Media Access Controller interface .....	82
9.4.1. Start up options .....	82
9.4.2. Commands .....	82
9.4.3. Debug flags .....	82
9.4.4. Ethernet packet server .....	83
9.4.5. Ethernet packet server protocol .....	83
9.5. SpaceWire interface with RMAP support .....	83
9.5.1. Start up options .....	84
9.5.2. Commands .....	84
9.5.3. Debug flags .....	84
9.5.4. SpaceWire packet server .....	85
9.5.5. SpaceWire packet server protocol .....	85
9.5.6. Simple Mode .....	92
9.6. PCI initiator/target interface .....	93
9.6.1. Connecting a user PCI model with the UT700 module .....	93
9.6.2. Commands .....	93
9.6.3. Debug flags .....	93
9.6.4. PCI bus model API .....	93
9.7. GPIO interface .....	94
9.7.1. Connecting a user GPIO model with the UT700 module .....	94
9.7.2. Commands .....	94
9.7.3. Debug flags .....	94
9.7.4. GPIO model API .....	95
9.8. CAN interface .....	95
9.8.1. Start up options .....	95
9.8.2. Commands .....	95
9.8.3. Debug flags .....	96
9.8.4. Packet server .....	96
9.8.5. CAN packet server protocol .....	96
9.9. SPI interface .....	98
9.9.1. Connecting a user SPI model with the UT700 module .....	98
9.9.2. Commands .....	98
9.9.3. Debug flags .....	98
9.9.4. SPI bus model API .....	98
10. Cobham Gaisler GR712RC emulation .....	100
10.1. Overview of the GR712RC AHB module .....	100
10.2. Loading the module .....	101
10.2.1. User input module interface .....	101
10.3. Debugging .....	102
10.4. CAN interface .....	103
10.4.1. Start up options .....	103
10.4.2. Commands .....	103
10.4.3. Debug flags .....	103

10.4.4. Packet server .....	104
10.4.5. CAN packet server protocol .....	104
10.5. 10/100 Mbps Ethernet Media Access Controller interface .....	105
10.5.1. Start up options .....	105
10.5.2. Commands .....	106
10.5.3. Debug flags .....	106
10.5.4. Ethernet packet server .....	106
10.5.5. Ethernet packet server protocol .....	106
10.6. SpaceWire interface with RMAP support .....	107
10.6.1. Start up options .....	107
10.6.2. Commands .....	108
10.6.3. Debug flags .....	108
10.6.4. SpaceWire packet server .....	109
10.6.5. SpaceWire packet server protocol .....	109
10.6.6. Simple Mode .....	116
10.7. SPI interface .....	117
10.7.1. Connecting a user SPI model with the GR712RC module .....	117
10.7.2. Commands .....	117
10.7.3. Debug flags .....	117
10.7.4. SPI bus model API .....	117
10.8. GPIO interface .....	118
10.8.1. Connecting a user GPIO model with the GR712RC module .....	118
10.8.2. Commands .....	118
10.8.3. Debug flags .....	118
10.8.4. GPIO model API .....	118
10.9. Clock Gating Unit, CANMUX and GRGPREG .....	119
11. Atmel AT697 emulation .....	120
11.1. Overview of the AT697 AHB module .....	120
11.2. Loading the module .....	121
11.3. AT697 initiator mode .....	121
11.4. AT697 target mode .....	121
11.5. Definitions .....	121
11.5.1. PCI command table .....	122
11.6. Read/write function installed by PCI module .....	122
11.7. Read/write function installed by AT697 module .....	122
11.8. Registers .....	123
11.9. Debug flags .....	124
11.10. Commands .....	124
12. TPS VxWorks AHB Module .....	125
12.1. Overview .....	125
12.2. Loading the module .....	125
12.3. Configuration .....	125
13. Support .....	126

## 1. Introduction

### 1.1. General

TSIM is a generic SPARC<sup>1</sup> architecture simulator capable of emulating ERC32- and LEON-based computer systems.

TSIM provides several unique features:

- Emulation of ERC32 and LEON2/3/4 processors (in single processor systems)
- Superior performance: up to 60 MIPS on high-end PC (Intel i7-2600K @3.4GHz)
- Accelerated processor standby mode, allowing faster-than-realtime simulation speeds
- Standalone operation or remote connection to GNU debugger (gdb)
- Also provided as library to be included in larger simulator frameworks
- 64-bit time for practically unlimited simulation periods
- Instruction trace buffer
- EDAC emulation (ERC32)
- MMU emulation (LEON2/3/4)
- SRAM emulation and functional emulation of SDRAM (with SRAM timing) (LEON2/3/4)
- Local scratch-pad RAM (LEON3/4)
- Loadable modules to include user-defined I/O devices
- Non-intrusive execution time profiling
- Code coverage monitoring
- Instruction trace buffer
- Stack backtrace with symbolic information
- Check-pointing capability to save and restore complete simulator state
- Unlimited number of breakpoints and watchpoints
- Pre-defined functional simulation modules for GR712RC, UT699, UT700 and AT697

### 1.2. Supported platforms and system requirements

TSIM supports the following platforms: Solaris 2.8, Linux, Linux-x64, Windows XP/7, and Windows XP/7 with Cygwin Unix emulation.

### 1.3. Obtaining TSIM

The primary site for TSIM is the Cobham Gaisler website [<http://www.gaisler.com>] where the latest version of TSIM can be ordered and evaluation versions downloaded.

### 1.4. License

TSIM2 ERC32, TSIM2 LEON2, TSIM2 LEON3 and TSIM2 LEON4 are licensed separately as separate products. The license can be found in `license.txt` in the top directory after installation.

### 1.5. Evaluation version

An evaluation version of TSIM2 LEON3 is available from the Cobham Gaisler website [<http://www.gaisler.com>]. The evaluation version may only be used for evaluation and internal testing and only during a period of 21 days without purchasing a license. See the `license.txt` file that is included in the archive for details.

The evaluation version is limited to 32-bit time. It does not support check-pointing, loadable modules, library interface, code coverage, configuration of caches, configuration of memory or chip flags such as `-gr712rc` or `-ut700`.

### 1.6. Problem reports

Please send problem reports or comments to [support@gaisler.com](mailto:support@gaisler.com).

---

<sup>1</sup>SPARC is a registered trademark of SPARC International

Customers with a valid support agreement may send questions to [support@gaisler.com](mailto:support@gaisler.com). Include a TSIM log when sending questions, please. A log can be obtained by starting TSIM with the command line switch `-logfile filename`. Try to include as much details as possible from commands such as **reg**, **hist/inst** (enable history with **hist len**), **bt** and with relevant debug options turned on. See also Chapter 13.



## 2. Installation

### 2.1. General

TSIM is distributed as a tar-file (e.g. `tsim-erc32-2.0.62.tar.gz`) with the following contents:

Table 2.1. TSIM content

Directory	Description
coverage	Source level coverage helper scripts
doc	TSIM documentation
samples	Sample programs
iomod	Example loadable modules
tsim/cygwin	TSIM binary for cygwin
tsim/linux	TSIM binary for linux
tsim/linux-x64	TSIM binary for linux-x64
tsim/solaris	TSIM binary for solaris
tsim/win32	TSIM binary for native Windows
tlib/cygwin	TSIM library for cygwin
tlib/linux	TSIM library for linux
tlib/linux-x64	TSIM library for linux-x64
tlib/solaris	TSIM library for solaris
tlib/win32	TSIM library for native Windows

The tar-file can be installed at any location with the following command:

```
gunzip -c tsim-erc32-2.0.62.tar.gz | tar xf -
```

### 2.2. License installation

TSIM is licensed using a HASP USB hardware key. Before use, a device driver for the key must be installed. See the simulator download page at the Cobham Gaisler website [<http://www.gaisler.com>] for information on where to find the HASP device drivers.

#### 2.2.1. Floating keys

Floating keys can be identified by having a red housing (instead of blue/purple).

Floating license keys requires that the runtime is installed in both client and server. In addition the server also need to have a license manager installed. The license manager software for Windows can be downloaded from the same website as the runtime.

For Linux, the license manager can be downloaded from here [<http://www.gaisler.com/rus/LM.tar.gz>]. The install script is outdated and will fail on many modern distributions. The following workaround works for Ubuntu 16.04 and 18.04:

```
$ sudo RUNLEVELDIR=/etc/rc2.d bash ./dinst .
```

The license manager can also be started manually by running the `hasplm` executable.

## 3. Operation

### 3.1. Overview

TSIM can operate in two modes: standalone and attached to gdb. In standalone mode, ERC32 or LEON applications can be loaded and simulated using a command line interface. A number of commands are available to examine data, insert breakpoints and advance simulation. When attached to gdb, TSIM acts as a remote gdb target, and applications are loaded and debugged through gdb (or a gdb front-end such as ddd).

### 3.2. Starting TSIM

TSIM is started as follows on a command line:

```
tsim-erc32 [options] [input_files]
tsim-leon [options] [input_files]
tsim-leon3 [options] [input_files]
tsim-leon4 [options] [input_files]
```

The following command line options are supported by TSIM:

```
-ahbm ahb_module
    Use ahb_module as loadable AHB module rather than the default ahb.so (LEON only). If multiple -ahbm switches are specified, up to 16 AHB modules can be loaded. The environmental variable TSIM_MODULE_PATH can be set to a ':' separated ( ';' in WIN32) list of search paths.
-ahbstatus
    Adds AHB status register support.
-asilnoallocate
    Makes ASI 1 reads not allocate cache lines (LEON3/4 only).
-at697e
    Configure caches according to the Atmel AT697E device (LEON2 only). See Chapter 11 for details on AT697 emulation.
-banks ram_banks
    Sets how many RAM banks the SRAM is divided on. Supported values are 1, 2 or 4. Default is 1. (LEON only).
-bopt
    Enables idle-loop optimisation (see Section 4.1.5).
-bp
    Enables emulation of LEON3/4 branch prediction
-bz
    Halt execution on all traps except privileged_instruction, fpu_disabled, window_overflow, window_underflow, asynchronous_interrupt and trap_instruction (As GRMON does when not using the -nb option). This halts at the pc and in the register window of the trapping instruction. Note that this does not function as an ordinary break in execution; continuing from this halt will re-execute the trapping instruction.
-c file
    Reads commands from file and executes them at startup.
-cfg file
    Reads extra configuration options from file.
-cfgreg_and and_mask, -cfgreg_or or_mask
    LEON2 only: Patch the Leon Configuration Register (0x80000024). The new value will be: (reg & and_mask) | or_mask.
-covtrans
    Enable MMU translations for the coverage system. Needed when MMU is enabled and not mapping 1-to-1.
-cpm cp_module
    Use cp_module as loadable co-processor module file name (LEON). The environmental variable TSIM_MODULE_PATH can be set to a ':' separated ( ';' in WIN32) list of search paths.
-cas (-nocas)
    When running a VXWORKS SMP image the SPARCV9 "casa" instruction is used. The option -cas enables this instruction (LEON3/4 only). The -nocas option can disable CAS support when otherwise already enabled.
```

- dcsize *size*  
Defines the set-size (KiB) of the LEON data cache. Allowed values are powers of two in the range 1 - 64 for LEON2 and 1-256 for LEON3/4. Default is 4 KiB.
- dlock  
Enable data cache line locking. Default is disabled. (LEON only).
- dlram *addr size*  
Allocates *size* KiB of local dcache scratchpad memory at address *addr*. (LEON3/4)
- dlsiz *size*  
Sets the line size of the LEON data cache (in bytes). Allowed values are 16 or 32. Default is 16.
- drepl *repl*  
Sets the replacement algorithm for the LEON data cache. Allowed values are *rnd* (default for LEON2) for random replacement, *lru* (default for LEON3/4) for the least-recently-used replacement algorithm and *lrr* for the least-recently-replaced replacement algorithm.
- dsets *sets*  
Defines the number of sets in the LEON data cache. Allowed values are 1 - 4.
- eclipse  
Enable some special handling of the GDB protocol when connecting with Eclipse.
- exc2b  
Issue 0x2b memory exception on memory write store error (LEON2 only)
- ext *nr*  
Enable extended irq ctrl with extended irq number *nr* (LEON3/4 only)
- fast\_uart  
Run UARTs at infinite speed, rather than with correct baud rate.
- fpm *fp\_module*  
Use *fp\_module* as loadable FPU module rather than a built in FPU model or looking for the default *fp.so/dll* module (LEON only). The environmental variable *TSIM\_MODULE\_PATH* can be set to a ':' separated (';' in WIN32) list of search paths.
- freq *system\_clock*  
Sets the simulated system clock (MHz). Will affect UART timing and performance statistics. Default is 14 for ERC32 and 50 for LEON.
- gdb  
Listen for GDB connection directly at start-up.
- gdbuartfwd  
Forward output from first UART to GDB.
- gr702rc  
Set cache parameters to emulate the GR702RC device.
- gr712rc  
Set parameters to emulate the GR712RC device (albeit as a single processor device). Must be used when using the GR712RC AHB module. This also sets up TSIM to simulate 6 APBUART cores and the GR-TIMER core. See Chapter 10 for details on GR721RC emulation.
- grfpu  
Emulate the GRFPU floating point unit, rather than Meiko or GRFPU-lite (LEON only).
- hwbp  
Use TSIM hardware breakpoints for gdb breakpoints.
- stack *addr*  
Set initial stack pointer.
- i  
Forces bootloader-like initialization even when running from ROM. See the **run** and **go** commands for details. See also the **-ni** option.
- icsize *size*  
Defines the set-size (KiB) of the LEON instruction cache. Allowed values are powers of two in the range 1 - 64 for LEON2 and 1-256 for LEON3/4. Default is 4 KiB.
- ift  
Generate illegal instruction trap on IFLUSH. Emulates the IFT input on the ERC32 processor.
- ilock  
Enable instruction cache line locking. Default is disabled.

- ilram *addr size*  
Allocates *size* bytes of local icache scratchpad memory at address *addr*. (LEON3/4)
- ilsize *size*  
Sets the line size of the LEON instruction cache (in bytes). Allowed values are 16 or 32. Default is 16 for LEON2/3 and 32 for LEON4.
- iom *io\_module*  
Use *io\_module* as loadable I/O module rather than the default io.so. The environmental variable TSIM\_MODULE\_PATH can be set to a ':' separated ( ';' in WIN32) list of search paths.
- irepl *repl*  
Sets the replacement algorithm for the LEON instruction cache. Allowed values are rnd (default for LEON2) for random replacement, lru (default for LEON3/4) for the least-recently-used replacement algorithm and lrr for the least-recently-replaced replacement algorithm.
- isets *sets*  
Defines the number of sets in the LEON instruction cache. Allowed values are 1(default) - 4.
- iwde  
Set the IWDE input to 1. Default is 0. (TSC695E only)
- l2wsize *size*  
Enable emulation of L2 cache (LEON4 only) with *size* KiB. The *size* must be binary aligned (e.g. 16, 32, 64 ...).
- logfile *filename*  
Logs the console output to *filename*. If *filename* is preceded by '+' output is append.
- mcfgX *value*  
Set the reset value of memory configuration register X, where X can be 1, 2 or 3 (LEON only).
- mfailok  
Do not fail on startup even if explicitly requested io/ahb modules fails to load.
- mflat  
This switch should be used when the application software has been compiled with the gcc -mflat option, and debugging with gdb is done.
- mmu / -nommu  
Enables or disables MMU support (LEON only). By default LEON2 and LEON3 does not have MMU support, and LEON4 has MMU support. Chip options, e.g. -gr712rc, enables MMU support when the corresponding chip has it.
- nb  
Do not break on error exceptions when debugging through GDB. This also enables the -hwbp option.
- nfp  
Disables the FPU to emulate system without FP hardware. Any FP instruction will generate an FP disabled trap.
- ni  
Prevents bootloader-like initialization even when not running from ROM. See the **run** and **go** commands for details. See also the -i option.
- nomac  
Disable LEON MAC instruction. (LEON only).
- noeditline  
Disable use of editline for history and tab completion.
- nosram  
Disable SRAM on startup. SDRAM will appear at 0x40000000 (LEON only).
- nothreads  
Disable threads support.
- nouart  
Disable emulation of UARTs. All access to UART registers will be routed to the I/O module.
- nov8  
Disable SPARC V8 MUL/DIV instructions (LEON only).
- nrtimers *val*  
Adds support for more than 2 timers. Value *val* can be in the range of 2 - 7 (LEON3/4 only). Default: 2. See also the -sametimerirq and -timerirqbase *number* switches.

- numbp *num*  
Sets the upper limit on number of possible breakpoints.
- numwp *num*  
Sets the upper limit on number of possible watchpoints.
- nwin *win*  
Defines the number of register windows in the processor. The default is 8. Only applicable to LEON3/4.
- port *portnum*  
Use *portnum* for gdb communication (port 1234 is default)
- pr  
Enable profiling.
- ram *ram\_size*  
Sets the amount of simulated RAM (KiB). Default is 4096.
- rest *file\_name*  
Restore saved state from *file\_name.tss*. See Section 3.8.
- rom *rom\_size*  
Sets the amount of simulated ROM (KiB). Default is 2048.
- rom8, -rom16  
By default, the PROM area at reset time is considered to be 32-bit. Specifying -rom8 or -rom16 will initialise the memory width field in the memory configuration register to 8- or 16-bits. The only visible difference is in the instruction timing.
- rtms *ver*  
Override autodetected RTEMS version for thread support. *ver* should be 46, 48, 48-edisoft or 410.
- sametimerirq  
Force the irq number to be the same for all timers. Default: separate increasing irqs for each timer. (LEON3/4 only). See also the -nrtimers *val* and -timerirqbase *number* switches.
- sdram *sdram\_size*  
Sets the amount of simulated SDRAM (MiB). Default is 32. (LEON only)
- sdbanks <1 | 2>  
Sets the SDRAM banks. This parameter is used to calculate the used SDRAM in conjunction with the mcfg2.sdramsize field. The actually used SDRAM at runtime is sdbanks\*mcfg2.sdramsize. Default:1 (LEON only)
- sym *file*  
Read symbols from *file*. Useful for self-extracting applications
- timer32  
Use 32 bit timers instead of 24 bit. (LEON2 only)
- timerirqbase *number*  
Set the irq number of the first timer to interrupt number *number* (LEON3/4 only). Default: 8. See also the -nrtimers *val* and -sametimerirq switches.
- tsc691  
Emulate the TSC691 device, rather than TSC695
- tsc695e  
Obsolete. TSIM/ERC32 now always emulates the TSC695 device rather than the early ERC32 chip-set.
- uartX *device*  
This option connects the chosen UART to a serial device. Here, X can be in the range 1 up to the number of uarts. By default, UART1 is connected to stdin/stdout and all others are disconnected.  
  
On Linux, e.g. connecting the first uart to /dev/ttyUSB0 can be done with “-uart1 /dev/ttyUSB0”. On Linux, using the device /dev/ptmx will create a pseudo-terminal pair with the chosen uart at one end. TSIM prints out the name of the other end of the pair to be opened by host software communicating with the chosen uart.  
  
On Windows use //./com1, //./com2 etc. to access the serial ports. The serial port settings can be adjusted by opening the relevant entry under “Ports (COM and LPT)” entry in the Device Manager and choosing the “Port Settings” tab in the dialogue that pops up.
- uart\_fs <1 | 2 | 4 | 8 | 16 | 32>  
UART FIFO depth in characters (LEON3/4 only). This setting affects all APBUARTs in the system. Valid configurations are 1 (default), 2, 4, 8, 16 and 32 characters. If the FIFO depth is configured to 1 the UART FIFO is not present instead only the holding register is present and FIFO level interrupts are not present.

The FIFO interface is available for both fast and accurate mode, however the transmitter side in fast mode never fills the FIFO since characters are always sent immediately.

- ut699  
Set parameters to emulate the UT699 device. Must be used when using the UT699 AHB module. Note that when -ut699 is given, snooping will be set as non-functional. This also sets up TSIM to simulate only one APBUART core. See Chapter 7 for details on UT699 emulation.
- ut699e  
Set parameters to emulate the UT699E device. Must be used when using the UT699E AHB module. This also sets up TSIM to simulate only one APBUART core. See Chapter 8 for details on UT699E emulation.
- ut700  
Set parameters to emulate the UT700 device. Must be used when using the UT700 AHB module. This also sets up TSIM to simulate only one APBUART core. See Chapter 9 for details on UT700 emulation.
- wdfreq *freq*  
Specify the frequency of the watchdog clock. (ERC32 only)
- input\_files*  
Executable files to be loaded into memory. The input file is loaded into the emulated memory according to the entry point for each segment. Recognized formats are elf32, aout and records.

Command line options can also be specified in the file .tsimcfg in the home directory. This file will be read at startup and the contents will be appended to the command line.

### 3.3. Standalone mode commands

If the file .tsimrc exists in the home directory, it will be used as a batch file and the commands in it will be executed at startup.

Below is a description of commands that are recognized by the simulator when used in standalone mode:

- batch** *file*  
Execute a batch file of TSIM commands.
- blod** *file* [*startaddr*]  
Load the binary file *file* into memory starting at *startaddr*. The default *startaddr* is the start of RAM memory.
- +bp, break** *address*  
Adds an breakpoint at *address*.
- bp, break**  
Prints all breakpoints and watchpoints.
- bp, del** [*num*]  
Deletes breakpoint/watchpoint *num*. If *num* is omitted, all breakpoints and watchpoints are deleted.
- bt**  
Print backtrace.
- cont** [*instructions* | *amount timeunit*]  
Continue execution at present position, optionally for a number of instructions or an amount of time. See Section 3.3.1 for the syntax for specifying time.
- coverage** <**enable** | **disable** | **save** [*file\_name*] | **clear** | **print** *address* [*len*]>  
Code coverage control. Coverage can be enabled, disabled, cleared, saved to a file or printed to the console.
- dump** *file address length*  
Dumps memory content to file *file*, in whole aligned words. The *address* argument can be a symbol.
- dis** [*addr*] [*count*]  
Disassemble [*count*] instructions at address [*addr*]. Default values for count is 16 and *addr* is the program counter address.
- echo** *string*  
Print *string* to the simulator window.
- edac** [**clear** | **cerr** | **merr** *address*]  
Insert EDAC errors, or clear EDAC checksums (ERC32 only)
- ep** [**clear**|*address*]  
Show, clear or set entry point for execution. Setting the entry point overrides the default start of execution address for **run** and **go** commands.

### event

Print events in the event queue. Only user-inserted events are printed.

### flush [**all** | **icache** | **dcache** | *addr*]

Flush the LEON caches. Specifying **all** will flush both the icache and dcache. Specifying **icache** or **dcache** will flush the respective cache. Specifying *addr* will flush the corresponding line in both caches.

### float [-v]

Prints the FPU registers. With the optional **-v** argument, the fields of the fsr registers are listed and denormalized numbers are marked.

### gdb

Listen for gdb connection.

### go [*address/symbol* | **-t**] [*instructions* | *amount timeunit*]

The **go** command will continue execution without restarting the simulation. If an address or symbol is given, execution starts from there. Otherwise, if an entry point has been set with the **ep** command, execution starts from that entry point. Otherwise execution starts from the entry point of the last loaded image.

If the simulation time is at 0 (e.g. due to TSIM having just been started or due to the **reset** command) and the address execution is being started from is not the reset address (i.e. address 0), TSIM sets up memory controllers, timers and the like normally done by a bootloader in order to be able to run memory images without a bootloader. Starting TSIM with the **-i** option forces such an initialization even when starting from the reset address (but still only when the time is 0) and starting TSIM with the **-ni** option prevents TSIM from doing such initialization in any case.

If an address or symbol is specified, or **-t** is used instead of an address or symbol, an optional number of instructions or amount of time to stop after can also be specified. See Section 3.3.1 for the syntax for specifying time.

### help

Print a small help menu for the TSIM commands.

### hist [*length*|-*file*]

**hist** *length* enables (or disables) the instruction trace buffer. The *length* last executed instructions will be placed in the trace buffer. Specifying a zero trace length will disable the trace buffer.

**hist** with no arguments will display the trace buffer. See the **inst** [*length*] command for displaying only a part of the instruction trace buffer.

**hist -f filename** will write the history trace to file.

### icache, dcache

Dumps the contents of tag and data cache memories (LEON only).

### inc *cycles* | *amount timeunit*

Increment simulator time without executing instructions for a number of cycles or an amount of time. The event queue is evaluated during the advancement of time. See Section 3.3.1 for the syntax for specifying time.

### inst [*length*]

Display the latest *length* (default 30) instructions in the instruction trace buffer. See the **hist** [*length*|-*file*] command for how to enable the instruction trace buffer.

### leon

Display LEON peripherals registers.

### load *files*

Load *files* into simulator memory.

### l2cache

Display contents of L2 cache. (LEON4 only)

### mcfgX [*value*]

Set or show the user defined reset value of memory configuration register *X*, where *X* can be 1, 2 or 3 (LEON only).

### mec

Display ERC32 MEC registers.

### mem [*addr*] [*count*]

Display memory at *addr* for *count* bytes. Same default values as for **dis**. Unimplemented registers are displayed as zero.

**vmem** [*vaddr*] [*count*]

Same as **mem** but does a MMU translation on *vaddr* first (LEON only).

**mmu**

Display the MMU registers (LEON only).

**quit**

Exits the simulator.

**perf** [**reset**]

The **perf** command will display various execution statistics. A ‘perf reset’ command will reset the statistics. This can be used if statistics shall be calculated only over a part of the program. The **run** and **reset** command also resets the statistic information.

**prof** [**0|1**] [*stime*]

Enable (‘prof 1’) or disable (‘prof 0’) profiling. Without parameters, profiling information is printed. Default sampling period is 1000 clock cycles, but can be changed by specifying *stime*.

**reg** [*reg\_name* [*value*]|*window*]

Prints and sets the IU registers in the current register window, prints and sets individual registers and prints other register windows. **reg** without parameters prints the IU registers of the current register window. **reg** *reg\_name* shows the value of the corresponding register. Valid register names are psr, tbr, wim, y, pc, npc, fsr, g1-g7, o0-o7, i0-i7, f0-f31. **reg** *reg\_name value* sets the corresponding register to *value*. To view a certain register window, use **reg** *wn*, where *n* is the index of the register window.

**reset**

Performs a power-on reset without starting any execution.

**restore** *file*

Restore simulator state from *file*.

**run** [*address/symbol* | **-t**] [*instructions* | *amount timeunit*]

Resets the simulator and starts simulation from time 0. The event queue is emptied but any set breakpoints remain. If an address or symbol is given, execution starts from there. Otherwise, if an entry point has been set with the **ep** command, execution starts from that entry point. Otherwise execution starts from the reset address (i.e. address 0) if a binary is loaded there or from the entry point from the last loaded image if the memory at the reset address is zero.

If execution starts from the reset address, no bootloader-like initialization of the system is done. Otherwise TSIM sets up memory controllers, timers and the like normally done by a bootloader in order to be able to run memory images without a bootloader. Starting TSIM with the **-i** option forces such an initialization even when starting from the reset address and starting TSIM with the **-ni** option prevents TSIM from doing such initialization in any case.

If an address or symbol is specified, or **-t** is used instead of an address or symbol, an optional number of instructions or amount of time to stop after can also be specified. See Section 3.3.1 for the syntax for specifying time.

**save** *file*

Save simulator state to *file*.

**shell** *cmd*

Execute the command *cmd* in the host system shell.

**stack** [**clear**]*address*]

Show, clear or set initial stack pointer. Setting the stack pointer will override the default stack pointer. Clearing a set stack pointer will make TSIM go back to setting a default stack pointer.

**step**

Execute and disassemble one instruction. See also **trace** [*instructions* | *amount timeunit*].

**sym** [*file*]

Load symbol table from *file*. If *file* is omitted, prints current (.text) symbols.

**trace** [*instructions* | *amount timeunit*]

Executes and disassembles instruction(s). Equivalent to the **cont** but with each instruction disassembled as it is executed. An optional number of instructions or amount of time to stop after can also be specified. See Section 3.3.1 for the syntax for specifying time.

**version**

Prints the TSIM version and build date.



**walk** *address* [*iswrite*|*isid*|*issu*]\*

If the MMU is enabled printout a table walk for the given address. The flags *iswrite*, *isid* and *issu* are specifying the context: *iswrite* for a write access (default read), *isid* for a icache access (default dcache), *issu* for a supervisor access (default user).

**watch** *address*

Adds a watchpoint at *address*.

**wmem, wmemh, wmemb** *address value*

Write a word, half-word or byte directly to simulated memory.

**xwmem** *asi address value*

Write a word to simulated memory using ASI=*asi*. Applicable to LEON3/4.

Typing a ‘Ctrl-C’ will interrupt a running simulator. Short forms of the commands are allowed, e.g **c**, **co**, or **con**, are all interpreted as **cont**.

### 3.3.1. Time specification for commands

Commands such as **run**, **cont**, **go**, **trace** and **int** supports simulating for a specified amount of time.

If an amount without a unit is specified, execution will stop after the specified number of instructions (except for the **inc** command that will stop after that many cycles). If an amount and a time unit (with whitespace between) is specified, the execution will continue until the given time has passed (relative to the current time). The following time units are supported:

Table 3.1. Time units for commands that run simulation

Argument	Unit
c	cycles
us	microseconds
ms	milliseconds
s	seconds
min	minutes
h	hours
d	days

### 3.4. Symbolic debug information

TSIM will automatically extract (.text) symbol information from elf-files. The symbols can be used where an address is expected:

```
tsim> break main
breakpoint 3 at 0x020012f0: main
tsim> dis strcmp 5
02002c04 84120009 or      %o0, %o1, %g2
02002c08 8088a003 andcc    %g2, 0x3, %g0
02002c0c 3280001a bne,a     0x02002c74
02002c10 c64a0000 ldsb     [%o0], %g3
02002c14 c6020000 ld      [%o0], %g3
```

The **sym** command can be used to display all symbols, or to read in symbols from an alternate (elf) file:

```
tsim> sym /opt/rtems/src/examples/samples/dhry
read 234 symbols
tsim> sym
0x02000000 L _text_start
0x02000000 L _trap_table
0x02000000 L text_start
0x02000000 L start
0x0200102c L _window_overflow
0x02001084 L _window_underflow
0x020010dc L _fpdis
```

Reading symbols from alternate files is necessary when debugging self-extracting applications, such as bootproms created with mkprom or linux/uClinux.

### 3.5. Breakpoints and watchpoints

TSIM supports execution breakpoints and write data watchpoints. In standalone mode, hardware breakpoints are always used and no instrumentation of memory is made. When using the gdb interface, the gdb ‘break’ command normally uses software breakpoints by overwriting the breakpoint address with a ‘ta 1’ instruction. Hardware breakpoints can be inserted by using the gdb ‘hbreak’ command or by starting tsim with -hwbp, which will force the use of hardware breakpoints also for the gdb ‘break’ command. Data write watchpoints are inserted using the ‘watch’ command. A watchpoint can only cover one word address, block watchpoints are not available.

### 3.6. Profiling

The profiling function calculates the amount of execution time spent in each subroutine of the simulated program. This is made without intervention or instrumentation of the code by periodically sample the execution point and the associated call tree. Cycles in the call graph are properly handled, as well as sections of the code where no stack is available (e.g. trap handlers). The profiling information is printed as a list sorted on highest execution time ratio. Profiling is enabled through the **prof 1** command. The sampling period is by default 1000 clocks which typically provides a good compromise between accuracy and performance. Other sampling periods can also be set through the **prof 1 n** command. Profiling can be disabled through the **prof 0** command. Below is an example profiling the dhrystone benchmark:

```

bash$tsim-erc32 /opt/rtems/src/examples/samples/dhry
tsim> pro 1
profiling enabled, sample period 1000
tsim> go
resuming at 0x02000000
Execution starts, 200000 runs through Dhrystone
Stopped at time 23375862 (1.670e+00 s)
tsim> pro
function      samples      ratio(%)
start         36144        100.00
_start        36144        100.00
main          36134        99.97
Proc_1        10476        28.98
Func_2        9885         27.34
strcmp        8161         22.57
Proc_8        2641         7.30
.div          2097         5.80
Proc_6        1412         3.90
Proc_3        1321         3.65
Proc_2        1187         3.28
.umul         1092         3.02
Func_1        777          2.14
Proc_7        772          2.13
Proc_4        731          2.02
Proc_5        453          1.25
Func_3        227          0.62
printf        8            0.02
vfprintf      8            0.02
_vfprintf_r   8            0.02

tsim>

```

### 3.7. Code coverage

To aid software verification, the professional version of TSIM includes support for code coverage. When enabled, code coverage keeps a record for each 32-bit word in the emulated memory and monitors whether the location has been read, written or executed. The coverage function is controlled by the coverage command:

- coverage enable**                    enable coverage
- coverage disable**                disable coverage
- coverage save [filename]**        write coverage data to file (file name optional)

**coverage print address [len]** print coverage data to console, starting at address  
**coverage clear** reset coverage data

The coverage data for each 32-bit word of memory consists of a 5-bit field, with bit0 (lsb) indicating that the word has been executed, bit1 indicating that the word has been written, and bit2 that the word has been read. Bit3 and bit4 indicates the presence of a branch instruction; if bit3 is set then the branch was taken while bit4 is set if the branch was not taken.

As an example, a coverage data of 0x6 would indicate that the word has been read and written, while 0x1 would indicate that the word has been executed. When the coverage data is printed to the console or save to a file, it is presented for one block of 32 words (128 bytes) per line:

```
tsim> cov print start
02000000 : 1 1 1 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 1 1 1 1 1 1 0 0 0 0
02000080 : 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
02000100 : 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
02000180 : 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
```

When the code coverage is saved to file, only blocks with at least one coverage field set are written to the file. Block that have all the coverage fields set to zero are not saved in order to decrease the file size.

NOTE: Only the internally emulated memory (PROM, SRAM and SDRAM) are subject for code coverage. Any memory emulated in the user's I/O module must be handled by a user-defined coverage function.

The address ranges that are monitored are based on TSIM's startup parameters. For instance, the range corresponding to the SDRAM for LEON will begin at address 0x40000000 if TSIM was started with -nosram or -ram 0, or will begin at 0x60000000 otherwise. Reconfiguration of the memory controller during execution will not be taken into account for monitored address ranges. Coverage information on memory reads will be recorded even for cache hits.

NOTE on MMU and coverage: The TSIM coverage system does no address translations by default, for performance reasons. To get physical address coverage when the MMU is enabled and not mapping 1-to-1, use the -covtrans option. The monitored address ranges are based on the physical addresses where TSIM emulates ROM, SRAM or SDRAM. There is no support for getting virtual address coverage for virtual addresses that untranslated would go outside these memory ranges.

When coverage is enabled, disassembly will include an extra column after the address, indicating the coverage data. This makes it easier to analyse which instructions has not been executed:

```
tsim> di start
02000000 1 a0100000 clr %l0
02000004 1 29008004 sethi %hi(0x2001000), %l4
02000008 1 81c52000 jmp %l4
0200000c 1 01000000 nop
02000010 0 91d02000 ta 0x0
02000014 0 01000000 nop
02000018 0 01000000 nop
```

The coverage data is not saved or restored during check-pointing operations. When enabled, the coverage function reduces the simulation performance of about 30%. When disabled, the coverage function does not impact simulation performance. Individual coverage fields can be read and written using the TSIM function interface using the `tsim_coverage()` call (see Section 6.2). Enabling and disabling the coverage functionality from the function interface should be done using `tsim_cmd()`.

Example scripts for annotating C code using saved coverage information from TSIM can be found in the coverage sub-directory.

### 3.8. Check-pointing

The professional version of TSIM can save and restore its complete state, allowing to resume simulation from a saved check-point. Saving the state is done with the **save** command:

```
tsim> save file_name
```

The state is saved to `file_name.tss`. To restore the state, use the **restore** command:

```
tsim> restore file_name
```

The state will be restored from `file_name.tss`. Restore directly at startup can be performed with the `'-rest file_name'` command line switch.

NOTE: TSIM command line options are not stored (such as alternate UART devices, etc.).

NOTE: AT697, UT699, UT700 and GR712RC simulation modules do not support check-pointing.

### 3.9. Performance

TSIM is highly optimised, and capable of simulating ERC32 systems faster than realtime. On high-end Athlon processors, TSIM achieves more than 1 MIPS / 100 MHz (CPU frequency of host). Enabling various debugging features such as watchpoints, profiling and code coverage can however reduce the simulation performance.

### 3.10. Backtrace

The `bt` command will display the current call backtrace and associated stack pointer:

```
tsim> bt
      %pc          %sp
#0  0x0200190c    0x023ffcc8  Proc_1 + 0xf0
#1  0x02001520    0x023ffd38  main + 0x230
#2  0x02001208    0x023ffe00  _start + 0x60
#3  0x02001014    0x023ffe40  start + 0x1014
```

### 3.11. Connecting to gdb

TSIM can act as a remote target for `gdb`, allowing symbolic debugging of target applications. To initiate `gdb` communication, start the simulator with the `-gdb` switch or use the TSIM **gdb** command:

```
bash-2.04$ ./tsim -gdb
TSIM/LEON - remote SPARC simulator, build 2001.01.10 (demo version)
serial port A on stdin/stdout
allocated 4096 K RAM memory
allocated 2048 K ROM memory
gdb interface: using port 1234
```

Then, start `gdb` in a different window and connect to TSIM using the extended-remote protocol:

```
bash-2.04$ sparc-rtems-gdb t4.exe
(gdb) target extended-remote localhost:1234
Remote debugging using localhost:1234
0x0 in ?? ()
(gdb)
```

To interrupt simulation, `Ctrl-C` can be typed in both `gdb` and TSIM windows. The program can be restarted using the `gdb run` command but a **load** has first to be executed to reload the program image into the simulator:

```
(gdb) load
Loading section .text, size 0x14e50 lma 0x40000000
Loading section .data, size 0x640 lma 0x40014e50
Start address 0x40000000 , load size 87184
Transfer rate: 697472 bits/sec, 278 bytes/write.
(gdb) run
The program being debugged has been started already.
Start it from the beginning? (y or n) y
Starting program: /home/jgais/src/gnc/t4.exe
```

If `gdb` is detached using the **detach** command, the simulator returns to the command prompt, and the program can be debugged using the standard TSIM commands. The simulator can also be re-attached to `gdb` by issuing the **gdb** command to the simulator (and the **target** command to `gdb`). While attached, normal TSIM commands can be executed using the `gdb monitor` command. Output from the TSIM commands is then displayed in the `gdb` console.

TSIM translates SPARC traps into (Unix) signals which are properly communicated to gdb. If the application encounters a fatal trap, simulation will be stopped exactly on the failing instruction. The target memory and register values can then be examined in gdb to determine the error cause. To disable this and let execution continue through the corresponding trap handler instead, use the `-nb` startup option.

Profiling an application executed from gdb is possible if the symbol table is loaded in TSIM before execution is started. gdb does not download the symbol information to TSIM, so the symbol table should be loaded using the monitor command:

```
(gdb) monitor sym t4.exe
read 158 symbols
```

When an application that has been compiled using the `gcc -mflat` option is debugged through gdb, TSIM should be started with `-mflat` in order to generate the correct stack frames to gdb.

## 3.12. Thread support

TSIM has thread support for the RTEMS operating system. Additional OS support will be added to future versions. The GDB interface of TSIM is also thread aware and the related GDB commands are described later.

### 3.12.1. TSIM thread commands

**thread info** - lists all known threads. The currently running thread is marked with an asterisk. (The wide example output below has been split into two parts.)

```
tsim> thread info
```

Name	Type	Id	Prio	Time (h:m:s)	Entry point	...
Int.	internal	0x09010001	255	5:30.682722	bsp_idle_thread	...
UI1	classic	0x0a010001	100	0.041217	system_init	...
ntwk	classic	0x0a010002	100	0.251199	soconnsleep	...
ETH0	classic	0x0a010003	100	0.000161	soconnsleep	...
* TA1	classic	0x0a010004	1	0.034739	prep_timer	...
TA2	classic	0x0a010005	1	0.025740	prep_timer	...
TA3	classic	0x0a010006	1	0.021357	prep_timer	...
TTCP	classic	0x0a010007	100	0.002914	rtems_ttcp_main	...

...	PC	State
...	0x40044bec _Thread_Dispatch + 0xd8	READY
...	0x40044bec _Thread_Dispatch + 0xd8	SUSP
...	0x40044bec _Thread_Dispatch + 0xd8	READY
...	0x40044bec _Thread_Dispatch + 0xd8	Wevnt
...	0x40006a28 printf + 0x4	READY
...	0x40044bec _Thread_Dispatch + 0xd8	DELAY
...	0x40044bec _Thread_Dispatch + 0xd8	DELAY
...	0x40044bec _Thread_Dispatch + 0xd8	Wevnt

**thread bt** *id* prints a backtrace of a thread.

```
tsim> thread bt 0x0a010007
```

```

%%pc
#0 0x40044bec  _Thread_Dispatch + 0xd8
#1 0x400418f8  rtems_event_receive + 0x74
#2 0x40031eb4  rtems_bsdnet_event_receive + 0x18
#3 0x40032050  soconnsleep + 0x50
#4 0x40033d48  accept + 0x60
#5 0x4000366c  rtems_ttcp_main + 0xda0

```

A backtrace of the current thread (equivalent to normal bt command):

```

tsim> thread bt
%%pc
#0 0x40006a28  0x4008d7d0  printf + 0x0
#1 0x40001c04  0x4008d838  Test_task + 0x178
#2 0x4005c88c  0x4008d8d0  _Thread_Handler + 0xfc
#3 0x4005c78c  0x4008d930  _Thread_Evaluate_mode + 0x58

```

### 3.12.2. GDB thread commands

TSIM needs the symbolic information of the image that is being debugged to be able to check for thread information. Therefore the symbols needs to be read from the image using the **sym** command before issuing the **gdb** command. When a program running in GDB stops TSIM reports which thread it is in. The command **info threads** can be used in GDB to list all known threads.

```

Program received signal SIGINT, Interrupt.
[Switching to Thread 167837703]

0x40001b5c in console_outbyte_polled (port=0, ch=113 'q') at ../../../../../../../../../../rtems-4.6.5/c/src/lib/libbsp/sparc/leon3/console/debugputs.c:38
38      while ( (LEON3_Console_Uart[LEON3_Cpu_Index+port]->status && LEON_REG_UART_STATUS_THE)
== 0 );

```

```

(gdb) info threads

 8 Thread 167837702 (FTPD Wevnt) 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
 7 Thread 167837701 (FTPa Wevnt) 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
 6 Thread 167837700 (Dctx Wevnt) 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
 5 Thread 167837699 (DCrx Wevnt) 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
 4 Thread 167837698 (ntwk ready) 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
 3 Thread 167837697 (UI1 ready) 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
 2 Thread 151060481 (Int. ready) 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
* 1 Thread 167837703 (HTPD ready ) 0x40001b5c in console_outbyte_polled (port=0, ch=113 'q')
  at ../../../../../../../../../../rtems-4.6.5/c/src/lib/libbsp/sparc/leon3/console/debugputs.c:38

```

Using the **thread** command a specified thread can be selected:

```

(gdb) thread 8

[Switching to thread 8 (Thread 167837702)]#0 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
109      _Context_Switch( &executing->Registers, &heir->Registers );

```

Then a backtrace of the selected thread can be printed using the **bt** command:

```

(gdb) bt

#0 0x4002f760 in _Thread_Dispatch () at ../../../../../../../../../../rtems-4.6.5/cpukit/score/src/threaddispatch.c:109
#1 0x40013ee0 in rtems_event_receive (event_in=33554432, option_set=0, ticks=0, event_out=0x43feccl4)
  at ../../../../../../leon3/lib/include/rtems/score/thread.inl:205
#2 0x4002782c in rtems_bsdnet_event_receive (event_in=33554432, option_set=2, ticks=0, event_out=0x43feccl4)
  at ../../../../../../rtems-4.6.5/cpukit/libnetworking/rtems/rtems_glue.c:641
#3 0x40027548 in soconnsleep (so=0x43f0cd70) at ../../../../../../../../../../rtems-4.6.5/cpukit/libnetworking/rtems/rtems_glue.c:465
#4 0x40029118 in accept (s=3, name=0x43feccf0, namelen=0x43feccec) at ../../../../../../../../../../rtems-

```

```
4.6.5/cpukit/libnetworking/rtems/rtems_syscall.c:215
#5 0x40004028 in daemon () at ../../../../../../rtems-4.6.5/c/src/libnetworking/rtems_servers/
ftpd.c:1925
#6 0x40053388 in _Thread_Handler () at ../../../../../../rtems-4.6.5/cpukit/score/src/threadhan-
dler.c:123
#7 0x40053270 in __res_mkquery (op=0, dname=0x0, class=0, type=0, data=0x0, datalen=0,
newrr_in=0x0, buf=0x0, buflen=0)
at ../../../../../../rtems-4.6.5/cpukit/libnetworking/lib/res_mkquery.c:199
```

It is possible to use the **frame** command to select a stack frame of interest and examine the registers using the **info registers** command. Note that the **info registers** command only can see the following registers for an inactive task: g0-g7, i0-i7, o0-o7, pc and psr. The other registers will be displayed as 0:

```
(gdb) frame 5

#5 0x40004028 in daemon () at ../../../../../../rtems-4.6.5/c/src/libnetworking/rtems_servers/
ftpd.c:1925
1925      ss = accept(s, (struct sockaddr *)&addr, &addrLen);

(gdb) info reg

g0          0x0          0
g1          0x0          0
g2          0xffffffff  -1
g3          0x0          0
g4          0x0          0
g5          0x0          0
g6          0x0          0
g7          0x0          0
o0          0x3          3
o1          0x43feccf0   1140772080
o2          0x43feccec   1140772076
o3          0x0          0
o4          0xf34000e4  -213909276
o5          0x4007cc00   1074252800
sp          0x43fec888   0x43fec888
o7          0x40004020   1073758240
i0          0x4007ce88   1074253448
i1          0x4007ce88   1074253448
i2          0x400048fc   1073760508
i3          0x43feccf0   1140772080
i4          0x3          3
i5          0x1          1
i6          0x0          0
i7          0x0          0
i8          0x0          0
i9          0x0          0
i10         0x0          0
i11         0x40003f94   1073758100
i12         0x0          0
i13         0x43ffa8c8   1140830152
i14         0x0          0
i15         0x4007cd40   1074253120
fp          0x43fec808   0x43fec808
i17         0x40053380   1074082688
y           0x0          0
psr         0xf34000e0  -213909280
wim         0x0          0
tbr         0x0          0
pc          0x40004028   0x40004028 <daemon+148>
npc         0x4000402c   0x4000402c <daemon+152>
fsr         0x0          0
csr         0x0          0
```

It is not supported to set thread specific breakpoints. All breakpoints are global and stops the execution of all threads. It is not possible to change the value of registers other than those of the current thread.

### 3.13. Synchronising TSIM time to external time

To maximise simulation performance, TSIM executes as fast as possible doing no synchronisation of the simulation time with any external notion of time. This is especially apparent when the processor is in power-down mode and simulation time is increased by the events in the event queue alone.

To synchronise the simulation time with an external notion of time, events that handles synchronisation needs to be added to the event queue. The `walltimesync` example AHB module in the `iomod` directory provides an example that makes sure that TSIM does not execute faster than real time. This example can be used as a template for synchronising to other notions of time. See Chapter 5 on how to use modules.

## 4. Emulation characteristics

### 4.1. Common behaviour

#### 4.1.1. Timing

The simulator time is maintained and incremented according to the IU and FPU instruction timing. The parallel execution between the IU and FPU is modelled, as well as stalls due to operand dependencies. Instruction timing has been modelled after the real devices. Integer instructions have a higher accuracy than floating-point instructions due to the somewhat unpredictable operand-dependent timing of the ERC32 and LEON MEIKO FPU. Typical usage patterns have higher accuracy than atypical ones, e.g. having vs. not having caches enabled on LEON systems. Tracing using the `inst` or `hist` command will display the current simulator time in the left column. This time indicates when the instruction is fetched. Cache misses, waitstates or data dependencies will delay the following fetch according to the incurred delay.

#### 4.1.2. UARTs

The UART model can be operating in two modes, correct timing and fast mode. In the correct timing mode the baud rate and frame length is taken into account but in fast mode the UARTs operate at infinite speed. In fast mode the transmitter FIFO/holding register is always empty and a transmitter empty interrupt is generated directly after each write to the transmitter data register. The receivers can never overflow or generate errors. Fast mode is enabled with the `-fast_uart` switch.

Note that with correct UART timing, it is possible that the last character of a program is not displayed on the console. This can happen if the program forces the processor in error mode, thereby terminating the simulation, before the last character has been shifted out from the transmitter shift register. To avoid this, an application should poll the UART status register and not force the processor in error mode before the transmitter shift registers are empty. The real hardware does not exhibit this problem since the UARTs continue to operate even when the processor is halted.

##### 4.1.2.1. APBUART model (LEON3/4 only)

The APBUART model used on LEON3 and LEON4 systems has support for receiver and transmitter FIFO mode also. In this mode the additional FIFO flags and level interrupts are also modelled like the APBUART IP. FIFO mode is enabled by setting the FIFO depth to a larger value than 1 with the `-fast_fs` switch. FIFO mode is supported with both accurate and fast mode. However in fast mode the transmitter operates in infinite speed always causing the FIFO to be empty.

Loopback mode is supported both in fast and accurate mode. In fast mode transmitted characters directly ends up in the receiver. Similar to the hardware the CTSN/RTSN signals are connected together in loop back mode making flow control possible regardless of operating mode.

Flow control bit is supported but has a different effect compared to hardware when loopback mode is disabled. TSIM UARTs interfaces to user controlled devices (see `-uartX`) which may/may not implement flow control in different ways. When flow control is enabled APBUART receiver never overflows, however the transmitter operates independently of the flow control setting as if CTSN is always 0 by pausing the simulator until the character is transferred to the UART device.

##### 4.1.2.2. UART model (ERC32/LEON2 only)

The UART model of ERC32/LEON2 automatically switch to fast mode when the scaler baud rate register is set to zero. This is different from the APBUART model where only the `-fast_uart` switch is used to determine the mode.

#### 4.1.3. Floating point unit (FPU)

The simulator maps floating-point operations on the hosts floating point capabilities. This means that accuracy and generation of IEEE exceptions is sometimes host dependent and will not always be identical to the actual ERC32/LEON hardware. For GRFPU we have seen no discrepancies for any calculations or IEEE exceptions on



any host. On Windows and Linux hosts, the only known discrepancies for calculations or IEEE exceptions for the Meiko on LEON2 and GRFPU-lite are that NaN:s can differ in significand bits. No discrepancies has been seen in the signalling/quiet bit.

The models for the ERC32 FPU, GRFPU-lite and GRFPU models supports parallel IU and FPU execution, deferred floating point traps and the floating point deferred trap queue. The GRFPU model does not however simulate the possibility of multiple outstanding floating point operations. The model for the Meiko FPU on LEON2 models the FPU setup for AT697E and AT7913E with no parallel IU and FPU execution, no floating point queue and no deferred floating point traps.

The simulator implements (to some extent) data-dependent execution timing for the ERC32 FPU, the Meiko FPU and GRFPU-lite. The complex timing of the GRFPU is not modelled in detail.

#### 4.1.4. Delayed write to special registers

The SPARC architecture defines that a write to the special registers (%psr, %wim, %tbr, %fsr, %y) may have up to 3 delay cycles, meaning that up to 3 of the instructions following a special register write might not 'see' the newly written value due to pipeline effects. While ERC32 and LEON have between 2 and 3 delay cycles, TSIM has 0. This does not affect simulation accuracy or timing as long as the SPARC ABI recommendations are followed that each special register write must always be followed by three NOP. If the three NOP are left out, the software might fail on real hardware while still executing 'correctly' on the simulator.

#### 4.1.5. Idle-loop optimisation

To minimise power consumption, LEON and ERC32 applications will typically place the processor in power-down mode when the idle task is scheduled in the operation system. In power-down mode, TSIM increments the event queue without executing any instructions, thereby significantly improving simulation performance. However, some (poorly written) code might use a busy loop (BA 0) instead of triggering power-down mode. The `-bopt` switch will enable a detection mechanism which will identify such behaviour and optimise the simulation as if the power-down mode was entered.

#### 4.1.6. Custom instruction emulation

TSIM/LEON allows the emulation of custom (non-SPARC) instructions. A handler for non-standard instruction can be installed using the `tsim_ext_ins()` callback function (see Section 6.2). The function handler is called each time an instruction is encountered that would cause an unimplemented instruction trap. The handler is passed the opcode and all processor registers in a pointer, allowing it to decode and emulate a custom instruction, and update the processor state.

The definition for the custom instruction handler is:

```
int myhandler (struct ins_interface *r);
```

The pointer `*r` is a structure containing the current instruction opcode and processor state:

```
struct ins_interface {
    uint32    psr;    /* Processor status registers */
    uint32    tbr;    /* Trap base register */
    uint32    wim;    /* Window maks register */
    uint32    g[8];   /* Global registers */
    uint32    r[128]; /* Windowed register file */
    uint32    y;      /* Y register */
    uint32    pc;     /* Program counter */
    uint32    npc;    /* Next program counter */
    uint32    inst;   /* Current instruction */
    uint32    icnt;   /* Clock cycles in curr inst */
    uint32    asr17;
    uint32    asr18;
};
```

SPARC uses an overlapping windowed register file, and accessing registers must be done using the current window pointer (%psr[4:0]). To access registers %r8 - %r31 in the current window, use:

```
cwp = r->psr & 7;
regval = r->r[((cwp << 4) + RS1) % (nwindows * 16)];
```

Note that global registers (%r0 - %r7) should always be accessed by `r->g[RS1]`.

The return value of the custom handler indicates which trap the emulated instruction has generated, or 0 if no trap was caused. If the handler could not decode the instruction, 2 should be returned to cause an unimplemented instruction trap.

The number of clocks consumed by the instruction should be returned in `r->icnt`; This value is by default 1, which corresponds to a fully pipelined instruction without data interlock. The handler should not increment the %pc or %npc registers, as this is done by TSIM.

#### 4.1.7. Chip-specific errata

Incorrect behavior described in errata documents for specific devices are not emulated by TSIM in general.

## 4.2. ERC32 specific emulation

### 4.2.1. Processor emulation

TSIM/ERC32 emulates the behaviour of the TSC695 processor from Atmel by default. The parallel execution between the IU and FPU is modelled, as well as stalls due to operand dependencies (IU & FPU). Starting TSIM with the `-tsc691` will enable TSC691 emulation (3-chip ERC32).

### 4.2.2. MEC emulation

The following table outlines the implemented MEC registers:

*Table 4.1. Implemented MEC registers*

Register	Address	Status
MEC control register	0x01f80000	implemented
Software reset register	0x01f80004	implemented
Power-down register	0x01f80008	implemented
Memory configuration register	0x01f80010	partly implemented
IO configuration register	0x01f80014	implemented
Waitstate configuration register	0x01f80018	implemented
Access protection base register 1	0x01f80020	implemented
Access protection end register 1	0x01f80024	implemented
Access protection base register 2	0x01f80028	implemented
Access protection end register 2	0x01f8002c	implemented
Interrupt shape register	0x01f80044	implemented
Interrupt pending register	0x01f80048	implemented
Interrupt mask register	0x01f8004c	implemented
Interrupt clear register	0x01f80050	implemented
Interrupt force register	0x01f80054	implemented
Watchdog acknowledge register	0x01f80060	implemented
Watchdog trap door register	0x01f80064	implemented
RTC counter register	0x01f80080	implemented
RTC counter program register	0x01f80080	implemented
RTC scaler register	0x01f80084	implemented

Register	Address	Status
RTC scaler program register	0x01f80084	implemented
GPT counter register	0x01f80088	implemented
GPT counter program register	0x01f80088	implemented
GPT scaler register	0x01f8008c	implemented
GPT scaler program register	0x01f8008c	implemented
Timer control register	0x01f80098	implemented
System fault status register	0x01f800A0	implemented
First failing address register	0x01f800A4	implemented
GPI configuration register	0x01f800A8	I/O module callback
GPI data register	0x01f800AC	I/O module callback
Error and reset status register	0x01f800B0	implemented
Test control register	0x01f800D0	implemented
UART A RX/TX register	0x01f800E0	implemented
UART B RX/TX register	0x01f800E4	implemented
UART status register	0x01f800E8	implemented

The MEC registers can be displayed with the **mec** command, or using **mem** ('mem 0x1f80000 256'). The registers can also be written using **wmem** (e.g. 'wmem 0x1f80000 0x1234'). When written, care has to be taken not to write an unimplemented register bit with '1', or a MEC parity error will occur.

### 4.2.3. Interrupt controller

Internal interrupts are generated as defined in the MEC specification. All 15 interrupts can be tested via the interrupt force register. External interrupts can be generated through loadable modules.

### 4.2.4. Watchdog

The watchdog timer operate as defined in the MEC specification. The frequency of the watchdog clock can be specified using the `-wdfreq` switch. The frequency is specified in MHz.

### 4.2.5. Power-down mode

The power-down register (0x01f80008) is implemented as in the specification. A Ctrl-C in the simulator window will exit the power-down mode. In power-down mode, the simulator skips time until the next event in the event queue, thereby significantly increasing the simulation speed.

### 4.2.6. Memory emulation

The amount of simulated memory is configured through the `-ram` and `-rom` switches. The RAM size can be between 256 KiB and 32 MiB, the ROM size between 128 KiB and 4 MiB. Access to unimplemented MEC registers or non-existing memory will result in a memory exception trap.

The memory configuration register is used to decode the simulated memory. The fields RSIZ and PSIZ are used to set RAM and ROM size, the remaining fields are not used.

NOTE: After reset, the MEC is set to decode 128 KiB of ROM and 256 KiB of RAM. The memory configuration register has to be updated to reflect the available memory. The waitstate configuration register is used to generate waitstates. This register must also be updated with the correct configuration after reset.

### 4.2.7. EDAC operation

The EDAC operation of ERC32 is implemented on the simulated RAM area (0x2000000 - 0x2FFFFFFF). The ERC32 Test Control Register can be used to enable the EDAC test mode and insert EDAC errors to test the

operation of the EDAC. The **edac** command can be used to monitor the number of errors in the memory, to insert new errors, or clear all errors. To see the current memory status, use the **edac** command without parameters:

```
tsim> edac
RAM error count : 2
0x20000000 : MERR
0x20000040 : CERR
```

TSIM keeps track of the number of errors currently present, and reports the total error count, the address of each error, and its type. The errors can either be correctable (CERR) or non-correctable (MERR). To insert an error using the **edac** command, do `'edac cerr addr'` or `'edac merr addr'` :

```
tsim> edac cerr 0x20000000
correctable error at 0x02000000
tsim> edac
RAM error count : 1
0x20000000 : CERR
```

To remove all injected errors, do **edac clear**. When accessing a location with an EDAC error, the behaviour of TSIM is identical to the real hardware. A correctable error will trigger interrupt 1, while un-correctable errors will cause a memory exception. The operation of the FSFR and FAR registers are fully implemented.

NOTE: The EDAC operation affect simulator performance when there are inserted errors in the memory. To obtain maximum simulation performance, any diagnostic software should remove all inserted errors after having performed an EDAC test.

#### 4.2.8. Extended RAM and I/O areas

TSIM allows emulation of user defined I/O devices through loadable modules. EDAC emulation of extended RAM areas is not supported.

#### 4.2.9. SYSAV signal

TSIM emulates changes in the SYSAV output by calling the `command()` callback in the I/O module with either "sysav 0" or "sysav 1" on each changes of SYSAV.

#### 4.2.10. EXTINTACK signal

TSIM emulates assertion of the EXTINTACK output by calling the `command()` callback in the I/O module with "extintack" on each assertion. Note that EXTINTACK is only asserted for one external interrupt as programmed in the MEC interrupt shape register.

#### 4.2.11. IWDE signal

The TSC695E processor input signal can be controlled by the `-iwde` switch at start-up. If the switch is given, the IWDE signal will be high, and the internal watchdog enabled. If `-iwde` is not given, IWDE will be low and the internal watchdog will be disabled. Note that the simulator must started in TSC695E-mode using the `-tsc695e` switch, for this option to take effect.

### 4.3. LEON2 specific emulation

#### 4.3.1. Processor

The LEON2 version of TSIM emulates the behavior of the LEON2 VHDL model. The (optional) MMU can be emulated using the `-mmu` switch.

#### 4.3.2. Cache memories

TSIM/LEON2 can emulate any permissible cache configuration using the `-icsize`, `-ilsize`, `-dcsize` and `-dlsize` options. Allowed sizes are 1 - 64 KiB with 16 - 32 bytes/line. The characteristics of the LEON multi-set caches can be emulated using the `-isets`, `-dsets`, `-irepl`, `-drelp`, `-ilock` and `-dlock` options. Diagnostic cache reads/writes are implemented. The simulator commands **icache** and **dcache** can be used to display cache contents. Starting TSIM with `-at697e` will configure that caches according to the Atmel AT697E device.

### 4.3.3. LEON peripherals registers

The LEON peripherals registers can be displayed with the **leon** command, or using **mem** ('mem 0x80000000 256'). The registers can also be written using **wmem** (e.g. 'wmem 0x80000000 0x1234').

### 4.3.4. Interrupt controller

External interrupts are not implemented, so the I/O port interrupt register has no function. Internal interrupts are generated as defined in the LEON specification. All 15 interrupts can also be generated from the user defined I/O module using the `set_irq()` callback.

### 4.3.5. Power-down mode

The power-down register (0x80000018) is implemented as in the specification. A Ctrl-C in the simulator window will exit the power-down mode. In power-down mode, the simulator skips time until the next event in the event queue, thereby significantly increasing the simulation speed.

### 4.3.6. Memory emulation

The memory configuration registers 1/2 are used to decode the simulated memory. The memory configuration registers has to be programmed by software to reflect the available memory, and the number and size of the memory banks. The waitstates fields must also be programmed with the correct configuration after reset. Both SRAM and functionally modelled SDRAM (with SRAM timing) can be emulated.

Using the `-banks` option, it is possible to set over how many RAM banks the external SRAM is divided in. For `mkprom` encapsulated programs, it is essential that the *same* RAM size and bank number setting is used for both `mkprom` and `TSIM`.

The memory EDAC of LEON2-FT is not implemented.

### 4.3.7. SPARC V8 MUL/DIV/MAC instructions

TSIM/LEON optionally supports the SPARC V8 multiply, divide and MAC instruction. To correctly emulate LEON systems which do not implement these instructions, use the `-nomac` to disable the MAC instruction and/or `-nov8` to disable multiply and divide instructions.

### 4.3.8. FPU emulation

By default, TSIM/LEON emulates the Meiko FPU. The `-grfpu` command line option enables the GRFPU model. See Section 4.1.3 for details on the FPU models.

### 4.3.9. DSU and hardware breakpoints

The LEON debug support unit (DSU) and the hardware watchpoints (%asr24 - %asr31) are not emulated.

## 4.4. LEON3 specific emulation

### 4.4.1. General

The LEON3 version of TSIM emulates the behavior of the LEON3MP template VHDL model distributed in the GRLIB-1.0 IP library. The system includes the following modules: LEON3 processor, APB bridge, IRQMP interrupt controller, LEON2 memory controller, GPTIMER timer unit with two 32-bit timers, two APBUART uarts (unless a chip option changes this number). The AHB/APB plug&play information is provided at address 0xFFFFF000 - 0xFFFFFFFF (AHB) and 0x800FF000 - 0x800FFFFF (APB).

### 4.4.2. Processor

The instruction timing of the emulated LEON3 processor is modelled after LEON3 VHDL model in GRLIB IP library. The processor can be configured with 2 - 32 register windows using the `-nwin` switch. The MMU can be emulated using the `-mmu` switch. Local scratch pad RAM can be added with the `-ilram` and `-dlram` switches.

#### 4.4.3. Cache memories

The evaluation version of TSIM/LEON3 implements 2\*4 KiB caches, with 16 bytes per line. The commercial TSIM version can emulate any permissible cache configuration using the `-icsize`, `-ilsize`, `-dcsize` and `-dlsize` options. Allowed sizes are 1 - 256 KiB with 16 - 32 bytes/line. The characteristics of the LEON multi-way caches can be emulated using the `-isets`, `-dsets`, `-irepl`, `-drepl`, `-ilock` and `-dlock` options. Diagnostic cache reads/writes are implemented. The simulator commands **icache** and **dcache** can be used to display cache contents.

#### 4.4.4. Power-down mode

The LEON3 power-down function is implemented as in the specification. A Ctrl-C in the simulator window will exit the power-down mode. In power-down mode, the simulator skips time until the next event in the event queue, thereby significantly increasing the simulation speed.

#### 4.4.5. LEON3 peripherals registers

The LEON3 peripherals registers can be displayed with the **leon** command, or using **mem** ('mem 0x80000000 256'). The registers can also be written using **wmem** (e.g. 'wmem 0x80000000 0x1234').

#### 4.4.6. Interrupt controller

The IRQMP interrupt controller is fully emulated as described in the GRLIB IP Manual. The IRQMP registers are mapped at address 0x80000200. All 15 interrupts can also be generated from the user-defined I/O module using the `set_irq()` callback. When having extended interrupts enabled, all 31 interrupts can be generated. Extended interrupts can be enabled by the `-ext` option or a chip option for a chip that has extended interrupts (e.g. `-gr712rc`, `-ut700` and `-ut699e`).

#### 4.4.7. Memory emulation

The LEON2 memory controller is emulated in the LEON3 version of TSIM. The memory configuration registers 1/2 are used to decode the simulated memory. The memory configuration registers has to be programmed by software to reflect the available memory, and the number and size of the memory banks. The waitstates fields must also be programmed with the correct configuration after reset. Both SRAM and functionally modelled SDRAM (with SRAM timing) can be emulated.

Using the `-banks` option, it is possible to set over how many RAM banks the external SRAM is divided in. For mkprom encapsulated programs, it is essential that the *same* RAM size and bank number setting is used for both mkprom and TSIM.

The memory EDAC of LEON3-FT is not implemented.

Options regarding memory characteristics are not available in the evaluation version of TSIM/LEON3.

#### 4.4.8. CASA instruction

The SPARCV9 "casa" command is implemented if the `-cas` switch is given. The "casa" instruction is used in VXWORKS SMP multiprocessing to synchronize using a lock free protocol.

#### 4.4.9. SPARC V8 MUL/DIV/MAC instructions

TSIM/LEON3 optionally supports the SPARC V8 multiply, divide and MAC instruction. To correctly emulate LEON systems which do not implement these instructions, use the `-nomac` to disable the MAC instruction and/or `-nov8` to disable multiply and divide instructions.

#### 4.4.10. FPU emulation

By default, TSIM/LEON3 emulates the GRFPU-lite FPU. The `-grfpu` command line option enables the GRFPU model. See Section 4.1.3 for details on the FPU models.

#### 4.4.11. DSU and hardware breakpoints

The LEON debug support unit (DSU) and the hardware watchpoints (%asr24 - %asr31) are not emulated.

#### 4.4.12. AHB status registers

When using `-ahbstatus` or a chip option for a chip that has AHB status registers, AHB status registers are enabled. As TSIM/LEON3 does not emulate FT, the CE bit will never be set. Furthermore, the HMASTER field is set to 0 when the CPU caused the error and 1 when any other master caused the error.

#### 4.4.13. GRTIMER emulation

When using `-gr712rc`, the GRTIMER core is modelled (in addition to the regular GPTIMER core).

### 4.5. LEON4 specific emulation

#### 4.5.1. General

The LEON4 version of TSIM emulates the behavior of the LEON4MP template VHDL model distributed in the GRLIB-1.0.x IP library. The system includes the following modules: LEON4 processor, APB bridge, IRQMP interrupt controller, LEON2 memory controller, L2 cache, GPTIMER timer unit with two 32-bit timers, two AP-BUART uarts. The AHB/APB plug&play information is provided at address 0xFFFFF000 - 0xFFFFFFFF (AHB) and 0x800FF000 - 0x800FFFFF (APB).

#### 4.5.2. Processor

The instruction timing of the emulated LEON4 processor is modelled after LEON4 VHDL model in GRLIB IP library. The processor can be configured with 2 - 32 register windows using the `-nwin` switch. The MMU can be emulated using the `-mmu` switch. Local scratch pad RAM can be added with the `-ilram` and `-dlram` switches.

#### 4.5.3. L1 Cache memories

TSIM/LEON4 can emulate any permissible cache configuration using the `-icsize`, `-ilsize`, `-dcsize` and `-dlsize` options. Allowed sizes are 1 - 256 KiB with 16 - 32 bytes/line. The characteristics of the LEON multi-set caches can be emulated using the `-isets`, `-dsets`, `-irepl`, `-drepl`, `-ilock` and `-dlock` options. Diagnostic cache reads/writes are implemented. The simulator commands **icache** and **dcache** can be used to display cache contents.

#### 4.5.4. L2 Cache memory

The LEON4 L2 cache is emulated, and placed between the memory controller and AHB bus. Both the PROM and SRAM/SDRAM areas are cached in the L2. The size of the L2 cache is default 64 KiB, but can be configured to any (binary aligned) size using the `-l2wsize` switch at start-up. Setting the size to 0 will disable the L2 cache. The L2 cache is implemented with one way and 32 bytes/line. The contents of the L2 cache can be displayed with the **l2cache** command.

#### 4.5.5. Power-down mode

The LEON4 power-down function is implemented as in the specification. A Ctrl-C in the simulator window will exit the power-down mode. In power-down mode, the simulator skips time until the next event in the event queue, thereby significantly increasing the simulation speed.

#### 4.5.6. LEON4 peripherals registers

The LEON4 peripherals registers can be displayed with the **leon** command, or using **mem** ('mem 0x80000000 256'). The registers can also be written using **wmem** (e.g. 'wmem 0x80000000 0x1234').

#### 4.5.7. Interrupt controller

The IRQMP interrupt controller is fully emulated as described in the GRLIB IP Manual. The IRQMP registers are mapped at address 0x80000200. All 15 interrupts can also be generated from the user-defined I/O module using

the `set_irq()` callback. When having extended interrupts enabled, all 31 interrupts can be generated. Extended interrupts can be enabled by the `-ext` option.

#### 4.5.8. Memory emulation

The LEON2 memory controller is emulated in the LEON4 version of TSIM. The memory configuration registers 1/2 are used to decode the simulated memory. The memory configuration registers has to be programmed by software to reflect the available memory, and the number and size of the memory banks. The waitstates fields must also be programmed with the correct configuration after reset. Both SRAM and functionally modelled SDRAM (with SRAM timing) can be emulated.

Using the `-banks` option, it is possible to set over how many RAM banks the external SRAM is divided in. For mkprom encapsulated programs, it is essential that the *same* RAM size and bank number setting is used for both mkprom and TSIM.

The memory EDAC of LEON4-FT is not implemented.

#### 4.5.9. CASA instruction

The SPARCV9 “casa” command is implemented if the `-cas` switch is given. The “casa” instruction is used in VXWORKS SMP multiprocessing to synchronize using a lock free protocol.

#### 4.5.10. SPARC V8 MUL/DIV/MAC instructions

TSIM/LEON4 optionally supports the SPARC V8 multiply, divide and MAC instruction. To correctly emulate LEON systems which do not implement these instructions, use the `-nomac` to disable the MAC instruction and/or `-nov8` to disable multiply and divide instructions.

#### 4.5.11. FPU emulation

By default, TSIM/LEON4 emulates the GRFPU FPU. See Section 4.1.3 for details on the FPU models.

#### 4.5.12. DSU and hardware breakpoints

The LEON debug support unit (DSU) and the hardware watchpoints (`%asr24 - %asr31`) are not emulated.

#### 4.5.13. AHB status registers

When using `-ahbstatus`, AHB status registers are enabled. As TSIM/LEON4 does not emulate FT, the CE bit will never be set. Furthermore, the HMASTER field is set to 0 when the CPU caused the error and 1 when any other master caused the error.



## 5. Loadable modules

### 5.1. TSIM I/O emulation interface

User-defined I/O devices can be loaded into the simulator through the use of loadable modules. As the real processor, the simulator primarily interacts with the emulated device through read and write requests, while the emulated device can optionally generate interrupts and DMA requests. This is implemented through the module interface described below. The interface is made up of two parts; one that is exported by TSIM and defines TSIM functions and data structures that can be used by the I/O device; and one that is exported by the I/O device and allows TSIM to access the I/O device. Address decoding of the I/O devices is straight-forward: All access that do not map on any AHB module (LEON only) or the internally emulated memory and control registers are forwarded to the I/O module.

TSIM exports two structures: `simif` and `ioif`. The `simif` structure defines functions and data structures belonging to the simulator core, while `ioif` defines functions provided by system (ERC32/LEON) emulation. At startup, TSIM searches for 'io.so' in the current directory, but the location of the module can be specified using the `-iom` switch. Note that the module must be compiled to be position-independent, i.e. with the `-fPIC` switch (`gcc`). The win32 version of TSIM loads `io.dll` instead of `io.so`. See the `iomod` directory in the TSIM distribution for an example `io.c` and how to build the `.so` and `.dll` modules. The environmental variable `TSIM_MODULE_PATH` can be set to a ':' separated (':' in WIN32) list of search paths.

#### 5.1.1. simif structure

The `simif` structure is defined in `tsim.h`:

```

struct sim_options {
    uint32 phys_ram;
    uint32 phys_rom;
    float64 freq;
    float64 wdfreq;
    uint32 phys_sdram;
};

struct sim_interface {
    struct sim_options *options;      /* tsim command-line options */
    uint64 *simtime;                 /* current simulator time */
    void (*event)(void (*cfunc)(), uint32 arg, uint64 offset);
    void (*stop_event)(void (*cfunc)());
    int *irl;                        /* interrupt request level */
    void (*sys_reset)();             /* reset processor */
    void (*sim_stop)();              /* stop simulation */
    char *args;                      /* concatenated argv */
    void (*stop_event_arg)(void (*cfunc)(), int arg, int op);

    /* Restorable events */
    unsigned short (*reg_revent)(void (*cfunc) (unsigned long arg));
    unsigned short (*reg_revent_prearg)(void (*cfunc) (unsigned long arg),
                                        unsigned long arg);
    int (*revent)(unsigned short index, unsigned long arg, uint64 offset);
    int (*revent_prearg)(unsigned short index, uint64 offset);
    void (*stop_revent)(unsigned short index);
    int (*lprintf)(const char *format, ...); /* logged formatted output */
    int (*vfprintf)(const char *format, va_list ap); /* logged formatted output */
};

struct sim_interface simif;          /* exported simulator functions */

```

The elements in the structure has the following meaning:

```
struct sim_options *options;
```

Contains some tsim startup options. `options.freq` defines the clock frequency of the emulated processor and can be used to correlate the simulator time to the real time.

```
uint64 *simtime;
```

Contains the current simulator time. Time is counted in clock cycles since start of simulation. To calculate the elapsed real time, divide `simtime` with `options.freq`.

```
void (*event)(void (*cfunc)(), int arg, uint64 offset);
```

TSIM maintains an event queue to emulate time-dependent functions. The `event()` function inserts an event in the event queue. An event consists of a function to be called when the event expires, an argument with which the function is called, and an offset (relative the current time) defining when the event should expire.

NOTE: The `event()` function may NOT be called from a signal handler installed by the I/O module, but only from event callbacks or at start of simulation. The event queue can hold a maximum of 2048 events.

NOTE: For save and restore support, restorable events should be used instead.

```
void (*stop_event)(void (*cfunc)());
stop_event() will remove all events from the event queue which has the calling function equal to cfunc().
```

NOTE: The `stop_event()` function may NOT be called from a signal handler installed by the I/O module.

```
int *irl;
Current IU interrupt level. Should not be used by I/O functions unless they explicitly monitor these lines.
```

```
void (*sys_reset)();
Performs a system reset. Should only be used if the I/O device is capable of driving the reset input.
```

```
void (*sim_stop)();
Stops current simulation. Can be used for debugging purposes if manual intervention is needed after a certain event.
```

```
char *args;
Arguments supplied when starting tsim. The arguments are concatenated as a single string.
```

```
void (*stop_event_arg)(void (*cfunc)(), int arg, int op);
Similar to stop_event() but differentiates between 2 events with same cfunc but with different arg given when inserted into the event queue via event(). Used when simulating multiple instances of an entity. Parameter op should be 1 to enable the arg check.
```

```
unsigned short (*reg_revent)(void (*cfunc) (unsigned long arg));
Registers a restorable event that will use cfunc as callback. The returned index should be used when calling revent(). The event argument is supplied when calling revent(). The call to reg_revent() should be done once at I/O or AHB module initialization.
```

```
unsigned short (*reg_revent_prearg)(void (*cfunc) (unsigned long arg), unsigned long arg);
Registers a restorable event that will use cfunc as callback and arg as argument. This can be used to register an argument that is a pointer to a data structure. The returned index should be used when calling revent_prearg(). The call to reg_revent_prearg() should be done once at I/O or AHB module initialization.
```

```
int (*revent)(unsigned short index, unsigned long arg, uint64 offset);
This inserts an event registered by reg_revent() into the event queue with the registered cfunc for the given index. Multiple events with the same index can be in the event queue at the same time. The arg and offset arguments are the same as for the event() function.
```

NOTE: See the description of `event()` for limitations on number of events and from which contexts events can be added.

```
int (*revent_prearg)(unsigned short index, uint64 offset);
This inserts an event registered by reg_revent_prearg() into the event queue with the registered cfunc and arg for the given index. Multiple events with the same index can be in the event queue at the same time. The offset argument is the same as for the event() function.
```

NOTE: See the description of `event()` for limitations on number of events and from which contexts events can be added.

```
void (*stop_revent)(unsigned short index);
This removes all events from the event queue that has been entered by revent() or revent_prearg() using the given index.
```

NOTE: The `stop_revent()` function may *not* be called from a signal handler installed by the I/O module.

```
int (*lprintf)(const char *format, ...)
Function for logged formatted output. The function interface works like for printf.
```

```
int (*vlprintf)(const char *format, va_list ap)
Function for logged formatted output. The function interface works like for vprintf.
```

### 5.1.2. ioif structure

ioif is defined in tsim.h:

```
struct io_interface {
    void (*set_irq)(int irq, int level);
    int (*dma_read)(uint32 addr, uint32 *data, int num);
    int (*dma_write)(uint32 addr, uint32 *data, int num);
    int (*dma_write_sub)(uint32 addr, uint32 *data, int sz);
};
extern struct io_interface ioif; /* exported processor interface */
```

The elements of the structure have the following meaning:

```
void (*set_irq)(int irq, int level);
```

ERC32 use: drive the external MEC interrupt signal. Valid interrupts are 0 - 5 (corresponding to MEC external interrupt 0 - 4, and EWDINT) and valid levels are 0 or 1. Note that the MEC interrupt shape register controls how and when processor interrupts are actually generated. When `-nouart` has been used, MEC interrupts 4, 5 and 7 can be generated by calling `set_irq()` with irq 6, 7 and 9 (level is not used in this case).

LEON use: set the interrupt pending bit for interrupt irq. Valid values on irq is 1 - 15 for systems without extended interrupts and 1-31 for systems with extended interrupts. Care should be taken not to set interrupts used by the LEON emulated peripherals. Note that the LEON interrupt control register controls how and when processor interrupts are actually generated. Note that the level parameter is not used for LEON.

```
int (*dma_read)(uint32 addr, uint32 *data, int num);
```

```
int (*dma_write)(uint32 addr, uint32 *data, int num);
```

Performs DMA transactions to/from the emulated processor memory. Only 32-bit word transfers are allowed, and the address must be word aligned. On bus error, 1 is returned, otherwise 0. For ERC32, the DMA transfer uses the external DMA interface. For LEON, DMA takes place on the AMBA AHB bus.

```
int (*dma_write_sub)(uint32 addr, uint32 *data, int sz);
```

Performs DMA transactions to/from the emulated processor memory on the AMBA AHB bus. Available for LEON only. On bus error, 1 is returned, otherwise 0. Write size is indicated by `sz` as follows: 0 = byte, 1 = half-word, 2 = word, 3 = double-word.

### 5.1.3. Structure to be provided by I/O device

```
struct io_subsystem {
    void (*io_init)(struct sim_interface sif, struct io_interface iif); /* start-up */
    void (*io_exit()); /* called once on exit */
    void (*io_reset()); /* called on processor reset */
    void (*io_restart()); /* called on simulator restart */
    int (*io_read)(unsigned int addr, int *data, int *ws);
    int (*io_write)(unsigned int addr, int *data, int *ws, int size);
    char *(*get_io_ptr)(unsigned int addr, int size);
    void (*command)(char * cmd); /* I/O specific commands */
    void (*sigio()); /* Not used */
    void (*save)(char *fname); /* save simulation state */
    void (*restore)(char *fname); /* restore simulation state */
};
extern struct io_subsystem *iosystem; /* imported I/O emulation functions */
```

The elements of the structure have the following meanings:

```
void (*io_init)(struct sim_interface sif, struct io_interface iif);
```

Called once on simulator startup. Set to NULL if unused.

```
void (*io_exit());
```

Called once on simulator exit. Set to NULL if unused.

```
void (*io_reset());
```

Called every time the processor is reset (i.e also startup). Set to NULL if unused.

```
void (*io_restart());
```

Called every time the simulator is restarted (simtime set to zero). Set to NULL if unused.

```
int (*io_read)(unsigned int addr, int *data, int *ws);
```

Processor read call. The processor always reads one full 32-bit word from `addr`. The data should be returned in `*data`, the number of waitstates should be returned in `*ws`. If the access would fail (illegal address etc.), 1 should be returned, on success 0.

```
int (*io_write)(unsigned int addr, int *data, int *ws, int size);
```

Processor write call. The size of the written data is indicated in size: 0 = byte, 1 = half-word, 2 = word, 3 = doubleword. The address is provided in addr, and is always aligned with respect to the size of the written data. The number of waitstates should be returned in \*ws. If the access would fail (illegal address etc.), 1 should be returned, on success 0.

```
char * (*get_io_ptr)(unsigned int addr, int size);
```

TSIM can access emulated memory in the I/O device in two ways: either through the io\_read/io\_write functions or directly through a memory pointer. get\_io\_ptr() is called with the target address and transfer size (in bytes), and should return a character pointer to the emulated memory array if the address and size is within the range of the emulated memory. If outside the range, -1 should be returned. Set to NULL if not used.

```
int (*command)(char * cmd);
```

The I/O module can optionally receive command-line commands. A command is first sent to the AHB and I/O modules, and if not recognised, the to TSIM. command() is called with the full command string in \*cmd. Should return 1 if the command is recognized, otherwise 0. TSIM/ERC32 also calls this callback when the SYSAV bit in the ERSR register changes. The commands “sysav 0” and “sysav 1” are then issued. When TSIM commands are issued through the gdb ‘monitor’ command, a return value of 0 or 1 will result in an ‘OK’ response to the gdb command. A return value > 1 will send the value itself as the gdb response. A return value < 1 will truncate the lsb 8 bits and send them back as a gdb error response: ‘Errn’.

```
void (*sigio)();
```

Not used as of tsim-1.2, kept for compatibility reasons.

```
void (*save)(char *fname);
```

The save() function is called when save command is issued in the simulator. The I/O module should save any required state which is needed to completely restore the state at a later stage. \*fname points to the base file name which is used by TSIM. TSIM saves its internal state to fname.tss. It is suggested that the I/O module save its state to fname.ios. Note that any events placed in the event queue by the I/O module will be saved (and restored) by TSIM.

```
void (*restore)(char *fname);
```

The restore() function is called when restore command is issued in the simulator. The I/O module should restore any required state to resume operation from a saved check-point. \*fname points to the base file name which is used by TSIM. TSIM restores its internal state from fname.tss.

#### 5.1.4. Cygwin specific io\_init()

Due to problems of resolving cross-referenced symbols in the module loading when using Cygwin, the io\_init() routine in the I/O module must initialise a local copy of simif and ioif. This is done by providing the following io\_init() routine:

```
static void io_init(struct sim_interface sif, struct io_interface iif)
{
#ifdef __CYGWIN32__
    /* Do not remove, needed when compiling on Cygwin! */
    simif = sif;
    ioif = iif;
#endif
    /* additional init code goes here */
};
```

The same method is also used in the AHB and FPU/CP modules.

## 5.2. LEON AHB emulation interface

In addition to the above described I/O modules, TSIM also allows loading AHB modules that can add simulation models, override built-in simulation models, and even emulating the LEON2/3/4 processor core with a completely user-defined memory and I/O architecture. This is not applicable to ERC32. The emulated processor core communicates with an AHB module using an interface similar to the AHB master interface in the real LEON VHDL model. A single AHB module have the possibility to emulate the complete AHB bus and all attached units, or to just emulate some cores on the AHB or APB bus. An AHB module that emulates memory can disable the internal memory emulation.

TSIM supports up to 16 AHB modules, loaded using multiple `-ahbm` options on TSIM startup. The order they are specified corresponds to the precedence order in which the modules handles bus accesses. For each bus access, one module at a time, in the same order as the `-ahbm` options, gets the chance to handle an access or to let it get passed to the next module. If an access is unhandled by all AHB modules, core TSIM will handle the access, or if applicable pass it on to an I/O module.

The AHB module interface is made up of two parts; one that is exported by TSIM and defines TSIM functions and data structures that can be used by the AHB module; and one that is exported by the AHB module and allows TSIM to access the emulated AHB devices.

At start-up, TSIM searches for `'ahb.so'` in the current directory, but the location of the module can be specified using the `-ahbm` switch. Note that the module must be compiled to be position-independent, i.e. with the `-fPIC` switch (gcc). The win32 version of TSIM loads `ahb.dll` instead of `ahb.so`. See the `iomod` directory in the TSIM distribution for an example `ahb.c` and how to build the `.so` / `.dll` modules. The environmental variable `TSIM_MODULE_PATH` can be set to a `':'` separated (`;` in WIN32) list of search paths.

### 5.2.1. procif structure

TSIM exports one structure for AHB emulation: `procif`. The `procif` structure defines a few functions giving access to the processor emulation and cache behaviour. The `procif` structure is defined in `tsim.h`:

```
struct proc_interface {
    void (*set_irl)(int level); /* generate external interrupt */
    void (*cache_snoop)(uint32 addr);
    void (*cctrl)(uint32 *data, uint32 read);
    void (*power_down)();
    void (*set_irq_level)(int level, int set);
    void (*set_irq)(uint32 irq, uint32 level); /* generate external interrupt */
};
extern struct proc_interface procif;
```

The elements in the structure have the following meaning:

```
void (*set_irl)(int level);
```

Set the current interrupt level (`iui.irl` in VHDL model). Allowed values are 0 - 15, with 0 meaning no pending interrupt. Once the interrupt level is set, it will remain until it is changed by a new call to `set_irl()`. The modules interrupt callback routine should typically reset the interrupt level to avoid new interrupts.

```
void (*cache_snoop)(uint32 addr);
```

The `cache_snoop()` function can be used to invalidate data cache lines (regardless of whether data cache snooping is enabled or not). The tags to the given address will be checked, and if a match is detected the corresponding cache lines will be flushed (i.e. the tag will be cleared). If an MMU is present and is enabled the argument should be a virtual address. See also the `snoop` function in `struct ahb_interface`.

```
void (*cctrl)(uint32 *data, uint32 read);
```

Read and write the cache control register (CCR). The CCR is attached to the APB bus in the LEON2 VHDL model, and this function can be called by the AHB module to read and write the register. If `read = 1`, the CCR value is returned in `*data`, else the value of `*data` is written to the CCR. The `cctrl()` function is only needed for LEON2 emulation, since LEON3/4 accesses the cache controller through a separate ASI load/store instruction.

```
void (*power_down)();
```

The LEON processor enters power down-mode when called.

```
void (*set_irq_level)(int level, int set);
```

Callback `set_irq_level` can be used to emulate level triggered interrupts. Parameter `set` should be 1 to activate the interrupt level specified in parameter `level` or 0 to reset it. The interrupt level will remain active after it is set until it is reset again. Multiple calls can be made with different `level` parameters in which case the highest level is used.

```
void (*set_irq)(uint32 irq, uint32 level);
```

Set the interrupt pending bit for interrupt `irq`. Valid values on `irq` is 1 - 15. Care should be taken not to set interrupts used by the LEON emulated peripherals. Note that the LEON interrupt control register controls how and when processor interrupts are actually generated.

### 5.2.2. Structure to be provided by AHB module

`tsim.h` defines the structure to be provided by the emulated AHB module:

```

struct ahb_access {
    uint32 address;
    uint32 *data;
    uint32 ws;
    uint32 rnum;
    uint32 wsize;
    uint32 cache; /* No longer used */
};

struct pp_amba {
    int is_apb;
    unsigned int vendor, device, version, irq;
    struct {
        unsigned int addr, p, c, mask, type;
    } bars[4];
};

struct ahb_subsystem {
    void (*init)(struct proc_interface procif); /* called once on start-up */
    void (*exit)(); /* called once on exit */
    void (*reset)(); /* called on processor reset */
    void (*restart)(); /* called on simulator restart */
    int (*read)(struct ahb_access *access);
    int (*write)(struct ahb_access *access);
    char *(*get_io_ptr)(unsigned int addr, int size);
    int (*command)(char * cmd); /* I/O specific commands */
    int (*sigio)(); /* Not used */
    void (*save)(char * fname); /* save state */
    void (*restore)(char * fname); /* restore state */
    int (*intack)(int level); /* interrupt acknowledge */
    int (*plugandplay)(struct pp_amba **); /* LEON3/4: get plug & play information */
    void (*intpend)(unsigned int pend); /* LEON3/4 only: interrupt pending change */
    int meminit; /* tell tsim weather to initialize mem */
    struct sim_interface *simif; /* initialized by tsim */
    unsigned char *(*get_mem_ptr_ws)(); /* initialized if meminit was set */
    void (*snoop)(unsigned int addr); /* initialized with cache snoop routine */
    struct io_interface *io; /* initialized by tsim */
    void (*dprint)(char *p); /* initialized by tsim, prints out a debug string */
    struct proc_interface *proc; /* initialized by tsim, access to proc_interface */
    int (*cacheable)(uint32 addr, uint32 size); /* Cacheability of area */
    int (*lprintf)(const char *format, ...); /* initialized by tsim */
    int (*vfprintf)(const char *format, va_list ap); /* initialized by tsim */
    void (*start)(void); /* Called each time simulation starts (again) (run, go, cont) */
    void (*stop)(void); /* Called each time simulation stops, (Ctrl-C, breakpoints, etc.) */
    void (*correctable_error)(uint32 addr, uint32 master, uint32 size, int write);
};

extern struct ahb_subsystem *ahbssystem; /* imported AHB emulation functions */

```

The elements of the structure have the following meanings:

`void (*init)(struct proc_interface procif);`

Called once on simulator startup. Set to NULL if unused.

`void (*exit)();`

Called once on simulator exit. Set to NULL if unused.

`void (*reset)();`

Called every time the processor is reset (i.e. also startup). Set to NULL if unused.

`void (*restart)();`

Called every time the simulator is restarted (simtime set to zero). Set to NULL if unused.

`void int (*read)(struct ahb_access *ahbacc);`

Processor AHB read. The processor always reads one or more 32-bit words from the AHB bus. The following fields of *ahbacc* is used. The *ahbacc.addr* field contains the read address of the first word to read. The *ahbacc.data* field points to a buffer that the module can fill in. The module can also change the pointer to point to a different buffer. The *ahbacc.ws* field should be set by the module to the number of cycles for the complete access. The *ahbacc.rnum* field contains the number of words to be read. The function should return 0 for a successful access, 1 for failed access and -1 for an area not handled by the module. The *ahbacc.wsize* field is not used during read cycles. The *ahbacc.cache* field is no longer in use (use `struct ahb_subsystem.cacheable` instead).

`int (*write)(struct ahb_access *ahbacc);`

Processor AHB write. The processor can write 1, 2, 4 or 8 bytes per access. The following fields of *ahbacc* is used. The *ahbacc.addr* field contains the address of the write. The *ahbacc.data* field points to the data to write; either one word for byte, half word or word writes or two words for double-word writes. The

ahbacc.wsize field defines write size as follows: 0 = byte, 1 = half-word, 2 = word, 3 = double-word. The function should return 0 for a successful access, 1 for failed access and -1 for an area not handled by the module. The ahbacc.rnum field is not used during write cycles. The ahbacc.cache field is no longer in use (use struct ahb\_subsystem.cacheable instead).

```
char * (*get_io_ptr)(unsigned int addr, int size);
```

During file load operations and displaying of memory contents, TSIM will access emulated memory through a memory pointer. `get_io_ptr()` is called with the target address and transfer size (in bytes), and should return a character pointer to the emulated memory array if the address and size is within the range of the emulated memory. If outside the range, -1 should be returned. Set to NULL if not used.

```
int (*command)(char * cmd);
```

The AHB module can optionally receive command-line commands. A command is first sent to the AHB and I/O modules, and if not recognised, then to TSIM. `command()` is called with the full command string in `*cmd`. Should return 1 if the command is recognized, otherwise 0. When TSIM commands are issued through the gdb 'monitor' command, a return value of 0 or 1 will result in an 'OK' response to the gdb command. A return value > 1 will send the value itself as the gdb response. A return value < 1 will truncate the lsb 8 bits and send them back as a gdb error response: 'Errn'.

```
void (*save)(char *fname);
```

The `save()` function is called when save command is issued in the simulator. The AHB module should save any required state which is needed to completely restore the state at a later stage. `*fname` points to the base file name which is used by TSIM. TSIM save its internal state to `fname.tss`. It is suggested that the AHB module save its state to `fname.ahs`. Note that any events placed in the event queue by the AHB module will be saved (and restored) by TSIM.

```
void (*restore)(char * fname);
```

The `restore()` function is called when restore command is issued in the simulator. The AHB module should restore any required state to resume operation from a saved check-point. `*fname` points to the base file name which is used by TSIM. TSIM restores its internal state from `fname.tss`.

```
int (*intack)(int level);
```

`intack()` is called when the processor takes an interrupt trap (`tt = 0x11 - 0x1f`). The level of the taken interrupt is passed in `level`. This callback can be used to implement interrupt controllers. `intack()` should return 1 if the interrupt acknowledgement was handled by the AHB module, otherwise 0. If 0 is returned, the default LEON interrupt controller will receive the `intack` instead.

```
int (*plugandplay)(struct pp_amba **p);
```

Leon3/4 only: The `plugandplay()` function is called at startup. `optioplugandplay()` should return in `p` a static pointer to an array with elements of type `struct pp_amba` and return the number of entries in the array. The callback `plugandplay()` is used to add entries in the AHB and APB configuration space. Each `struct pp_amba` entry specifies an entry: If `is_apb` is set to 1 the entry will appear in the APB configuration space and only member `bars[0]` will be used. If `is_apb` is 0 then the entry will appear in the AHB slave configuration space and `bars[0-3]` will be used. If `is_apb` is 2 then the entry will appear in the AHB master configuration space and `bars[0-3]` will be used. The members of the struct resemble the fields in a configuration space entries. The entry is mapped to the first free slot. When using the `-gr712rc` or `-ut700` option, if `is_apb` is 3 the entry will appear under a second ABPCTRL core.

```
void (*intpend)(unsigned int pend);
```

Leon3/4 only: The `intpend()` function is called when the set of pending interrupts changes. The `pend` argument is a bitmask with the bits of pending interrupts set to 1.

```
int meminit;
```

If all loaded AHB modules sets `meminit` to 1, TSIM will initialize and emulate initialize and emulate SRAM/SDRAM/PROM memory. Thus, the AHB module should initialize `meminit` with 1 if TSIM (or another AHB module) should handle memory simulation. Calls to read and write should return -1 (undecoded area) for the memory regions in which case TSIM (or possibly some other AHB module) will handle them. If `meminit` is set to 0 the AHB module itself should emulate the memory address regions.

```
struct sim_interface *simif;
```

Entry `simif` is initialized by `tsim` with the global `struct sim_interface` structure.

```
unsigned char *(*get_mem_ptr_ws)(unsigned int addr, int size, int *wws, int *rws)
```

If `meminit` was set to 1 `tsim` will initialize `get_mem_ptr_ws` with a callback that can be used to query a pointer to the host memory emulating the LEON's memory, along with waitstate information. Note that the host memory pointer returned is in the hosts byte order (normally little endian on a PC). The `size`

parameter should be the length of the access (1 for byte, 2 for short, 4 for word and 8 for double word access). The *wws* and *rws* parameters will return the calculated write and read waitstates for a possible access. See also snoop below for responsibilities when DMA writes are done via pointers from this function.

```
void (*snoop) (unsigned int addr)
```

The callback snoop is initialized by tsim. If data cache snooping is enabled (and functioning, i.e. not ut699) it flushes (i.e. invalidates) data cache lines corresponding to physical address *addr* (on LEON3/4 even when MMU is enabled). If the AHB module is doing DMA writes directly to memory pointers, it is the responsibility of the AHB module to call this for all changed words for snooping to work correctly.

```
struct io_interface *io;
```

Initialized with the I/O interface structure pointer.

```
void (*dprint)(char *);
```

Initialized by tsim with a callback pointer to the debug output function. Output ends up in log, when logging is enabled and gets forwarded to gdb when running TSIM via gdb. See `lprintf` and `vlprintf` for the formatted counterparts.

```
struct proc_interface *proc;
```

Initialized with the procif structure pointer.

```
int (*cacheable)(uint32 addr, uint32 size)
```

The cacheable callback is initialized by the module to NULL or a function returning cacheability for a memory area. The function should return 1 if the range [addr,addr+size) is cacheable, 0 if it is un-cacheable or -1 if the memory area it is not handled by the module. If all modules return -1 and/or lack the cacheable callback, the area will be considered cacheable for memory areas [0x00000000,0x20000000) and [0x40000000-0x80000000) and non-cacheable for all other areas. NOTE: For any (correspondingly aligned) area as large as the largest data cache or instruction cache line size in the system, the cacheable callback may not return different results for different words in the area.

```
int (*lprintf)(const char *format, ...)
```

Initialized by TSIM with a function for formatted loggable debug output. The function interface works like for printf.

```
int (*vlprintf)(const char *format, va_list ap)
```

Initialized by TSIM with a function for formatted loggable debug output. The function interface works like for vprintf.

```
void (*start)(void)
```

Called each time simulation starts, both when starting for the first time using **go** or **run** command and when continuing using **cont**.

```
void (*stop)(void)
```

Called every time simulation stops, e.g. due to breakpoints, user pressing Ctrl-C, etc.

```
void correctable_error(uint32 addr, uint32 master, uint32 size, int write)
```

Can be called by an AHB module to signal a correctable error to an AHBSTAT core (if present) or a LEON2 memstat. It is intended to be called during handling of a successful read or write. The parameters to supply corresponds to the register fields to the AHBSTAT registers or LEON2 FAILAR/FAILSR registers (the *rw* field in LEON2 FAILSR corresponding to !write).

### 5.2.3. Big versus little endianness

SPARC conforms to the big endian byte ordering. This means that the most significant byte of a (half) word has lowest address. To execute efficiently on little-endian hosts (such as Intel x86 PCs), emulated memory is organised on word basis with the bytes within a word arranged according the endianness of the host. Read cycles can then be performed without any conversion since SPARC always reads a full 32-bit word. During byte and half word writes, care must be taken to insert the written data properly into the emulated memory. On a byte-write to address 0, the written byte should be inserted at address 3, since this is the most significant byte according to little endian. Similarly, on a half-word write to bytes 0/1, bytes 2/3 should be written. For a complete example, see the prom emulation function in `io.c`.

## 5.3. TSIM/LEON co-processor emulation

### 5.3.1. FPU/CP interface

The professional version of TSIM/LEON can emulate a user-defined floating-point unit (FPU) and co-processor (CP). The FPU and CP are included into the simulator using loadable modules. To access the module, use the



structure 'cp\_interface' defined in tsim.h. The structure contains a number of functions and variables that must be provided by the emulated FPU/CP:

```

/* structure of function to be provided by an external co-processor */
struct cp_interface {
    void (*cp_init)(); /* called once on start-up */
    void (*cp_exit)(); /* called once on exit */
    void (*cp_reset)(); /* called on processor reset */
    void (*cp_restart)(); /* called on simulator restart */
    uint32 (*cp_reg)(int reg, uint32 data, int read);
    int (*cp_load)(int reg, uint32 data, int *hold);
    int (*cp_store)(int reg, uint32 *data, int *hold);
    int (*cp_exec)(uint32 pc, uint32 inst, int *hold);
    int (*cp_cc)(int *cc, int *hold); /* get condition codes */
    int *cp_status; /* unit status */
    void (*cp_print)(); /* print registers */
    int (*command)(char * cmd); /* CP specific commands */
    int set_fsr(uint32 fsr); /* initialized by tsim */
};
extern struct cp_interface *cp; /* imported co-processor emulation functions */

```

### 5.3.2. Structure elements

```
void (*cp_init)(struct sim_interface sif, struct io_interface iif);
```

Called once on simulator startup. Set to NULL if not used.

```
void (*cp_exit)();
```

Called once on simulator exit. Set to NULL if not used.

```
void (*cp_reset)();
```

Called every time the processor is reset. Set to NULL if not used.

```
void (*cp_restart)();
```

Called every time the simulator is restarted. Set to NULL if not used.

```
uint32 (*cp_reg)(int reg, uint32 data, int read);
```

Used by the simulator to perform diagnostics read and write to the FPU/CP registers. Calling `cp_reg()` should not have any side-effects on the FPU/CP status. `reg` indicates which register to access: 0-31 indicates %f0-%f31/%c0- %31, 34 indicates %fsr/%csr. `read` indicates read or write access: `read==0` indicates write access, `read!=0` indicates read access. Written data is passed in `data`, the return value contains the read value on read accesses.

```
int (*cp_exec)(uint32 pc, uint32 inst, int *hold);
```

Execute FPU/CP instruction. The %pc is passed in `pc` and the instruction opcode in `inst`. If data dependency is emulated, the number of stall cycles should be return in `*hold`. The return value should be zero if no trap occurred or the trap number if a trap did occur (0x8 for the FPU, 0x28 for CP). A trap can occur if the FPU/CP is in exception\_pending mode when a new FPU/CP instruction is executed.

```
int (*cp_cc)(int *cc, int *hold); /* get condition codes */
```

Read condition codes. Used by FBCC/CBCC instructions. The condition codes (0 - 3) should be returned in `*cc`. If data dependency is emulated, the number of stall cycles should be return in `*hold`. The return value should be zero if no trap occurred or the trap number if a trap did occur (0x8 for the FPU, 0x28 for CP). A trap can occur if the FPU/CP is in exception\_pending mode when a FBCC/CBCC instruction is executed.

```
int *cp_status; /* unit status */
```

Should contain the FPU/CP execution status: 0 = execute\_mode, 1 = exception\_pending, 2 = exception\_mode.

```
void (*cp_print)(); /* print registers */
```

Should print the FPU/CP registers to stdio.

```
int (*command)(char * cmd); /* CP specific commands */
```

User defined FPU/CP control commands. NOT YET IMPLEMENTED.

```
int (*set_fsr)(char * cmd); /* initialized by tsim */
```

This callback is initialized by tsim and can be called to set the FPU status register.

### 5.3.3. Attaching the FPU and CP

At startup the simulator tries to load two dynamic link libraries containing an external FPU or CP. The simulator looks for the file `fp.so` and `cp.so` in the current directory and in the search path defined by `ldconfig`. The location of the modules can also be defined using `-cpm` and `-fpm` switches. The environmental variable

TSIM\_MODULE\_PATH can be set to a ':' separated (':' in WIN32) list of search paths. Each library is searched for a pointer 'cp' that points to a cp\_interface structure describing the co-processor. Below is an example from fp.c:

```
struct cp_interface test_fpu = {
    cp_init,          /* cp_init */
    NULL,            /* cp_exit */
    cp_init,          /* cp_reset */
    cp_init,          /* cp_restart */
    cp_reg,           /* cp_reg */
    cp_load,          /* cp_load */
    cp_store,         /* cp_store */
    fpmeiko,          /* cp_exec */
    cp_cc,            /* cp_cc */
    &fpregs.fpstate, /* cp_status */
    cp_print,         /* cp_print */
    NULL,             /* cp_command */
};
struct cp_interface *cp = &test_fpu; /* Attach pointer!! */
```

### 5.3.4. Big versus little endianness

SPARC conforms to the big-endian byte ordering. This means that the most significant byte of a (half) word has lowest address. To execute efficiently on little-endian hosts (such as Intel x86 PCs), emulated register-file is organised on word basis with the bytes within a word arranged according to the endianness of the host. Double words are also in host order, and the read/write register functions must therefore invert the lsb of the register address when performing word access on little-endian hosts. See the file fp.c for examples (cp\_load(), cp\_store()).

### 5.3.5. Additional TSIM commands

- float  
Shows the registers of the FPU
- cp  
Shows the registers of the co-processor.

### 5.3.6. Example FPU

The file fp.c contains a complete SPARC FPU using the co-processor interface. It can be used as a template for implementation of other co-processors. Note that data-dependency checking for correct timing is not implemented in this version (it is however implemented in the built-in version of TSIM).

## 5.4. Loadable modules distributed with TSIM

The following table shows which loadable modules are distributed with which TSIM versions.

Table 5.1. Loadable modules distributed with TSIM

Module	For TSIM versions
Atmel AT697 emulation	LEON2
Cobham UT699 emulation	LEON3
Cobham UT700 emulation	LEON3
Cobham Gaisler GR712RC emulation	LEON3
TPS VxWorks AHB Module	LEON3/4
Example IO module	ERC32, LEON2/3/4
Example AHB module	LEON2/3/4
Example FPU/coprocessor module	LEON2/3/4

### 5.4.1. General AHB module limitations

The general AHB module interface allows for the possibility to support checkpointing and to support system reset during simulation. However, the modules distributed with TSIM does not support these features unless otherwise noted.

The socket base interfaces for the simulation models for cores such as GRETH, GRSPW1, GRSPW2 and CAN\_OC does not support any signalling of restart of the simulation. To ensure a clean restart of simulation when using these cores, restarting TSIM and reconnecting all such socket interfaces is advisable.

## 6. TSIM library (TLIB)

### 6.1. Introduction

The professional version of TSIM is also available as a library, allowing the simulator to be integrated in a larger simulation frame-work. The various TSIM commands and options are accessible through a simple function interface. I/O functions can be added, and use a similar interface to the loadable I/O modules described earlier.

### 6.2. Function interface

The following functions are provided to access TSIM features:

```
int tsim_init (char *option); /* initialise tsim with optional params. */
    Initialize TSIM - must be called before any other TSIM function (except tsim_set_diag()) are used.
    The options string can contain any valid TSIM startup option (as used for the standalone simulator), with
    the exception that no filenames for files to be loaded into memory may be given. tsim_init() may
    only be called once, use the TSIM reset command to reset the simulator without exiting. tsim_init()
    will return 1 on success or 0 on failure.

int tsim_cmd (char *cmd); /* execute tsim command */
    Execute TSIM command. Any valid TSIM command-line command may be given. The following return
    values are defined:

    SIGINT           Simulation stopped due to interrupt
    SIGHUP          Simulation stopped normally
    SIGTRAP         Simulation stopped due to breakpoint hit
    SIGSEGV        Simulation stopped due to processor in error mode
    SIGTERM        Simulation stopped due to program termination

void tsim_exit (int val);
    Should be called to cleanup TSIM internal state before main program exits.

void tsim_get_regs (unsigned int *regs);
    Get SPARC registers. regs is a pointer to an array of integers, see tsim.h for how the various registers
    are indexed.

void tsim_set_regs (unsigned int *regs);
    Set SPARC registers. *regs is a pointer to an array of integers, see tsim.h for how the various registers
    are indexed.

void tsim_disas(unsigned int addr, int num);
    Disassemble memory. addr indicates which address to disassemble, num indicates how many instructions.

void tsim_set_diag (void (*cfunc)(char *));
    Set console output function. By default, TSIM writes all diagnostics and console messages on stdout.
    tsim_set_diag() can be used to direct all output to a user defined routine. The user function is called
    with a single string parameter containing the message to be written.

void tsim_set_callback (void (*cfunc)(void));
    Set the debug callback function. Calling tsim_set_callback() with a function pointer will cause
    TSIM to call the callback function just before each executed instruction, when the history is enabled. At
    this point the instruction to be executed can be seen as the last entry in the history. History can be enabled
    with the tsim_cmd() function.

void tsim_gdb (unsigned char (*inchar)(), void (*outchar)(unsigned char c));
    Controls the simulator using the gdb 'extended-remote' protocol. The inchar parameter is a pointer to a
    function that when called, returns next character from the gdb link. The outchar parameter is a pointer
    to a function that sends one character to the gdb link.

void tsim_read(unsigned int addr, unsigned int *data);
    Performs a read from addr, returning the value in *data. Only for diagnostic use.

void tsim_write(unsigned int addr, unsigned int data);
    Performs a write to addr, with value data. Only for diagnostic use.
```

```
void tsim_stop_event(void (*cfunc)(), int arg, int op);
```

`tsim_stop_event()` can remove certain event depending on the setting of `arg` and `op`. If `op = 0`, all instance of the callback function `cfunc` will be removed. If `op = 1`, events with the argument = `arg` will be removed. If `op = 2`, only the first (earliest) of the events with the argument = `arg` will be removed.

NOTE: The `stop_event()` function may NOT be called from a signal handler installed by the I/O module.

```
void tsim_inc_time(uint64);
```

`tsim_inc_time()` will increment the simulator time without executing any instructions. The event queue is evaluated during the advancement of time and the event callbacks are properly called. Can not be called from event handlers.

```
int tsim_trap(int (*trap)(int tt), void (*rett)());
```

`tsim_trap()` is used to install callback functions that are called every time the processor takes a trap or returns from a trap (RETT instruction). The `trap()` function is called with one argument (`tt`) that contains the SPARC trap number. If `tsim_trap()` returns with 0, execution will continue. A non-zero return value will stop simulation with the program counter pointing to the instruction that will cause the trap. The `rett()` function is called when the program counter points to the RETT instruction but before the instruction is executed. The callbacks are removed by calling `tsim_trap()` with a NULL arguments.

```
int tsim_cov_get(int start, int end, char *ptr);
```

`tsim_cov_get()` will return the coverage data for the address range  $\geq start$  and  $< end$ . The coverage data will be written to a char array pointed to by `*ptr`, starting at `ptr[0]`. One character per 32-bit word in the address range will be written. The user must assure that the char array is large enough to hold the coverage data.

```
int tsim_cov_set(int start, int end, char val);
```

`tsim_cov_set()` will fill the coverage data in the address range limited by `start` and `end` (see above for definition) with the value of `val`.

```
int tsim_ext_ins (int (*func) (struct ins_interface *r));
```

`tsim_ext_ins()` installs a handler for custom instructions. `func` is a pointer to an instruction emulation function as described in Section 4.1.6. Calling `tsim_ext_ins()` with a NULL pointer will remove the handler.

```
int tsim_lastbp (int *addr)
```

When simulation stopped due to breakpoint or watchpoint hit (SIGTRAP), this function will return the address of the break/watchpoint in `*addr`. The function return value indicates the break cause; 0 = breakpoint, 1 = watchpoint.

```
void tsim_set_iosystem (struct io_subsystem *ioarg)
```

On win32 (excluding cygwin), this installs an I/O module that is built into the TLIB application. It must be called before calling `tsim_init()`. See also Section 6.4 for more details.

```
void tsim_set_ahbssystem (struct ahb_subsystem *ahbarg)
```

On win32 (excluding cygwin), this installs an AHB module that is built into the TLIB application. It must be called before calling `tsim_init()`. See also Section 6.4 for more details.

### 6.3. External I/O and AHB modules

External I/O and AHB modules can be loaded when using TLIB, just as with standalone TSIM, by adding the `-iom name` and `-ahbm name` switches to the `tsim_init()` argument string when starting. See Chapter 5 for further information.

### 6.4. Builtin I/O module and/or AHB module

The TSIM library can use a builtin I/O module and or a builtin AHB module that is part of the TLIB application that uses the same I/O interface and AHB interface as the standalone simulator. Instead of loading a shared library containing the module, the module is linked with the main program (for non-win32, including cygwin) or installed using the `tsim_set_iosystem()` and/or `tsim_set_ahbssystem()` functions (for win32). The I/O and AHB functions (and the main program) has the same access to the exported simulator interface (`simif` and `ioif`) as described in the loadable module interface.

For non-win32 (including cygwin) the TSIM library imports the I/O structure pointer, `struct io_subsystem *iosystem`, and AHB structure pointer `struct ahb_subsystem *ahbssystem`. These pointers must exist, but can be set to NULL if no builtin I/O and/or AHB module is present.

For win32 (but not cygwin) the `tsim_set_iosystem()` and `tsim_set_ahbssystem()` functions is instead used to install a builtin I/O module and/or a builtin AHB module. If used, these functions must be called before calling `tsim_init()`. Calling these functions is optional (unlike the direct linking case where the pointers must exist).

An example I/O module and an example AHB module, prepared to be builtin, are provided in `simple_io.c` and `simple_ahb.c`. These modules provides a simpler interface to attach I/O functions and AHB functions. The `app1.c` example shows how the builtin modules are connected for both the win32 case and for other hosts. By default the builtin I/O module is the one that is actively used, but by defining `USEIO` to 0 the builtin AHB module is instead the one that is actively used.

The following interface is provided by `simple_io.c`:

```
void simple_io_set_ioread (void (*cfunc)(int address, int *data, int *ws));
    This function is used to pass a pointer to a user function which is to be called by TSIM when an I/O read
    access is made. The user function is called with the address of the access, a pointer to where the read data
    should be returned, and a pointer to a waitstate variable that should be set to the number of waitstates that
    the access took.
void simple_io_set_iowrite (void (*cfunc)(int address, int *data, int *ws,
int size));
    This function is used to pass a pointer to a user function which is to be called by TSIM when an I/O write
    access is made. The user function is called with the address of the access, a pointer to the data to be written,
    a pointer to a waitstate variable that should be set to the number of waitstates that the access took, and the
    size of the access (0=byte, 1=half-word, 2=word, 3=double-word).
```

The interface in `simple_ahb.c` follows the same principles as the one in `simple_io.c`, but uses the AHB interface.

## 6.5. UART handling

By default, the library is using the same UART handling as the standalone simulator. This means that the UARTs can be connected to the console, or any Unix device (pseudo-ttys, pipes, fifos). If the UARTs are to be handled by the user's I/O emulation routines, `tsim_init()` should be called with `'-nouart'`, which will disable all internal UART emulation. Any access to the UART register by an application will then be routed to the I/O module `read/write` functions.

## 6.6. Linking a TLIB application

Three sample application are provided, one that uses the simplified I/O (or simplified AHB interface) interface (`app1.c`), and two that uses the standard loadable module interface (`app2` and `app3`). They are built by doing a 'make all' in the `tlib` directory. The win32 version of TSIM provides the library as a DLL, for all other platform a static library is provided (.a). Support for dynamic libraries on Linux or Solaris is not available.

## 6.7. Limitations

On Windows/Cygwin hosts a TLIB application is not capable of reading UART A/B from the console, only writing is possible. If reading of UART A/B is necessary, the simulator should be started with `-nouart`, and emulation of the UARTs should be handled by the I/O module.

## 7. Cobham UT699 emulation

To emulate the UT699 chip the `-ut699` should be used. That sets up parameters for core TSIM2 to match UT699 and sets snooping as non-functional. In addition, the UT699 loadable AHB module implements emulation models for additional cores of the UT699. Apart from an overview of what TSIM supports for UT699 emulation, this chapter is mainly about the UT699 AHB module.

The following table lists which cores in the UT699 are modelled by TSIM or not. Some supported cores are modelled by the core TSIM2 and some in the UT699 AHB module. The table contains some notes of some unsupported features for otherwise supported cores, but is not necessarily exhaustive in this respect. See Chapter 4 for details on the builtin simulation models and the rest of the chapter for the AHB module models.

Table 7.1. Simulation models for UT699

Core	Status	Notes
LEON3FT	Supported by core TSIM2	Only one CPU is modelled. No FT features are modelled.
GRFPU	Supported by core TSIM2	
AHBSTAT	Supported by core TSIM2	
APBCTRL	Supported by core TSIM2	
APBUART	Supported by core TSIM2	
FTMCTRL	Supported by core TSIM2	No FT features are modelled
GPTIMER	Supported by core TSIM2	
IRQMP	Supported by core TSIM2	
CAN_OC	Supported by AHB module	
GRETH	Supported by AHB module	
GRGPIO	Supported by AHB module	
GRPCI	Supported by AHB module	Including DMA controller
GRSPW	Supported by AHB module	
CLKGATE	Not supported	
AHBJTAG	Not supported	Debug link
AHBUART	Not supported	Debug link
DSU3	Not supported	Debug unit

TSIM supports running several AHB modules. User defined models for unsupported cores can be used in parallel with the UT699 AHB module. User defined models can also override the simulation models in the UT699 AHB module.

### 7.1. Overview of the UT699 AHB module

The UT699 AHB module is a loadable AHB module that implements UT699 peripherals in addition to what is emulated by core TSIM as listed in Table 7.1. The interfaces are modelled at packet/transaction/message level and provides an easy way to connect the simulated UT699 to a larger simulation framework. See also Section 5.4.1 on some limitations of some features when using this module. The UT699 AHB module is only supported for TSIM2 LEON3.

The following files are delivered with the UT699 TSIM module:

Table 7.2. Files delivered with the UT699 TSIM module

File	Description
ut699/linux/ut699.so	UT699 AHB module for Linux

File	Description
ut699/win32/ut699.dll	UT699 AHB module for Windows
ut699/examples/input	The input directory contains two examples of PCI user modules
ut699/examples/input/README.txt	Description of the user module examples
ut699/examples/input/pci.c	PCI user module example that makes UT699 PCI initiator accesses
ut699/examples/input/pci_target.c	PCI user module example that makes UT699 PCI target accesses
ut699/examples/input/gpio.c	GPIO user module example
ut699/examples/input/ut699inputprovider.h	Interface between the UT699 module and the user defined PCI module
ut699/examples/input/pci_input.h	UT699 PCI input provider definitions
ut699/examples/input/input.h	Generic input provider definitions
ut699/examples/input/tsim.h	TSIM interface definitions
ut699/examples/input/end.h	Defines the endian of the local machine
ut699/examples/test	The test directory contains tests that can be executed in TSIM
ut699/examples/test/README.txt	Description of the tests
ut699/examples/test/Makefile	Makefile for building the tests
ut699/examples/test/cansend.c	CAN transmission test
ut699/examples/test/canrec.c	CAN reception test
ut699/examples/test/pci.c	PCI interface test
ut699/examples/test/pcitest.h	Header file for PCI test

## 7.2. Loading the module

The module is loaded using the TSIM2 option `-ahbm`. A user input module for SPI and PCI can optionally be declared, between `-designinput` and `-designinputend` options. For example:

On Linux:

```
tsim-leon3 -ut699 -ahbm ut699/linux/ut699.so
          -designinput ./input.so -designinputend
```

On Windows:

```
tsim-leon3 -ut699 -ahbm ut699/win32/ut699.dll
          -designinput input.dll -designinputend
```

The option `-ut699` needs to be given to TSIM to enable the UT699 processor configuration. The above line loads the UT699 AHB module `ut699.so` which in turn loads the user user input module `./input.so`. The user input module `./input.so` communicates with `ut699.so` using the user module interface described in `ut699inputprovider.h`, while `ut699.so` communicates with TSIM via the AHB interface.

Example user input modules can be found in `ut699/examples/input/`.

### 7.2.1. User input module interface

The SPI and PCI models in the UT699 module uses a user supplied user input module, in the form of a dynamic loadable library, that models the outside world. This section describes the general interface for hooking up the user module to the UT699 module. The details on the interfaces to the particular cores, see their respective sections.



A user supplied dynamic library should expose a public symbol `ut699inputsystem` of type `struct ut699_subsystem *`. The `struct ut699_subsystem` is defined in `ut699inputprovider.h` as:

```
struct ut699_subsystem {
    void (*ut699_inp_setup) (int id,
                            struct ut699_inp_layout * l,
                            char **argv, int argc);
    void (*ut699_inp_restart) (int id,
                               struct ut699_inp_layout * l);
    struct sim_interface *simif;
};
```

The callback `ut699_inp_restart` will be called every time the simulator restarts. At initialization the callback `ut699_inp_setup` will be called once, supplied with a pointer to structure `struct ut699_inp_layout` defined in `ut699inputprovider.h`.

```
struct ut699_inp_layout {
    struct grpci_input grpci;
    struct gpio_input gpio;
};
```

The user module can access the global TSIM `struct sim_interface` structure through the `simif` member. See Chapter 5 for more details.

The user supplied dynamic library should, in its `ut699_inp_setup` function, “claim” the input structs it uses using the `INPUT_CLAIM` macro. For example `INPUT_CLAIM(l->gpio)` as in the example below.

A user supplied dynamic library that only sets up a model for GPIO could look like this:

```
#include <stdio.h>
#include <string.h>
#include "tsim.h"
#include "ut699inputprovider.h"

extern struct ut699_subsystem *ut699inputsystem;
static struct ut699_inp_layout *lay = 0;

static void Change(struct gpio_input *ctrl) {
    ...
}

int gpioout(struct gpio_input *ctrl, unsigned int out) {
    ...
}

static void ut699_inp_setup (int id,
                            struct ut699_inp_layout * l,
                            char **argv, int argc) {
    lay = l;
    printf("User-dll: ut699_inp_setup:Claiming %s\n", l->gpio._b.name);
    INPUT_CLAIM(l->gpio);
    l->gpio.gpioout = gpioout;
    ut699inputsystem->simif->event(Change, (unsigned long)&l->gpio, 10000000);
}

static struct ut699_subsystem ut699_gpio = {
    ut699_inp_setup, 0, 0
};

struct ut699_subsystem *ut699inputsystem = &ut699_gpio;
```

A Makefile that would build a user supplied dynamic library `gpio.(dll|so)` could look like this:

```
M_DLL_FIX=$(if $(strip $(shell uname|grep MINGW32)),dll,so)
M_LIB=$(if $(strip $(shell uname|grep MINGW32)),-lws2_32 -luser32 -lkernel32 -lwinmm,)

all: gpio.$(M_DLL_FIX)

gpio.$(M_DLL_FIX) : gpio.o
$(CC) -shared -g gpio.o -o gpio.$(M_DLL_FIX) $(M_LIB)

gpio.o: gpio.c
$(CC) -fPIC -c -g -O0 gpio.c -o gpio.o
```

```
clean:
  -rm -f *.o *.so
```

The user can then specify the user module to be loaded by the ut699.so AHB module using the `-designinput` and `-designinputend` command line options. The first argument after `-designinput` is the user module. Arguments after that are passed to the user input module in the call to `ut699_inp_setup`.

For example: `-designinput ut699/examples/input/gpio.so -gpioverbose -designinputend` will specify that the example user input module `gpio.so` should be used and that it should receive the argument `-gpioverbose`.

### 7.3. Debugging

To enable printout of debug information the `-ut699_dbg on flag` switch can be used. Alternatively one can issue the `ut699_dbg on flag` command on the TSIM2 command line to toggle the on/off state of a flag. The debug flags that are available are described for each core in the following sections and can be listed by `ut699_dbg on help`.

Many cores also have their own debug commands on the format `coreX_dbg` that targets single cores instead of all of one kind and that have support to set all or none of the debug flags options and list the current setting for the debug flags. See the sections on the respective cores for details.

### 7.4. 10/100 Mbps Ethernet Media Access Controller interface

The Ethernet core simulation model is designed to functionally model the 10/100 Ethernet MAC available in the UT699. For core details and register specification please see the UT699 manual.

The following features are supported:

- Direct Memory Access
- Interrupts

#### 7.4.1. Start up options

*Ethernet core start up options*

```
-grethconnect host[:port]
```

Connect Ethernet core to a packet server at the specified host and port. Default port is 2224.

#### 7.4.2. Commands

*Ethernet core TSIM commands*

```
greth_connect host[:port]
```

Connect Ethernet core to a packet server at the specified host and port. Default port is 2224.

```
greth_status
```

Print Ethernet register status

#### 7.4.3. Debug flags

The following debug flags are available for the Ethernet interface. Use the them in conjunction with the `ut699_dbg on` command to enable different levels of debug information.

Table 7.3. Ethernet debug flags

Flag	Trace
GAISLER_GRETH_ACC	GRETH accesses
GAISLER_GRETH_L1	GRETH accesses verbose
GAISLER_GRETH_TX	GRETH transmissions
GAISLER_GRETH_RX	GRETH reception
GAISLER_GRETH_RXPACKET	GRETH received packets

Flag	Trace
GAISLER_GRETH_RXCTRL	GRETH RX packet server protocol
GAISLER_GRETH_RXBDCTRL	GRETH RX buffer descriptors DMA
GAISLER_GRETH_RXBDCTRL	GRETH TX packet server protocol
GAISLER_GRETH_TXPACKET	GRETH transmitted packets
GAISLER_GRETH_IRQ	GRETH interrupts

#### 7.4.4. Ethernet packet server

The simulation model relies on a packet server to receive and transmit the Ethernet packets. The packet server should open a TCP socket which the module can connect to. The Ethernet core is connected to a packet server using the `-grethconnect` start-up parameter or using the `greth_connect` command.

An example implementation of a packet server, named `greth_config`, is included in TSIM distribution. It uses the TUN/TAP interface in Linux, or the WinPcap library on Windows, to connect the GRETH core to a physical Ethernet LAN. This makes it easy to connect the simulated GRETH core to real hardware. It can provide a throughput in the order of magnitude of 500 to 1000 KiB/sec. See its distributed README for usage instructions.

#### 7.4.5. Ethernet packet server protocol

Ethernet data packets have the following format. Note that each packet is prepended with a one word length field indicating the length of the packet to come (including its header).

Packet length at offset 0x0:

31 0



31:0    LEN    Length of rest of packet: 4 + number of data bytes

Header at offset 0x4:

31 16 15 8 7 5 4 0



31:16    *R*    Reserved for future use. Must be set to 0.

15:8    IPID    IP core ID: 1 for Ethernet

7:5    TYPE    Packet type: 0 for data packets

4:0    *R*    Reserved for future use. Must be set to 0.

Offset 0x8: The rest of the packet is the encapsulated Ethernet packet

*Figure 7.1. Ethernet data packet*

### 7.5. SpaceWire interface with RMAP support

The UT699 AHB module contains 4 GRSPW cores which models the GRSPW cores available in the UT699. For core details and register specification please see the UT699 manual.

The UT699E AHB module has GRSPW2 cores instead of GRSPW cores. So, for UT699E see Section 9.5 instead.

The following features are supported:

- Transmission and reception of SpaceWire packets
- Interrupts
- RMAP

### 7.5.1. Start up options

#### *SpaceWire core start up options*

- grspwX\_connect host:port  
Connect GRPSW core X to packet server at specified server and port.
- grspwX\_server port  
Open a packet server for core X on specified port.
- grspw\_rxfreq freq  
Set the RX frequency which is used to calculate receive performance.
- grspw\_txfreq freq  
Set the TX frequency which is used to calculate transmission performance.

X in the above options has the range 1-4.

### 7.5.2. Commands

#### *SpaceWire core TSIM commands*

- grspwX\_connect host:port**  
Connect GRSPW core X to packet server at specified server and TCP port.
- grspwX\_server port**  
Open a packet server for core X on specified TCP port.
- grspw\_status**  
Print status for all GRSPW cores.

X in the above commands has the range 1-4.

### 7.5.3. Debug flags

The following debug flags are available for the SpaceWire interfaces. Use the them in conjunction with the **ut699\_dbgon** command to enable different levels of debug information.

*Table 7.4. SpaceWire debug flags*

Flag	Trace
GAISLER_GRSPW_ACC	GRSPW accesses
GAISLER_GRSPW_RXPACKET	GRSPW received packets
GAISLER_GRSPW_RXCTRL	GRSPW rx protocol
GAISLER_GRSPW_TXPACKET	GRSPW transmitted packets
GAISLER_GRSPW_TXCTRL	GRSPW tx protocol

### 7.5.4. SpaceWire packet server

Each SpaceWire core can be configured independently as a packet server or client using either -grspwX\_server or -grspwX\_connect. TCP sockets are used for establishing the connections. When acting as a server the core can only accept a single connection.

For more flexibility, such as custom routing, an external packet server can be implemented using the protocol specified in the following sections. Each core should then be connected to that server.

### 7.5.5. SpaceWire packet server protocol

The protocol used to communicate with the packet server is described below. Three different types of packets are defined according to the table below.


*Table 7.5. Packet types*

Type	Value
Data	0
Time code	1

Note that all packets are prepended by a one word length field which specified the length of the coming packet including the header.


**7.5.5.1. Data packet format**

Packet length at offset 0x0:



31:0    LEN    Length of rest of packet: 4 + number of data bytes

Header at offset 0x4:




- 31:16    *R*        Reserved for future use. Must be set to 0.
- 15:8     IPID        IP core ID: 0 for SpaceWire
- 7:5      TYPE        Packet type: 0 for data packets
- 4:1      *R*        Reserved for future use. Must be set to 0.
- 0        EE         Error End of Packet. Set when the packet is truncated and terminated by an EEP.

Offset 0x8: The rest of the packet is the encapsulated SpaceWire packet

*Figure 7.2. SpaceWire data packet*


**7.5.5.2. Time code packet format**

Packet length at offset 0x0:



31:0    LEN    Length of rest of packet: 8

Header at offset 0x4:



- 31:16    *R*        Reserved for future use. Must be set to 0.
- 15:8     IPID        IP core ID: 0 for SpaceWire
- 7:5      TYPE        Packet type: 1 for time code packets
- 4:0      *R*        Reserved for future use. Must be set to 0.

Payload at offset 0x8:



- 31:8     *R*        Reserved for future use. Must be set to 0.
- 7:6     CT         Time control flags
- 5:0     CN         Value of time counter

*Figure 7.3. SpaceWire time code packet*

## 7.6. PCI initiator/target interface

The UT699 AHB module models the PCI core available in the UT699 ASIC. For core details and register specification please see the UT699 manual.

### 7.6.1. Connecting a user PCI model with the UT699 module

See Section 7.2 for details on how to connect the user PCI model to the UT699 module.

### 7.6.2. Commands

*PCI Commands*

#### **pci\_status**

Print status for the PCI core

### 7.6.3. Debug flags

The following debug flags are available for the PCI interface. Use them in conjunction with the `ut699_dbgcon` command to enable different levels of debug information.

*Table 7.6. PCI interface debug flags*

Flag	Trace
GAISLER_GRP_CI_ACC	AHB accesses to/from PCI core
GAISLER_GRP_CI_REGACC	GRPCI APB register accesses
GAISLER_GRP_CI_DMA_REGACC	PCIDMA APB register accesses
GAISLER_GRP_CI_DMA	GRPCI DMA accesses on the AHB bus
GAISLER_GRP_CI_TARGET_ACC	GRPCI target accesses
GAISLER_GRP_CI_INIT	Print summary on startup

### 7.6.4. PCI bus model API

The structure `struct grpci_input` models the PCI bus. It is defined as:

```
struct grpci_input {
    struct input_inp_b;

    int (*acc)(struct grpci_input *ctrl, int cmd, unsigned int addr,
              unsigned int *data, unsigned int *abort, unsigned int *ws);

    int (*target_acc)(struct grpci_input *ctrl, int cmd, unsigned int addr,
                    unsigned int *data, unsigned int *mexc);
};
```

The `acc` callback should be set by the PCI user module at startup. It is called by the UT699 module whenever it reads/writes as a PCI bus master.

*Table 7.7. acc callback parameters*

Parameter	Description
<code>cmd</code>	Command to execute, see Section 7.6.2 details.
<code>addr</code>	PCI address.
<code>data</code>	Data buffer. The user module should return the read data in <code>*data</code> for read commands or write the data in <code>*data</code> for write commands.
<code>ws</code>	0: 8-bit access 1: 16-bit access, 2: 32-bit access. Is always 2 for read accesses.
<code>ws</code>	Set <code>*ws</code> to the number of PCI clocks it takes to complete the transaction.
<code>abort</code>	Set <code>*abort</code> to 1 to generate target abort, or 0 otherwise.

The return value of `acc` determines if the transaction terminates successfully (1, `GRPCI_ACC_OK`) or with master abort (0, `GRPCI_ACC_MASTER_ABORT`).

The callback `target_acc` is installed by the UT699 AHB module. The PCI user dynamic library can call this function to initiate an access to the UT699 PCI target.

Table 7.8. `target_acc` parameters

Parameter	Description
<code>cmd</code>	Command to execute, see Section 7.6.2 for details. I/O cycles are not supported by the UT699 target.
<code>addr</code>	PCI address. Should always be word aligned for read accesses.
<code>data</code>	Data buffer. The read data is returned in <code>*data</code> for read commands or the data in <code>*data</code> is written for write commands.
<code>wsz</code>	0: 8-bit access 1: 16-bit access, 2: 32-bit access. Should always be 2 for read accesses.
<code>mexc</code>	0 if access is successful, 1 in case of target abort.

If the address matched MEMBAR0, MEMBAR1 or CONFIG `target_acc` will return 1 otherwise 0.

See the `ut699/examples/input` for example implementations.

## 7.7. GPIO interface

### 7.7.1. Connecting a user GPIO model with the UT699 module

See Section 7.2 for details on how to connect the user GPIO model to the UT699 module.

### 7.7.2. Commands

*GPIO Commands*

#### **gpio0\_status**

Print status for the GPIO core.

#### **gpio0\_dbg** [*flag* | *subcommand*]

Toggle, set, clear, list debug flags for the GPIO core.

### 7.7.3. Debug flags

The following debug flags and debug subcommands are available for GPIO interfaces. The `GAISLER_GPIO_*` flags can be used with the **gpio0\_dbg** command to toggle individual flags for individual GPIO cores and with the **ut699\_dbg** command to toggle individual flags for all GPIO cores. The subcommands can be used with the **gpio0\_dbg** command to change and list the settings of all flags for individual GPIO cores.

Table 7.9. *GPIO debug flags*

Flag/subcommand	Trace
<code>GAISLER_GPIO_ACC</code>	GPIO register accesses
<code>GAISLER_GPIO_IRQ</code>	GPIO interrupts
<code>all</code>	Set all GPIO debug flags for the core
<code>clean</code>	Set none of the GPIO debug flags for the core
<code>list</code>	List the current setting of the debug flags for the core

### 7.7.4. GPIO model API

The structure `struct gpio_input` models the GPIO pins. It is defined as:

```
/* GPIO input provider */
struct gpio_input {
    struct input_inp_b;
    int (*gpioout)(struct gpio_input *ctrl, unsigned int out);
    int (*gpioin) (struct gpio_input *ctrl, unsigned int in);
};
```

The `gpioout` callback should be set by the user module at startup. The `gpioin` callback is set by the UT699 AHB module. The `gpioout` callback is called by the UT699 module whenever a GPIO output pin changes. The `gpioin` callback is called by the user module when the input pins should change. Typically the user module would register an event handler at a certain time offset and call `gpioin` from within the event handler.

Table 7.10. *gpioout callback parameters*

Parameter	Description
out	The values of the output pins

Table 7.11. *gpioin callback parameters*

Parameter	Description
in	The input pin values

The return value of `gpioin/gpioout` is ignored.

See the `ut699/examples/input` for an example implementation.

## 7.8. CAN interface

The UT699 AHB module contains 2 CAN\_OC cores which models the CAN\_OC cores available in the UT699. For core details and register specification please see the UT699 manual.

### 7.8.1. Start up options

*CAN core start up options*

- can\_ocX\_connect host:port  
Connect CAN\_OC core X to packet server to specified server and TCP port.
- can\_ocX\_server port  
Open a packet server for CAN\_OC core X on specified TCP port.
- can\_ocX\_ack [0|1]  
Specifies whether the CAN\_OC core will wait for a acknowledgment packet on transmission. This option must be put after `-can_ocX_connect`.

X in the above options is in the range 1-2.

### 7.8.2. Commands

*CAN core TSIM commands*

- can\_ocX\_connect host:port**  
Connect CAN\_OC core X to packet server to specified server and TCP port.
- can\_ocX\_server port**  
Open a packet server for CAN\_OC core X on specified TCP port.
- can\_ocX\_ack <0|1>**  
Specifies whether the CAN\_OC core will wait for a acknowledgment packet on transmission. This command should only be issued after a connection has been established.
- can\_ocX\_status**  
Prints out status information for the CAN\_OC core.
- can\_ocX\_dbg**  
Toggle, set, clear, list debug flags for the CAN\_OC core.

X in the above commands is in the range 1-2.

### 7.8.3. Debug flags

The following debug flags and debug subcommands are available for CAN interfaces. The `GAISLER_CAN_OC_*` flags can be used with the `can_ocX_dbg` command to toggle individual flags for individual CAN\_OC cores and



with the **ut699\_dbgon** command to toggle individual flags for all CAN\_OC cores. The subcommands can be used with the **can\_ocX\_dbg** command to change and list the settings of all flags for individual CAN\_OC cores.

Table 7.12. CAN debug flags

Flag	Trace
GAISLER_CAN_OC_ACC	CAN_OC register accesses
GAISLER_CAN_OC_RXPACKET	CAN_OC received messages
GAISLER_CAN_OC_TXPACKET	CAN_OC transmitted messages
GAISLER_CAN_OC_ACK	CAN_OC acknowledgements
GAISLER_CAN_OC_IRQ	CAN_OC interrupts
all	Set all debug flags for the core
clean	Set none of the debug flags for the core
list	List the current setting of the debug flags for the core

### 7.8.4. Packet server

Each CAN\_OC core can be configured independently as a packet server or client using either `-can_ocX_server` or `-can_ocX_connect`. When acting as a server the core can only accept a single connection.

### 7.8.5. CAN packet server protocol


The protocol used to communicate with the packet server is described below. Four different types of packets are defined according to the table below.

Table 7.13. CAN packet types

Type	Value
Message	0x00
Error counter	0xFD
Acknowledge	0xFE
Acknowledge config	0xFF

#### 7.8.5.1. CAN message packet format

Used to send and receive CAN messages.



CAN message

Byte #	Description	Bits (MSB-LSB)							
		7	6	5	4	3	2	1	0
4	Protocol ID = 0	Prot ID 7-0							
5	Control	FF	RTR	-	-	DLC (max 8 bytes)			
6-9	ID (32 bit word in network byte order)	ID 10-0 (bits 31 - 11 ignored for standard frame format) ID 28-0 (bits 31-29 ignored for extended frame format)							
10-17	Data byte 1 - DLC	Data byte <i>n</i> 7-0							

Figure 7.4. CAN message packet format

### 7.8.5.2. Error counter packet format

Used to write the RX and TX error counter of the modelled CAN interface.

	31		0
0x0	LENGTH		
31:0	LENGTH, specifies the length of the rest of the packet		

Error counter packet

Byte #	Field	Description
4	Packet type	Type of packet, 0xFD for error counter packets
5	Register	0 - RX error counter, 1 - TX error counter
6	Value	Value to write to error counter

Figure 7.5. Error counter packet format

### 7.8.5.3. Acknowledge packet format

If the acknowledge function has been enabled through the start up option or command the CAN interface will wait for an acknowledge packet each time it transmits a message. To enable the CAN receiver to send acknowledge packets (either NAK or ACK) an acknowledge configuration packet must be sent. This is done automatically by the CAN interface when **can\_ocX\_ack** is issued.

	31		0
0x0	LENGTH		
31:0	LENGTH, specifies the length of the rest of the packet		

Acknowledge packet

Byte #	Field	Description
4	Packet type	Type of packet, 0xFE for acknowledge packets
5	Ack payload	0 - No acknowledge, 1 - Acknowledge

Figure 7.6. Acknowledge packet format

### 7.8.5.4. Acknowledge configuration packet format

This packet is used for enabling/disabling the transmission of acknowledge packets and their payload (ACK or NAK) by the CAN receiver. The CAN transmitter will always wait for an acknowledge if started with **-can\_ocX\_ack** or if the **can\_ocX\_ack** command has been issued.

	31		0
0x0	LENGTH		
31:0	LENGTH, specifies the length of the rest of the packet		

Acknowledge configuration packet

Byte #	Field	Description	
4	Packet type	Type of packet, 0xFF for acknowledge configuration packets	
5	Ack configuration	bit 0	Unused
		bit 1	Ack packet enable, 1 - enabled, 0 - disabled
		bit 2	Set ack packet payload, 1 - ACK, 0 - NAK

Figure 7.7. Acknowledge configuration packet format

## 8. Cobham UT699E emulation

To emulate the UT699E chip the `-ut699e` should be used. That sets up parameters for core TSIM2 to match UT699E. In addition, the UT699E loadable AHB module implements emulation models for additional cores of the UT699E. Apart from an overview of what TSIM supports for UT699E emulation, this chapter is mainly about the UT699E AHB module.

The following table lists which cores in the UT699E are modelled by TSIM or not. Some supported cores are modelled by the core TSIM2 and some in the UT699E AHB module. The table contains some notes of some unsupported features for otherwise supported cores, but is not necessarily exhaustive in this respect. See Chapter 4 for details on the builtin simulation models and the rest of the chapter for the AHB module models.

Table 8.1. Simulation models for UT699E

Core	Status	Notes
LEON3FT	Supported by core TSIM2	Only one CPU is modelled. No FT features are modelled.
GRFPU	Supported by core TSIM2	
AHBSTAT	Supported by core TSIM2	
APBCTRL	Supported by core TSIM2	
APBUART	Supported by core TSIM2	
FTMCTRL	Supported by core TSIM2	No FT features are modelled
GPTIMER	Supported by core TSIM2	
IRQMP	Supported by core TSIM2	
CAN_OC	Supported by AHB module	
GRETH	Supported by AHB module	
GRGPIO	Supported by AHB module	
GRPCI	Supported by AHB module	Including DMA controller
GRSPW2	Supported by AHB module	
CLKGATE	Not supported	
AHBJTAG	Not supported	Debug link
AHBUART	Not supported	Debug link
DSU3	Not supported	Debug unit

TSIM supports running several AHB modules. User defined models for unsupported cores can be used in parallel with the UT699E AHB module. User defined models can also override the simulation models in the UT699E AHB module.

### 8.1. Overview of the UT699E AHB module

The UT699E AHB module is a loadable AHB module that implements UT699E peripherals in addition to what is emulated by core TSIM as listed in Table 8.1. The interfaces are modelled at packet/transaction/message level and provides an easy way to connect the simulated UT699E to a larger simulation framework. See also Section 5.4.1 on some limitations of some features when using this module. The UT699E AHB module is only supported for TSIM2 LEON3.

The following files are delivered with the UT699E TSIM module:

Table 8.2. Files delivered with the UT699E TSIM module

File	Description
ut699/linux/ut699e.so	UT699E AHB module for Linux

File	Description
ut699/win32/ut699e.dll	UT699E AHB module for Windows
ut699/examples/input	The input directory contains two examples of PCI user modules
ut699/examples/input/README.txt	Description of the user module examples
ut699/examples/input/pci.c	PCI user module example that makes UT699E PCI initiator accesses
ut699/examples/input/pci_target.c	PCI user module example that makes UT699E PCI target accesses
ut699/examples/input/gpio.c	GPIO user module example
ut699/examples/input/ut699inputprovider.h	Interface between the UT699E module and the user defined PCI module
ut699/examples/input/pci_input.h	UT699E PCI input provider definitions
ut699/examples/input/input.h	Generic input provider definitions
ut699/examples/input/tsim.h	TSIM interface definitions
ut699/examples/input/end.h	Defines the endian of the local machine
ut699/examples/test	The test directory contains tests that can be executed in TSIM
ut699/examples/test/README.txt	Description of the tests
ut699/examples/test/Makefile	Makefile for building the tests
ut699/examples/test/cansend.c	CAN transmission test
ut699/examples/test/canrec.c	CAN reception test
ut699/examples/test/pci.c	PCI interface test
ut699/examples/test/pcitest.h	Header file for PCI test

## 8.2. Loading the module

The module is loaded using the TSIM2 option `-ahbm`. A user input module for SPI and PCI can optionally be declared, between `-designinput` and `-designinputend` options. For example:

On Linux:

```
tsim-leon3 -ut699e -ahbm ut699/linux/ut699e.so
          -designinput ./input.so -designinputend
```

On Windows:

```
tsim-leon3 -ut699e -ahbm ut699/win32/ut699e.dll
          -designinput input.dll -designinputend
```

The option `-ut699e` needs to be given to TSIM to enable the UT699E processor configuration. The above line loads the UT699E AHB module `ut699e.so` which in turn loads the user user input module `./input.so`. The user input module `./input.so` communicates with `ut699e.so` using the user module interface described in `ut699inputprovider.h`, while `ut699e.so` communicates with TSIM via the AHB interface.

Example user input modules can be found in `ut699/examples/input/`.

### 8.2.1. User input module interface

The SPI and PCI models in the UT699E module uses a user supplied user input module, in the form of a dynamic loadable library, that models the outside world. This section describes the general interface for hooking up the user module to the UT699E module. The details on the interfaces to the particular cores, see their respective sections.

A user supplied dynamic library should expose a public symbol `ut699inputsystem` of type `struct ut699_subsystem *`. The `struct ut699_subsystem` is defined in `ut699inputprovider.h` as:

```
struct ut699_subsystem {
    void (*ut699_inp_setup) (int id,
                            struct ut699_inp_layout * l,
                            char **argv, int argc);
    void (*ut699_inp_restart) (int id,
                               struct ut699_inp_layout * l);
    struct sim_interface *simif;
};
```

The callback `ut699_inp_restart` will be called every time the simulator restarts. At initialization the callback `ut699_inp_setup` will be called once, supplied with a pointer to structure `struct ut699_inp_layout` defined in `ut699inputprovider.h`.

The user module can access the global TSIM `struct sim_interface` structure through the `simif` member. See Chapter 5 for more details.

The user supplied dynamic library should, in its `ut699_inp_setup` function, “claim” the input structs it uses using the `INPUT_CLAIM` macro. For example `INPUT_CLAIM(l->gpio)` as in the example below.

A user supplied dynamic library that only sets up a model for GPIO could look like this:

```
#include <stdio.h>
#include <string.h>
#include "tsim.h"
#include "ut699inputprovider.h"

extern struct ut699_subsystem *ut699inputsystem;
static struct ut699_inp_layout *lay = 0;

static void Change(struct gpio_input *ctrl) {
    ...
}

int gpioout(struct gpio_input *ctrl, unsigned int out) {
    ...
}

static void ut699_inp_setup (int id,
                            struct ut699_inp_layout * l,
                            char **argv, int argc) {
    lay = l;
    printf("User-dll: ut699_inp_setup:Claiming %s\n", l->gpio._b.name);
    INPUT_CLAIM(l->gpio);
    l->gpio.gpioout = gpioout;
    ut699inputsystem->simif->event(Change, (unsigned long)&l->gpio, 1000000);
}

static struct ut699_subsystem ut699_gpio = {
    ut699_inp_setup, 0, 0
};

struct ut699_subsystem *ut699inputsystem = &ut699_gpio;
```

A Makefile that would build a user supplied dynamic library `gpio.(dll|so)` could look like this:

```
M_DLL_FIX=$(if $(strip $(shell uname|grep MINGW32)),dll,so)
M_LIB=$(if $(strip $(shell uname|grep MINGW32)),-lws2_32 -luser32 -lkernel32 -lwinmm,)

all: gpio.$(M_DLL_FIX)

gpio.$(M_DLL_FIX) : gpio.o
$(CC) -shared -g gpio.o -o gpio.$(M_DLL_FIX) $(M_LIB)

gpio.o: gpio.c
$(CC) -fPIC -c -g -O0 gpio.c -o gpio.o

clean:
-rm -f *.o *.so
```

The user can then specify the user module to be loaded by the `ut699e.so` AHB module using the `-designinput` and `-designinputend` command line options. The first argument after `-designinput` is the user module. Arguments after that are passed to the user input module in the call to `ut699_inp_setup`.

For example: `-designinput ut699/examples/input/gpio.so -gpioverbose -designinputend` will specify that the example user input module `gpio.so` should be used and that it should receive the argument `-gpioverbose`.

### 8.3. Debugging

To enable printout of debug information the `-ut699_dbg on flag` switch can be used. Alternatively one can issue the `ut699_dbg on flag` command on the TSIM2 command line to toggle the on/off state of a flag. The debug flags that are available are described for each core in the following sections and can be listed by `ut699_dbg on help`.

Many cores also have their own debug commands on the format `coreX_dbg` that targets single cores instead of all of one kind and that have support to set all or none of the debug flags options and list the current setting for the debug flags. See the sections on the respective cores for details.

### 8.4. 10/100 Mbps Ethernet Media Access Controller interface

The Ethernet core simulation model is designed to functionally model the 10/100 Ethernet MAC available in the UT699E. For core details and register specification please see the UT699E manual.

The following features are supported:

- Direct Memory Access
- Interrupts

#### 8.4.1. Start up options

*Ethernet core start up options*

`-grethconnect host[:port]`

Connect Ethernet core to a packet server at the specified host and port. Default port is 2224.

#### 8.4.2. Commands

*Ethernet core TSIM commands*

**greth\_connect host[:port]**

Connect Ethernet core to a packet server at the specified host and port. Default port is 2224.

**greth\_status**

Print Ethernet register status

#### 8.4.3. Debug flags

The following debug flags are available for the Ethernet interface. Use the them in conjunction with the `ut699_dbg on` command to enable different levels of debug information.

*Table 8.3. Ethernet debug flags*

Flag	Trace
GAISLER_GRETH_ACC	GRETH accesses
GAISLER_GRETH_L1	GRETH accesses verbose
GAISLER_GRETH_TX	GRETH transmissions
GAISLER_GRETH_RX	GRETH reception
GAISLER_GRETH_RXPACKET	GRETH received packets
GAISLER_GRETH_RXCTRL	GRETH RX packet server protocol
GAISLER_GRETH_RXBDCTRL	GRETH RX buffer descriptors DMA
GAISLER_GRETH_RXBDCTRL	GRETH TX packet server protocol
GAISLER_GRETH_TXPACKET	GRETH transmitted packets

Flag	Trace
GAISLER_GRETH_IRQ	GRETH interrupts

#### 8.4.4. Ethernet packet server


The simulation model relies on a packet server to receive and transmit the Ethernet packets. The packet server should open a TCP socket which the module can connect to. The Ethernet core is connected to a packet server using the `-grethconnect` start-up parameter or using the `greth_connect` command.

An example implementation of a packet server, named `greth_config`, is included in TSIM distribution. It uses the TUN/TAP interface in Linux, or the WinPcap library on Windows, to connect the GRETH core to a physical Ethernet LAN. This makes it easy to connect the simulated GRETH core to real hardware. It can provide a throughput in the order of magnitude of 500 to 1000 KiB/sec. See its distributed README for usage instructions.

#### 8.4.5. Ethernet packet server protocol


Ethernet data packets have the following format. Note that each packet is prepended with a one word length field indicating the length of the packet to come (including its header).

Packet length at offset 0x0:



31:0    LEN    Length of rest of packet: 4 + number of data bytes

Header at offset 0x4:



31:16    *R*        Reserved for future use. Must be set to 0.

15:8     IPID     IP core ID: 1 for Ethernet

7:5     TYPE     Packet type: 0 for data packets

4:0     *R*        Reserved for future use. Must be set to 0.

Offset 0x8: The rest of the packet is the encapsulated Ethernet packet

*Figure 8.1. Ethernet data packet*

### 8.5. SpaceWire interface with RMAP support

The UT699E AHB module contains 4 GRSPW2 cores which models the GRSPW2 cores available in the UT699E. For core details and register specification please see the UT699E manual.

Supported features include:

- Transmission and reception of SpaceWire packets
- Transmission and reception of Time codes
- RMAP
- Server side link state model
- Link errors
- Link error injection

All GRSPW2 register fields with underlying functionality in the UT699E are supported except for:

- The link model is only in `error` `reset` state or `run` state.
- The RMAP buffer disable (RD) bit in the control register with underlying functionality is not modelled.

- The limitations of the No spill (NS) DMA control register as noted in the section on Flow control limitations below.

### 8.5.1. Start up options

*SpaceWire core start up options*

- grspwX\_connect *host:port*  
Connect GRPSW core *X* to packet server at specified server and port.
- grspwX\_server *port*  
Open a packet server for core *X* on specified port.
- grspw\_spwfreq *freq*  
Sets the SpaceWire input clock frequency. Combined with the clock divisor register, this determines the startup frequency and TX frequency.
- grspw\_clkdiv *value*  
Sets the reset value for the clock divisor register for all GRSPW2 cores.
- grspw\_tx\_max\_part\_len *len*  
Sets up all GRSPW2 cores to transmit any SpaceWire packet longer than *len* in data part packets with no more than *len* bytes of data.
- grspw\_simple 1  
Set all GRSPW2 cores to “simple mode”. This can be used for backward compatibility with TSIM 2.0.44 and backwards. See the separate section on simple mode for details. Note the needed 1 argument.
- grspw\_simple\_rxfreq *freq*  
Sets the RX frequency in MHz for all GRSPW2 cores to *freq*. This is only valid together with the -grspw\_simple 1 option.

*X* in the above options has the range 1-4.

### 8.5.2. Commands

*SpaceWire core TSIM commands*

- grspwX\_connect** *host:port*  
Connect GRSPW2 core *X* to packet server at specified server and TCP port.
- grspwX\_server** *port*  
Open a packet server for GRSPW2 core *X* on specified TCP port.
- grspwX\_status**  
Print status for GRSPW2 core *X*.
- grspwX\_dbg** [*argument*]  
Sets, clears, lists, toggles debug options for individual GRSPW2 cores. Using **grspwX\_dbg** without any arguments will list all available options. The **list** argument will list current debug option settings. The **all** argument will turn on all debug options. The **clean** argument will turn off all debug options. Using one of the available debug options as argument will toggle that debug option. See the section below.

*X* in the above commands has the range 1-4.

### 8.5.3. Debug flags

The following debug flags and debug subcommands are available for SpaceWire interfaces. The **GAISLER\_GRSPW\_\*** flags can be used with the **grspwX\_dbg** command to toggle individual flags for individual SpaceWire cores and with the **ut699\_dbgon** command to toggle individual flags for all SpaceWire cores. The subcommands can be used with the **grspwX\_dbg** command to change and list the settings of all flags for individual SpaceWire cores.

Table 8.4. SpaceWire debug flags

Flag	Trace
GAISLER_GRSPW_ACC	GRSPW accesses
GAISLER_GRSPW_RXPACKET	GRSPW received packets



Flag	Trace
GAISLER_GRSPW_RXCTRL	GRSPW rx protocol
GAISLER_GRSPW_TXPACKET	GRSPW transmitted packets
GAISLER_GRSPW_TXCTRL	GRSPW tx protocol
GAISLER_GRSPW_RMAP	GRSPW RMAP accesses
GAISLER_GRSPW_RMAPPACKET	GRSPW RMAP packet dumps
GAISLER_GRSPW_RMAPPACKDE	GRSPW RMAP packet decoding
GAISLER_GRSPW_DMAERR	GRSPW DMA errors
GAISLER_GRSPW_LINK	Link changes
GAISLER_GRSPW_PART	TX/RX of GRSPW data part packets
all	Set all debug flags for the core
clean	Set none of the debug flags for the core
list	List the current setting of the debug flags for the core

#### 8.5.4. SpaceWire packet server

Each SpaceWire core can be configured independently as a packet server or client using either `-grspwX_server` or `-grspwX_connect`. TCP sockets are used for establishing the connections. When acting as a server the core can only accept a single connection.

A connection should be set up before starting simulation for the first time, and must not be broken after that. Restarting the simulation will not tear down the connection, nor emptying any socket buffers.

The server side contains a link model that gets control information from the models at each end of the link, determines the link state and communicates frequencies and link errors to the two models at each ends of the link. It also supports error injection via two error injection packet types that can be sent from a custom client. See the following sections for details.

For more flexibility, such as custom routing, an external packet server can be implemented using the protocol specified in the following sections. Each core should then be connected to that server. That server would also have to implement a link model that at least reacts to link control packets and sends out link state packets and RX frequency packets.

#### 8.5.5. SpaceWire packet server protocol

The protocol used to communicate with the packet server is described below. The different types of packets are defined according to the table below.

Table 8.5. Packet types

Type	Value	Direction	Notes
Data part	0	Both	Only when in run state
Time code	1	Both	Only when in run state
Link state	2	Server to client	
Link control	3	Client to server	Must be sent for model to reach run state
RX frequency	4	Server to client	
Error injection	5	Client to server	Optional
Packet error request	6	Client to server	Optional

All packets begin with a 32-bit big endian word length field which specifies the length of the rest of the packet, including header and other fixed fields. For most packet types this length is fixed for the particular type. Apart

from the data part packet type, where data follows the header byte-wise, all fields are 32-bit big endian words if not otherwise specified.

All packets received by the GRSPW2 model are handled sequentially, and all packets sent by the GRSPW2 model and the server side link model are supposed to be handled sequentially by the client. SpaceWire packets can be split into multiple data parts, transferred in data part packets. Between such parts other packets such as for time codes, link state changes, link control changes, etc., can be handled. During the simulated time span for the reception of a data part, the receiver will not/should not handle any other packet types. Use the `-grspw_tx_max_part_len` to set up GRSPW2 model to split up SpaceWire packets into data parts in order for such events to be able to happen during the data stream.

**8.5.5.1. Flow control limitations**

Flow control in terms of credit is not modeled between two ends of a link. A transmitter gets no notice if the other end cannot give more credit. If the no-spill bit in the GRSPW2 core is set and an enabled receiving DMA channel has no enabled descriptors, the data part packet will be held on the receiving side until a descriptor is available. Due to the sequential nature of the packet model a link error, time code, etc. will not be handled at all by the GRSPW2 model during this time.

**8.5.5.2. Data part packet format**

A SpaceWire packet is represented by one or more data parts. A data part packet represents one such a part. For the data parts of a multi part SpaceWire packet, only the last data part should have an EOP or EEP end marker, i.e. the *END* field set to 0 or 1. The other parts should have no end marker, i.e. the *END* field set to 2. Each data part is delivered in its entirety or not at all. A link error occurring between data parts on the other hand cuts the SpaceWire packet short and is considered the end of that SpaceWire packet.


A data part packet is sent at the beginning of transmission of the corresponding part of the SpaceWire packet, so that the receiver can start reacting to it as soon as the transmission starts. Therefore, the receiver should delay for the amount of simulated time it takes to receive the part before handling the next packet in the socket.

Packet length at offset 0x0:



31:0    LEN    Length of rest of packet: 4 + number of data bytes in the part

Header at offset 0x4:



31:16    *R*    Reserved for future use. Must be set to 0.

15:8    IPID    IP core ID: 0 for SpaceWire

7:5    TYPE    Packet type: 0 for data part packets

4:2    *R*    Reserved for future use. Must be set to 0.


1:0    END    End marker: 0: Normal End of Packet, 1: Error End of Packet, 2: No end marker

Offset 0x8: The data bytes of the part starts here


*Figure 8.2. SpaceWire data part packet*

### 8.5.5.3. Time code packet format

Packet length at offset 0x0:



Header at offset 0x4:



Payload at offset 0x8:




Figure 8.3. SpaceWire time code packet

### 8.5.5.4. Link state packet format

Link state packets are sent out by the server side link model when the link state changes. The only states currently simulated are `Error Reset` and `Run`. A link state packet with state `Error Reset` can have the `ERROR` field set to an error seen at the receiver. Other link state packets has only `None` in the `ERROR` field.

Packet length at offset 0x0:


31 0



31:0    LEN    Length of rest of packet: 4

Header at offset 0x4:

31 19 18 16 15 8 7 5 4 3 2 0



- 31:19    *R*        Reserved for future use. Must be set to 0.
- 18:16    ERROR    Link error: 0: None, 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8     IPID     IP core ID: 0 for SpaceWire
- 7:5     TYPE    Packet type: 2 for link state packets
- 4:3     *R*        Reserved for future use. Must be set to 0.
- 2:0     LS        Link State: 0: Error reset, 1: Error wait, 2: Ready, 3: Started, 4: Connecting, 5: Run

*Figure 8.4. SpaceWire link state packet*

**8.5.5.5. Link control packet format**

A link control packet must be sent from a client to the server side link model to inform if that side of the link is in start mode, autostart mode, and/or has the link disabled. In addition, the control packet contains information on the startup frequency and the TX frequency that will be used once run state is reached. A new link control packet should be sent from a client any time any of these parameters change.

If the startup frequencies of the two ends differ by more than a factor 1.1/0.9, the link model will reach run state. This limit is chosen based on the limits on timeout periods in the SpaceWire standard that must be within 10% up or down from nominal frequency. So even though the startup frequency should be 10 MHz, run state can be reached if startup frequencies are close enough.

Packet length at offset 0x0:

31 0



31:0 LEN Length of rest of packet: 12

Header at offset 0x4:

31 16 15 8 7 5 4 3 2 1 0



31:16 *R* Reserved for future use. Must be set to 0.

15:8 IPID IP core ID: 0 for SpaceWire

7:5 TYPE Packet type: 3 for link control packets

4:3 *R* Reserved for future use. Must be set to 0.


2 AS Link autostart.

1 LS Link start.

0 LD Link disable.

Startup frequency in MHz at offset 0x8:

31 0



31:0 SFREQ Startup frequency in MHz, big endian IEEE-754 32-bit float

TX frequency in MHz at offset 0xc:

31 0



31:0 TFREQ TX frequency in MHz, big endian in IEEE-754 32-bit float

*Figure 8.5. SpaceWire link control packet*

**8.5.5.6. RX frequency packet format**

The server side link model sends out this packet type to inform the client of with what frequency the other side transmits with when in run state. A new packet of this type is sent any time the transmitter on the other side changes its TX frequency.

Packet length at offset 0x0:

31 0

LEN
-----

31:0 LEN Length of rest of packet: 8

Header at offset 0x4:

31 16 15 8 7 5 4 0

R	IPID	TYPE	R
---	------	------	---

31:16 R Reserved for future use. Must be set to 0.

15:8 IPID IP core ID: 0 for SpaceWire

7:5 TYPE Packet type: 4 for rx frequency packets

4:0 R Reserved for future use. Must be set to 0.

RX frequency in MHz at offset 0x8:

31 0

RFREQ
-------

31:0 RFREQ RX frequency in MHz, big endian IEEE-754 32-bit float

Figure 8.6. SpaceWire rx frequency packet

### 8.5.5.7. Link error injection packet format

A client can send a packet of this kind to the server side link model to request that a link error will occur. The error specified is the link error that is seen at the targeted end. The *OE* bit determines which end of the link is the targeted end, i.e. will see the error.

If the *OE* bit is set to 1, the error will be seen at the receiver of the simulation model on the other end. The simulation model on the client side will see a disconnect error via a link state packet. In order for this error to happen during reception of a SpaceWire packet at the other end, the client can send a data part packet with no end marker followed by a link error injection packet.

If the *OE* bit is set to 0, the error will be seen at the receiver on the client end. The simulation model at the client end will see the requested error via a link state packet. The simulation model at the other end will see a disconnect error. Note that due to the nature of the model, this cannot in general be relied upon to inject an error during the reception of a SpaceWire packet, even if split up in multiple data parts. The link state packet will not be sent by the server side link model until all previous packets have been handled, and the client should handle all other packets queued up before that link state packet can be handled. To inject a link error during the reception of a SpaceWire packet at the client side, the packet error request packet should be used instead.

Packet length at offset 0x0:


31 0



31:0 LEN Length of rest of packet: 4

Header at offset 0x4:

31 21 20 19 18 16 15 8 7 5 4 0



- 31:21 *R* Reserved for future use. Must be set to 0.
- 20 OE Other end: 1: other end gets the error, 0: my end gets error
- 19 *R* Reserved for future use. Must be set to 0.
- 18:16 ERROR Link error: 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8 IPID IP core ID: 0 for SpaceWire
- 7:5 TYPE Packet type: 5 for link error injection packets
- 4:0 *R* Reserved for future use. Must be set to 0.

*Figure 8.7. SpaceWire link error injection packet*

**8.5.5.8. Packet error request packet format**

A client can send a packet of this kind to the server side link model to request that a link error will occur during reception of a certain data packet by the client. The error specified is the link error that is seen, via a link state packet, by the client as a result. The other side will see a disconnect error. A 64-bit packet number, counting from 0, indicates during which SpaceWire packet sent from the other side to the client the link error should happen. Note that this number is indexing SpaceWire packets, not individual data part packets, and does not take SpaceWire packets sent from the client to the server side into account in the numbering. There can only be one outstanding packet error request per targeted GRSPW2 core at a time.

The **grspwX\_status** command can be issued for the targeted GRSPW2 core to see how many SpaceWire packets have currently been sent by that core. This includes started but aborted SpaceWire packets, due to link error, core reset or active aborting using the Abort TX (AT) bit in the DMA control register of the GRSPW2 core.

Packet length at offset 0x0:


31 0



31:0 LEN Length of rest of packet: 16

Header at offset 0x4:

31 19 18 16 15 8 7 5 4 0



- 31:19 R Reserved for future use. Must be set to 0.
- 18:16 ERROR Link error: 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8 IPID IP core ID: 0 for SpaceWire
- 7:5 TYPE Packet type: 6 for packet error request packets
- 4:0 R Reserved for future use. Must be set to 0.

Packet number to request error for, most significant word at offset 0x8:


31 0



31:0 MSW Bits 63:32 of unsigned 64-bit big endian integer

Packet number to request error for, least significant word at offset 0xc:


31 0



31:0 LSW Bits 31:0 of unsigned 64-bit big endian integer

Reserved field at offset 0x10:

31 0



31:0 R Reserved for future use. Must be set to 0.

Figure 8.8. SpaceWire packet error request packet

### 8.5.6. Simple Mode

For backwards compatibility with TSIM 2.0.44 and older, the GRSPW2 models can be set up in “simple mode” with the `-grspw_simple 1` option. This makes the following changes to the simulation model for all GRSPW2 cores:

- The *only* supported packet types are data part packets and time code packets. The model sends out no other packet types and accepts no other packet types.
- Data part packets should *always* contain full SpaceWire packets. The `-grspw_tx_max_part_len` should not be used together with simple mode and data part packets without end marker should be sent to a GRSPW2 model when using simple mode.
- The link state that a GRSPW2 core perceives is solely determined by its own link control setting. The other end is assumed to try to start the link. In other words, run state is achieved once the GRSPW2 is set to start or autostart without having link disable set. Moreover, startup frequencies are ignored and run state is achieved without any delay.



- The RX frequency is determined primarily by the `-grspw_simple_rxfreq` option. If that is not used, the RX frequency is taken by the `-grspw_spwfreq` option. If none of those options are set the CPU frequency is used. No cases take any clock divisors into account. The TX frequency is determined in the usual way as when not in simple mode, which includes taking the clock divisor register into account.

## 8.6. PCI initiator/target interface

The UT699E AHB module models the PCI core available in the UT699E ASIC. For core details and register specification please see the UT699E manual.

### 8.6.1. Connecting a user PCI model with the UT699E module

See Section 8.2 for details on how to connect the user PCI model to the UT699E module.

### 8.6.2. Commands

*PCI Commands*

#### **pci\_status**

Print status for the PCI core

### 8.6.3. Debug flags

The following debug flags are available for the PCI interface. Use them in conjunction with the `ut699_dbgon` command to enable different levels of debug information.

*Table 8.6. PCI interface debug flags*

Flag	Trace
GAISLER_GRP_CI_ACC	AHB accesses to/from PCI core
GAISLER_GRP_CI_REGACC	GRPCI APB register accesses
GAISLER_GRP_CI_DMA_REGACC	PCIDMA APB register accesses
GAISLER_GRP_CI_DMA	GRPCI DMA accesses on the AHB bus
GAISLER_GRP_CI_TARGET_ACC	GRPCI target accesses
GAISLER_GRP_CI_INIT	Print summary on startup

### 8.6.4. PCI bus model API

The structure `struct grpci_input` models the PCI bus. It is defined as:

```
struct grpci_input {
    struct input_inp_b;

    int (*acc)(struct grpci_input *ctrl, int cmd, unsigned int addr,
              unsigned int *data, unsigned int *abort, unsigned int *ws);

    int (*target_acc)(struct grpci_input *ctrl, int cmd, unsigned int addr,
                    unsigned int *data, unsigned int *mexc);
};
```

The `acc` callback should be set by the PCI user module at startup. It is called by the UT699E module whenever it reads/writes as a PCI bus master.

*Table 8.7. acc callback parameters*

Parameter	Description
<code>cmd</code>	Command to execute, see Section 8.6.2 details.
<code>addr</code>	PCI address.
<code>data</code>	Data buffer. The user module should return the read data in <code>*data</code> for read commands or write the data in <code>*data</code> for write commands.

Parameter	Description
wsiz	0: 8-bit access 1: 16-bit access, 2: 32-bit access. Is always 2 for read accesses.
ws	Set <i>*ws</i> to the number of PCI clocks it takes to complete the transaction.
abort	Set <i>*abort</i> to 1 to generate target abort, or 0 otherwise.

The return value of `acc` determines if the transaction terminates successfully (1, `GRPCI_ACC_OK`) or with master abort (0, `GRPCI_ACC_MASTER_ABORT`).

The callback `target_acc` is installed by the UT699E AHB module. The PCI user dynamic library can call this function to initiate an access to the UT699E PCI target.

Table 8.8. *target\_acc* parameters

Parameter	Description
cmd	Command to execute, see Section 8.6.2 for details. I/O cycles are not supported by the UT699E target.
addr	PCI address. Should always be word aligned for read accesses.
data	Data buffer. The read data is returned in <i>*data</i> for read commands or the data in <i>*data</i> is written for write commands.
wsiz	0: 8-bit access 1: 16-bit access, 2: 32-bit access. Should always be 2 for read accesses.
mexc	0 if access is successful, 1 in case of target abort.

If the address matched `MEMBAR0`, `MEMBAR1` or `CONFIG` `target_acc` will return 1 otherwise 0.

See the `ut699/examples/input` for example implementations.

## 8.7. GPIO interface

### 8.7.1. Connecting a user GPIO model with the UT699E module

See Section 8.2 for details on how to connect the user GPIO model to the UT699E module.

### 8.7.2. Commands

#### *GPIO Commands*

##### **gpio0\_status**

Print status for the GPIO core.

##### **gpio0\_dbg** [*flag* | *subcommand*]

Toggle, set, clear, list debug flags for the GPIO core.

### 8.7.3. Debug flags

The following debug flags and debug subcommands are available for GPIO interfaces. The `GAISLER_GPIO_*` flags can be used with the `gpio0_dbg` command to toggle individual flags for individual GPIO cores and with the `ut699_dbgon` command to toggle individual flags for all GPIO cores. The subcommands can be used with the `gpio0_dbg` command to change and list the settings of all flags for individual GPIO cores.

Table 8.9. *GPIO debug flags*

Flag/subcommand	Trace
<code>GAISLER_GPIO_ACC</code>	GPIO register accesses
<code>GAISLER_GPIO_IRQ</code>	GPIO interrupts
<code>all</code>	Set all GPIO debug flags for the core

Flag/subcommand	Trace
clean	Set none of the GPIO debug flags for the core
list	List the current setting of the debug flags for the core

### 8.7.4. GPIO model API

The structure `struct gpio_input` models the GPIO pins. It is defined as:

```
/* GPIO input provider */
struct gpio_input {
    struct input_inp _b;
    int (*gpioout)(struct gpio_input *ctrl, unsigned int out);
    int (*gpioin) (struct gpio_input *ctrl, unsigned int in);
};
```

The `gpioout` callback should be set by the user module at startup. The `gpioin` callback is set by the UT699E AHB module. The `gpioout` callback is called by the UT699E module whenever a GPIO output pin changes. The `gpioin` callback is called by the user module when the input pins should change. Typically the user module would register an event handler at a certain time offset and call `gpioin` from within the event handler.

Table 8.10. *gpioout* callback parameters

Parameter	Description
out	The values of the output pins

Table 8.11. *gpioin* callback parameters

Parameter	Description
in	The input pin values

The return value of `gpioin/gpioout` is ignored.

See the `ut699/examples/input` for an example implementation.

## 8.8. CAN interface

The UT699E AHB module contains 2 CAN\_OC cores which models the CAN\_OC cores available in the UT699E. For core details and register specification please see the UT699E manual.

### 8.8.1. Start up options

*CAN core start up options*

- can\_ocX\_connect host:port  
Connect CAN\_OC core X to packet server to specified server and TCP port.
- can\_ocX\_server port  
Open a packet server for CAN\_OC core X on specified TCP port.
- can\_ocX\_ack [0|1]  
Specifies whether the CAN\_OC core will wait for a acknowledgment packet on transmission. This option must be put after `-can_ocX_connect`.

X in the above options is in the range 1-2.

### 8.8.2. Commands

*CAN core TSIM commands*

- can\_ocX\_connect host:port**  
Connect CAN\_OC core X to packet server to specified server and TCP port.

**can\_ocX\_server port**

Open a packet server for CAN\_OC core X on specified TCP port.

**can\_ocX\_ack <0|1>**

Specifies whether the CAN\_OC core will wait for a acknowledgment packet on transmission. This command should only be issued after a connection has been established.

**can\_ocX\_status**

Prints out status information for the CAN\_OC core.

**can\_ocX\_dbg**

Toggle, set, clear, list debug flags for the CAN\_OC core.

X in the above commands is in the range 1-2.

### 8.8.3. Debug flags

The following debug flags and debug subcommands are available for CAN interfaces. The *GAISLER\_CAN\_OC\_\** flags can be used with the **can\_ocX\_dbg** command to toggle individual flags for individual CAN\_OC cores and with the **ut699\_dbgon** command to toggle individual flags for all CAN\_OC cores. The subcommands can be used with the **can\_ocX\_dbg** command to change and list the settings of all flags for individual CAN\_OC cores.

Table 8.12. CAN debug flags

Flag	Trace
GAISLER_CAN_OC_ACC	CAN_OC register accesses
GAISLER_CAN_OC_RXPACKET	CAN_OC received messages
GAISLER_CAN_OC_TXPACKET	CAN_OC transmitted messages
GAISLER_CAN_OC_ACK	CAN_OC acknowledgements
GAISLER_CAN_OC_IRQ	CAN_OC interrupts
all	Set all debug flags for the core
clean	Set none of the debug flags for the core
list	List the current setting of the debug flags for the core

### 8.8.4. Packet server

Each CAN\_OC core can be configured independently as a packet server or client using either `-can_ocX_server` or `-can_ocX_connect`. When acting as a server the core can only accept a single connection.

### 8.8.5. CAN packet server protocol

The protocol used to communicate with the packet server is described below. Four different types of packets are defined according to the table below.

Table 8.13. CAN packet types

Type	Value
Message	0x00
Error counter	0xFD
Acknowledge	0xFE
Acknowledge config	0xFF

#### 8.8.5.1. CAN message packet format

Used to send and receive CAN messages.

31

0

0x0	LENGTH
31:0	LENGTH, specifies the length of the rest of the packet

CAN message

Byte #	Description	Bits (MSB-LSB)							
		7	6	5	4	3	2	1	0
4	Protocol ID = 0	Prot ID 7-0							
5	Control	FF	RTR	-	-	DLC (max 8 bytes)			
6-9	ID (32 bit word in network byte order)	ID 10-0 (bits 31 - 11 ignored for standard frame format) ID 28-0 (bits 31-29 ignored for extended frame format)							
10-17	Data byte 1 - DLC	Data byte <i>n</i> 7-0							

Figure 8.9. CAN message packet format

### 8.8.5.2. Error counter packet format

Used to write the RX and TX error counter of the modelled CAN interface.

31

0

0x0	LENGTH
31:0	LENGTH, specifies the length of the rest of the packet

Error counter packet

Byte #	Field	Description
4	Packet type	Type of packet, 0xFD for error counter packets
5	Register	0 - RX error counter, 1 - TX error counter
6	Value	Value to write to error counter

Figure 8.10. Error counter packet format

### 8.8.5.3. Acknowledge packet format

If the acknowledge function has been enabled through the start up option or command the CAN interface will wait for an acknowledge packet each time it transmits a message. To enable the CAN receiver to send acknowledge packets (either NAK or ACK) an acknowledge configuration packet must be sent. This is done automatically by the CAN interface when **can\_ocX\_ack** is issued.

31

0

0x0	LENGTH
31:0	LENGTH, specifies the length of the rest of the packet


Acknowledge packet

Byte #	Field	Description
4	Packet type	Type of packet, 0xFE for acknowledge packets
5	Ack payload	0 - No acknowledge, 1 - Acknowledge

Figure 8.11. Acknowledge packet format

**8.8.5.4. Acknowledge packet format**

This packet is used for enabling/disabling the transmission of acknowledge packets and their payload (ACK or NAK) by the CAN receiver. The CAN transmitter will always wait for an acknowledge if started with - can\_ocX\_ack or if the **can\_ocX\_ack** command has been issued.



Acknowledge configuration packet

Byte #	Field	Description	
4	Packet type	Type of packet, 0xFF for acknowledge configuration packets	
5	Ack configuration	bit 0	Unused
		bit 1	Ack packet enable, 1 - enabled, 0 - disabled
		bit 2	Set ack packet payload, 1 - ACK, 0 - NAK

*Figure 8.12. Acknowledge configuration packet format*

## 9. Cobham UT700 emulation

To emulate the UT700 chip the `-ut700` should be used. That sets up parameters for core TSIM2 to match UT700 and sets snooping as non-functional. In addition, the UT700 loadable AHB module implements emulation models for additional cores of the UT700. Apart from an overview of what TSIM supports for UT700 emulation, this chapter is mainly about the UT700 AHB module.

The following table lists which cores in the UT700 are modelled by TSIM or not. Some supported cores are modelled by the core TSIM2 and some in the UT700 AHB module. The table contains some notes of some unsupported features for otherwise supported cores, but is not necessarily exhaustive in this respect. See Chapter 4 for details on the builtin simulation models and the rest of the chapter for the AHB module models.

Table 9.1. Simulation models for UT700

Core	Status	Notes
LEON3FT	Supported by core TSIM2	Only one CPU is modelled. No FT features are modelled.
GRFPU	Supported by core TSIM2	
AHBSTAT	Supported by core TSIM2	
APBCTRL	Supported by core TSIM2	
APBUART	Supported by core TSIM2	
FTMCTRL	Supported by core TSIM2	No FT features are modelled
GPTIMER	Supported by core TSIM2	
IRQMP	Supported by core TSIM2	
CAN_OC	Supported by AHB module	
GRETH	Supported by AHB module	
GRGPIO	Supported by AHB module	
GRPCI	Supported by AHB module	Including DMA controller
GRSPW	Supported by AHB module	
SPICTRL	Supported by AHB module	
CLKGATE	Not supported	
GR1553B	Not supported	
GRTC	Not supported	
GRTM	Not supported	
AHBJTAG	Not supported	Debug link
AHBUART	Not supported	Debug link
DSU3	Not supported	Debug unit

TSIM supports running several AHB modules. User defined models for unsupported cores can be used in parallel with the UT700 AHB module. User defined models can also override the simulation models in the UT700 AHB module.

### 9.1. Overview of the UT700 AHB module

The UT700 AHB module is a loadable AHB module that implements UT700 peripherals in addition to what is emulated by core TSIM as listed in Table 9.1. The interfaces are modelled at packet/transaction/message level and provides an easy way to connect the simulated UT700 to a larger simulation framework. See also Section 5.4.1 on some limitations of some features when using this module. The UT700 AHB module is only supported for TSIM2 LEON3.

The following files are delivered with the UT700 TSIM module:

Table 9.2. Files delivered with the UT700 TSIM module

File	Description
ut700/linux/ut700.so	UT700 AHB module for Linux
ut700/win32/ut700.dll	UT700 AHB module for Windows
ut700/examples/input	The input directory contains two examples of PCI user modules
ut700/examples/input/README.txt	Description of the user module examples
ut700/examples/input/Makefile	Makefile for building the user modules
ut700/examples/input/pci.c	PCI user module example that makes UT700 PCI initiator accesses
ut700/examples/input/pci_target.c	PCI user module example that makes UT700 PCI target accesses
ut700/examples/input/ut700inputprovider.h	Interface between the UT700 module and the user defined PCI module
ut700/examples/input/pci_input.h	UT700 PCI input provider definitions
ut700/examples/input/input.h	Generic input provider definitions
ut700/examples/input/tsim.h	TSIM interface definitions
ut700/examples/input/end.h	Defines the endian of the local machine
ut700/examples/test	The test directory contains tests that can be executed in TSIM
ut700/examples/test/README.txt	Description of the tests
ut700/examples/test/Makefile	Makefile for building the tests
ut700/examples/test/cansend.c	CAN transmission test
ut700/examples/test/canrec.c	CAN reception test
ut700/examples/test/pci.c	PCI interface test
ut700/examples/test/pcitest.h	Header file for PCI test

## 9.2. Loading the module

The module is loaded using the TSIM2 option `-ahbm`. A user input module for SPI, GPIO and PCI can optionally be declared, between `-designinput` and `-designinputend` options. For example:

On Linux:

```
tsim-leon3 -ut700 -ahbm ut700/linux/ut700.so
           -designinput ./input.so -designinputend
```

On Windows:

```
tsim-leon3 -ut700 -ahbm ut700/win32/ut700.dll
           -designinput input.dll -designinputend
```

The option `-ut700` needs to be given to TSIM to enable the UT700 processor configuration. The above line loads the UT700 AHB module `ut700.so` which in turn loads the user user input module `./input.so`. The user input module `./input.so` communicates with `ut700.so` using the user module interface described in `ut700inputprovider.h`, while `ut700.so` communicates with TSIM via the AHB interface.

Example user input modules can be found in `ut700/examples/input/`.

### 9.2.1. User input module interface

The SPI, GPIO and PCI models in the UT700 module uses a user supplied user input module, in the form of a dynamic loadable library, that models the outside world. This section describes the general interface for hooking



up the user module to the UT700 module. The details on the interfaces to the particular cores, see their respective sections.

A user supplied dynamic library should expose a public symbol `ut700inputsystem` of type `struct ut700_subsystem *`. The struct `ut700_subsystem` is defined in `ut700inputprovider.h` as:

```
struct ut700_subsystem {
    void (*ut700_inp_setup) (int id,
                             struct ut700_inp_layout * l,
                             char **argv, int argc);
    void (*ut700_inp_restart) (int id,
                               struct ut700_inp_layout * l);
    struct sim_interface *simif;
};
```

The callback `ut700_inp_restart` will be called every time the simulator restarts. At initialization the callback `ut700_inp_setup` will be called once, supplied with a pointer to structure `struct ut700_inp_layout` defined in `ut700inputprovider.h`.

```
struct ut700_inp_layout {
    struct grpci_input grpci;
    struct gpio_input gpio;
    struct spi_input spi;
};
```

The user module can access the global TSIM struct `sim_interface` structure through the `simif` member. See Chapter 5 for more details.

The user supplied dynamic library should, in its `ut700_inp_setup` function, “claim” the input structs it uses using the `INPUT_CLAIM` macro. For example `INPUT_CLAIM(l->gpio)` as in the example below.

A user supplied dynamic library that only sets up a model for GPIO could look like this:

```
#include <stdio.h>
#include <string.h>
#include "tsim.h"
#include "ut700inputprovider.h"

extern struct ut700_subsystem *ut700inputsystem;
static struct ut700_inp_layout *lay = 0;

static void Change(struct gpio_input *ctrl) {
    ...
}

int gpioout(struct gpio_input *ctrl, unsigned int out) {
    ...
}

static void ut700_inp_setup (int id,
                             struct ut700_inp_layout * l,
                             char **argv, int argc) {
    lay = l;
    printf("User-dll: ut700_inp_setup:Claiming %s\n", l->gpio._b.name);
    INPUT_CLAIM(l->gpio);
    l->gpio.gpioout = gpioout;
    ut700inputsystem->simif->event(Change, (unsigned long)&l->gpio, 10000000);
}

static struct ut700_subsystem ut700_gpio = {
    ut700_inp_setup, 0, 0
};

struct ut700_subsystem *ut700inputsystem = &ut700_gpio;
```

A Makefile that would build a user supplied dynamic library `gpio.(dll|so)` could look like this:

```
M_DLL_FIX=$(if $(strip $(shell uname|grep MINGW32)),dll,so)
M_LIB=$(if $(strip $(shell uname|grep MINGW32)),-lws2_32 -luser32 -lkernel32 -lwinmm,)

all: gpio.$(M_DLL_FIX)

gpio.$(M_DLL_FIX) : gpio.o
$(CC) -shared -g gpio.o -o gpio.$(M_DLL_FIX) $(M_LIB)
```

```

gpio.o:  gpio.c
$(CC) -fPIC -c -g -O0 gpio.c -o gpio.o

clean:
-rm -f *.o *.so

```

The user can then specify the user module to be loaded by the ut700.so AHB module using the `-designinput` and `-designinputend` command line options. The first argument after `-designinput` is the user module. Arguments after that are passed to the user input module in the call to `ut700_inp_setup`.

For example: `-designinput ut700/examples/input/gpio.so -gpioverbose -designinputend` will specify that the example user input module `gpio.so` should be used and that it should receive the argument `-gpioverbose`.

### 9.3. Debugging

To enable printout of debug information the `-ut700_dbgon flag` switch can be used. Alternatively one can issue the `ut700_dbgon flag` command on the TSIM2 command line to toggle the on/off state of a flag. The debug flags that are available are described for each core in the following sections and can be listed by `ut700_dbgon help`.

Many cores also have their own debug commands on the format `coreX_dbg` that targets single cores instead of all of one kind and that have support to set all or none of the debug flags options and list the current setting for the debug flags. See the sections on the respective cores for details.

### 9.4. 10/100 Mbps Ethernet Media Access Controller interface

The Ethernet core simulation model is designed to functionally model the 10/100 Ethernet MAC available in the UT700. For core details and register specification please see the UT700 manual.

The following features are supported:

- Direct Memory Access
- Interrupts

#### 9.4.1. Start up options

*Ethernet core start up options*

```
-grethconnect host[:port]
```

Connect Ethernet core to a packet server at the specified host and port. Default port is 2224.

#### 9.4.2. Commands

*Ethernet core TSIM commands*

```
greth_connect host[:port]
```

Connect Ethernet core to a packet server at the specified host and port. Default port is 2224.

```
greth_status
```

Print Ethernet register status

#### 9.4.3. Debug flags

The following debug flags are available for the Ethernet interface. Use the them in conjunction with the `ut700_dbgon` command to enable different levels of debug information.

*Table 9.3. Ethernet debug flags*

Flag	Trace
GAISLER_GRETH_ACC	GRETH accesses
GAISLER_GRETH_L1	GRETH accesses verbose
GAISLER_GRETH_TX	GRETH transmissions
GAISLER_GRETH_RX	GRETH reception

Flag	Trace
GAISLER_GRETH_RXPACKET	GRETH received packets
GAISLER_GRETH_RXCTRL	GRETH RX packet server protocol
GAISLER_GRETH_RXBDCTRL	GRETH RX buffer descriptors DMA
GAISLER_GRETH_RXBDCTRL	GRETH TX packet server protocol
GAISLER_GRETH_TXPACKET	GRETH transmitted packets
GAISLER_GRETH_IRQ	GRETH interrupts

#### 9.4.4. Ethernet packet server


The simulation model relies on a packet server to receive and transmit the Ethernet packets. The packet server should open a TCP socket which the module can connect to. The Ethernet core is connected to a packet server using the `-grethconnect` start-up parameter or using the `greth_connect` command.

An example implementation of a packet server, named `greth_config`, is included in TSIM distribution. It uses the TUN/TAP interface in Linux, or the WinPcap library on Windows, to connect the GRETH core to a physical Ethernet LAN. This makes it easy to connect the simulated GRETH core to real hardware. It can provide a throughput in the order of magnitude of 500 to 1000 KiB/sec. See its distributed README for usage instructions.

#### 9.4.5. Ethernet packet server protocol


Ethernet data packets have the following format. Note that each packet is prepended with a one word length field indicating the length of the packet to come (including its header).

Packet length at offset 0x0:



31:0    LEN    Length of rest of packet: 4 + number of data bytes

Header at offset 0x4:



31:16    *R*        Reserved for future use. Must be set to 0.

15:8     IPID     IP core ID: 1 for Ethernet

7:5     TYPE    Packet type: 0 for data packets

4:0     *R*        Reserved for future use. Must be set to 0.

Offset 0x8: The rest of the packet is the encapsulated Ethernet packet

*Figure 9.1. Ethernet data packet*

### 9.5. SpaceWire interface with RMAP support

The UT700 AHB module contains 4 GRSPW2 cores which models the GRSPW2 cores available in the UT700. For core details and register specification please see the UT700 manual.

Supported features include:

- Transmission and reception of SpaceWire packets
- Transmission and reception of Time codes
- RMAP
- Server side link state model

- Link errors
- Link error injection

All GRSPW2 register fields with underlying functionality in the UT700 are supported except for:

- The link model is only in `error reset` state or `run` state.
- The RMAP buffer disable (RD) bit in the control register with underlying functionality is not modelled.
- The port loopback (Loop) bit in the control register with underlying functionality is not modelled.
- The limitations of the No spill (NS) DMA control register as noted in the section on Flow control limitations below.

### 9.5.1. Start up options

*SpaceWire core start up options*

- `grspwX_connect host:port`  
Connect GRPSW core *X* to packet server at specified server and port.
- `grspwX_server port`  
Open a packet server for core *X* on specified port.
- `grspw_spwfreq freq`  
Sets the SpaceWire input clock frequency. Combined with the clock divisor register, this determines the startup frequency and TX frequency.
- `grspw_clkdiv value`  
Sets the reset value for the clock divisor register for all GRSPW2 cores.
- `grspw_tx_max_part_len len`  
Sets up all GRSPW2 cores to transmit any SpaceWire packet longer than *len* in data part packets with no more than *len* bytes of data.
- `grspw_simple 1`  
Set all GRSPW2 cores to “simple mode”. This can be used for backward compatibility with TSIM 2.0.44 and backwards. See the separate section on simple mode for details. Note the needed 1 argument.
- `grspw_simple_rxfreq freq`  
Sets the RX frequency in MHz for all GRSPW2 cores to *freq*. This is only valid together with the `-grspw_simple 1` option.

*X* in the above options has the range 1-4.

### 9.5.2. Commands

*SpaceWire core TSIM commands*

- grspwX\_connect** *host:port*  
Connect GRSPW2 core *X* to packet server at specified server and TCP port.
- grspwX\_server** *port*  
Open a packet server for GRSPW2 core *X* on specified TCP port.
- grspwX\_status**  
Print status for GRSPW2 core *X*.
- grspwX\_dbg** [*argument*]  
Sets, clears, lists, toggles debug options for individual GRSPW2 cores. Using **grspwX\_dbg** without any arguments will list all available options. The **list** argument will list current debug option settings. The **all** argument will turn on all debug options. The **clean** argument will turn off all debug options. Using one of the available debug options as argument will toggle that debug option. See the section below.

*X* in the above commands has the range 1-4.

### 9.5.3. Debug flags

The following debug flags and debug subcommands are available for SpaceWire interfaces. The `GAISLER_GRSPW_*` flags can be used with the **grspwX\_dbg** command to toggle individual flags for individual SpaceWire cores and with the **ut700\_dbgon** command to toggle individual flags for all SpaceWire cores. The subcommands can be used with the **grspwX\_dbg** command to change and list the settings of all flags for individual SpaceWire cores.

Table 9.4. SpaceWire debug flags

Flag	Trace
GAISLER_GRSPW_ACC	GRSPW accesses
GAISLER_GRSPW_RXPACKET	GRSPW received packets
GAISLER_GRSPW_RXCTRL	GRSPW rx protocol
GAISLER_GRSPW_TXPACKET	GRSPW transmitted packets
GAISLER_GRSPW_TXCTRL	GRSPW tx protocol
GAISLER_GRSPW_RMAP	GRSPW RMAP accesses
GAISLER_GRSPW_RMAPPACKET	GRSPW RMAP packet dumps
GAISLER_GRSPW_RMAPPACKDE	GRSPW RMAP packet decoding
GAISLER_GRSPW_DMAERR	GRSPW DMA errors
GAISLER_GRSPW_LINK	Link changes
GAISLER_GRSPW_PART	TX/RX of GRSPW data part packets
all	Set all debug flags for the core
clean	Set none of the debug flags for the core
list	List the current setting of the debug flags for the core

#### 9.5.4. SpaceWire packet server

Each SpaceWire core can be configured independently as a packet server or client using either `-grspwX_server` or `-grspwX_connect`. TCP sockets are used for establishing the connections. When acting as a server the core can only accept a single connection.

A connection should be set up before starting simulation for the first time, and must not be broken after that. Restarting the simulation will not tear down the connection, nor emptying any socket buffers.

The server side contains a link model that gets control information from the models at each end of the link, determines the link state and communicates frequencies and link errors to the two models at each ends of the link. It also supports error injection via two error injection packet types that can be sent from a custom client. See the the following sections for details.

For more flexibility, such as custom routing, an external packet server can be implemented using the protocol specified in the following sections. Each core should then be connected to that server. That server would also have to implement a link model that at least reacts to link control packets and sends out link state packets and RX frequency packets.

#### 9.5.5. SpaceWire packet server protocol

The protocol used to communicate with the packet server is described below. The different types of packets are defined according to the table below.

Table 9.5. Packet types

Type	Value	Direction	Notes
Data part	0	Both	Only when in run state
Time code	1	Both	Only when in run state
Link state	2	Server to client	
Link control	3	Client to server	Must be sent for model to reach run state
RX frequency	4	Server to client	
Error injection	5	Client to server	Optional
Packet error request	6	Client to server	Optional

All packets begin with a 32-bit big endian word length field which specifies the length of the rest of the packet, including header and other fixed fields. For most packet types this length is fixed for the particular type. Apart from the data part packet type, where data follows the header byte-wise, all fields are 32-bit big endian words if not otherwise specified.

All packets received by the GRSPW2 model are handled sequentially, and all packets sent by the GRSPW2 model and the server side link model are supposed to be handled sequentially by the client. SpaceWire packets can be split into multiple data parts, transferred in data part packets. Between such parts other packets such as for time codes, link state changes, link control changes, etc., can be handled. During the simulated time span for the reception of a data part, the receiver will not/should not handle any other packet types. Use the `-grspw_tx_max_part_len` to set up GRSPW2 model to split up SpaceWire packets into data parts in order for such events to be able to happen during the data stream.

**9.5.5.1. Flow control limitations**

Flow control in terms of credit is not modeled between two ends of a link. A transmitter gets no notice if the other end cannot give more credit. If the no-spill bit in the GRSPW2 core is set and an enabled receiving DMA channel has no enabled descriptors, the data part packet will be held on the receiving side until a descriptor is available. Due to the sequential nature of the packet model a link error, time code, etc. will not be handled at all by the GRSPW2 model during this time.

**9.5.5.2. Data part packet format**

A SpaceWire packet is represented by one or more data parts. A data part packet represents one such a part. For the data parts of a multi part SpaceWire packet, only the last data part should have an EOP or EEP end marker, i.e. the *END* field set to 0 or 1. The other parts should have no end marker, i.e. the *END* field set to 2. Each data part is delivered in its entirety or not at all. A link error occurring between data parts on the other hand cuts the SpaceWire packet short and is considered the end of that SpaceWire packet.


A data part packet is sent at the beginning of transmission of the corresponding part of the SpaceWire packet, so that the receiver can start reacting to it as soon as the transmission starts. Therefore, the receiver should delay for the amount of simulated time it takes to receive the part before handling the next packet in the socket.

Packet length at offset 0x0:



31:0    LEN    Length of rest of packet: 4 + number of data bytes in the part

Header at offset 0x4:



31:16    *R*    Reserved for future use. Must be set to 0.

15:8    IPID    IP core ID: 0 for SpaceWire

7:5    TYPE    Packet type: 0 for data part packets

4:2    *R*    Reserved for future use. Must be set to 0.


1:0    END    End marker: 0: Normal End of Packet, 1: Error End of Packet, 2: No end marker

Offset 0x8: The data bytes of the part starts here


*Figure 9.2. SpaceWire data part packet*

**9.5.5.3. Time code packet format**


Packet length at offset 0x0:



Header at offset 0x4:



Payload at offset 0x8:



*Figure 9.3. SpaceWire time code packet*

**9.5.5.4. Link state packet format**

Link state packets are sent out by the server side link model when the link state changes. The only states currently simulated are `Error` `Reset` and `Run`. A link state packet with state `Error` `Reset` can have the `ERROR` field set to an error seen at the receiver. Other link state packets has only `None` in the `ERROR` field.

Packet length at offset 0x0:


31 0



31:0    LEN    Length of rest of packet: 4

Header at offset 0x4:

31 19 18 16 15 8 7 5 4 3 2 0



- 31:19    *R*        Reserved for future use. Must be set to 0.
- 18:16    ERROR    Link error: 0: None, 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8     IPID     IP core ID: 0 for SpaceWire
- 7:5     TYPE    Packet type: 2 for link state packets
- 4:3     *R*        Reserved for future use. Must be set to 0.
- 2:0     LS        Link State: 0: Error reset, 1: Error wait, 2: Ready, 3: Started, 4: Connecting, 5: Run

*Figure 9.4. SpaceWire link state packet*

**9.5.5.5. Link control packet format**

A link control packet must be sent from a client to the server side link model to inform if that side of the link is in start mode, autostart mode, and/or has the link disabled. In addition, the control packet contains information on the startup frequency and the TX frequency that will be used once run state is reached. A new link control packet should be sent from a client any time any of these parameters change.

If the startup frequencies of the two ends differ by more than a factor 1.1/0.9, the link model will reach run state. This limit is chosen based on the limits on timeout periods in the SpaceWire standard that must be within 10% up or down from nominal frequency. So even though the startup frequency should be 10 MHz, run state can be reached if startup frequencies are close enough.



Packet length at offset 0x0:

31 0



31:0    LEN    Length of rest of packet: 12

Header at offset 0x4:

31 16 15 8 7 5 4 3 2 1 0



31:16    *R*    Reserved for future use. Must be set to 0.

15:8    IPID    IP core ID: 0 for SpaceWire

7:5    TYPE    Packet type: 3 for link control packets

4:3    *R*    Reserved for future use. Must be set to 0.


2    AS    Link autostart.

1    LS    Link start.

0    LD    Link disable.

Startup frequency in MHz at offset 0x8:

31 0



31:0    SFREQ    Startup frequency in MHz, big endian IEEE-754 32-bit float

TX frequency in MHz at offset 0xc:

31 0



31:0    TFREQ    TX frequency in MHz, big endian in IEEE-754 32-bit float

*Figure 9.5. SpaceWire link control packet*

**9.5.5.6. RX frequency packet format**

The server side link model sends out this packet type to inform the client of with what frequency the other side transmits with when in run state. A new packet of this type is sent any time the transmitter on the other side changes its TX frequency.

Packet length at offset 0x0:

31 0

LEN
-----

31:0 LEN Length of rest of packet: 8

Header at offset 0x4:

31 16 15 8 7 5 4 0

<i>R</i>	IPID	TYPE	<i>R</i>
----------	------	------	----------

31:16 *R* Reserved for future use. Must be set to 0.

15:8 IPID IP core ID: 0 for SpaceWire

7:5 TYPE Packet type: 4 for rx frequency packets

4:0 *R* Reserved for future use. Must be set to 0.

RX frequency in MHz at offset 0x8:

31 0

RFREQ
-------

31:0 RFREQ RX frequency in MHz, big endian IEEE-754 32-bit float

*Figure 9.6. SpaceWire rx frequency packet*

### 9.5.5.7. Link error injection packet format

A client can send a packet of this kind to the server side link model to request that a link error will occur. The error specified is the link error that is seen at the targeted end. The *OE* bit determines which end of the link is the targeted end, i.e. will see the error.

If the *OE* bit is set to 1, the error will be seen at the receiver of the simulation model on the other end. The simulation model on the client side will see a disconnect error via a link state packet. In order for this error to happen during reception of a SpaceWire packet at the other end, the client can send a data part packet with no end marker followed by a link error injection packet.

If the *OE* bit is set to 0, the error will be seen at the receiver on the client end. The simulation model at the client end will see the requested error via a link state packet. The simulation model at the other end will see a disconnect error. Note that due to the nature of the model, this cannot in general be relied upon to inject an error during the reception of a SpaceWire packet, even if split up in multiple data parts. The link state packet will not be sent by the server side link model until all previous packets have been handled, and the client should handle all other packets queued up before that link state packet can be handled. To inject a link error during the reception of a SpaceWire packet at the client side, the packet error request packet should be used instead.

Packet length at offset 0x0:

31 0

LEN
-----

31:0 LEN Length of rest of packet: 4

Header at offset 0x4:

31 21 20 19 18 16 15 8 7 5 4 0

R	OE	R	ERROR	IPID	TYPE	R
---	----	---	-------	------	------	---

- 31:21 R Reserved for future use. Must be set to 0.
- 20 OE Other end: 1: other end gets the error, 0: my end gets error
- 19 R Reserved for future use. Must be set to 0.
- 18:16 ERROR Link error: 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8 IPID IP core ID: 0 for SpaceWire
- 7:5 TYPE Packet type: 5 for link error injection packets
- 4:0 R Reserved for future use. Must be set to 0.

Figure 9.7. SpaceWire link error injection packet

**9.5.5.8. Packet error request packet format**

A client can send a packet of this kind to the server side link model to request that a link error will occur during reception of a certain data packet by the client. The error specified is the link error that is seen, via a link state packet, by the client as a result. The other side will see a disconnect error. A 64-bit packet number, counting from 0, indicates during which SpaceWire packet sent from the other side to the client the link error should happen. Note that this number is indexing SpaceWire packets, not individual data part packets, and does not take SpaceWire packets sent from the client to the server side into account in the numbering. There can only be one outstanding packet error request per targeted GRSPW2 core at a time.

The **grspwX\_status** command can be issued for the targeted GRSPW2 core to see how many SpaceWire packets have currently been sent by that core. This includes started but aborted SpaceWire packets, due to link error, core reset or active aborting using the Abort TX (AT) bit in the DMA control register of the GRSPW2 core.

Packet length at offset 0x0:


31 0



31:0 LEN Length of rest of packet: 16

Header at offset 0x4:

31 19 18 16 15 8 7 5 4 0



- 31:19 R Reserved for future use. Must be set to 0.
- 18:16 ERROR Link error: 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8 IPID IP core ID: 0 for SpaceWire
- 7:5 TYPE Packet type: 6 for packet error request packets
- 4:0 R Reserved for future use. Must be set to 0.

Packet number to request error for, most significant word at offset 0x8:


31 0



31:0 MSW Bits 63:32 of unsigned 64-bit big endian integer

Packet number to request error for, least significant word at offset 0xc:


31 0



31:0 LSW Bits 31:0 of unsigned 64-bit big endian integer

Reserved field at offset 0x10:

31 0



31:0 R Reserved for future use. Must be set to 0.

Figure 9.8. SpaceWire packet error request packet

### 9.5.6. Simple Mode

For backwards compatibility with TSIM 2.0.44 and older, the GRSPW2 models can be set up in “simple mode” with the `-grspw_simple 1` option. This makes the following changes to the simulation model for all GRSPW2 cores:

- The *only* supported packet types are data part packets and time code packets. The model sends out no other packet types and accepts no other packet types.
- Data part packets should *always* contain full SpaceWire packets. The `-grspw_tx_max_part_len` should not be used together with simple mode and data part packets without end marker should be sent to a GRSPW2 model when using simple mode.
- The link state that a GRSPW2 core perceives is solely determined by its own link control setting. The other end is assumed to try to start the link. In other words, run state is achieved once the GRSPW2 is set to start or autostart without having link disable set. Moreover, startup frequencies are ignored and run state is achieved without any delay.

- The RX frequency is determined primarily by the `-grspw_simple_rxfreq` option. If that is not used, the RX frequency is taken by the `-grspw_spwfreq` option. If none of those options are set the CPU frequency is used. No cases take any clock divisors into account. The TX frequency is determined in the usual way as when not in simple mode, which includes taking the clock divisor register into account.

## 9.6. PCI initiator/target interface

The UT700 AHB module models the PCI core available in the UT700 ASIC. For core details and register specification please see the UT700 manual.

### 9.6.1. Connecting a user PCI model with the UT700 module

See Section 9.2 for details on how to connect the user PCI model to the UT700 module.

### 9.6.2. Commands

*PCI Commands*

#### **pci\_status**

Print status for the PCI core

### 9.6.3. Debug flags

The following debug flags are available for the PCI interface. Use them in conjunction with the `ut700_dbgon` command to enable different levels of debug information.

*Table 9.6. PCI interface debug flags*

Flag	Trace
GAISLER_GRP_CI_ACC	AHB accesses to/from PCI core
GAISLER_GRP_CI_REGACC	GRPCI APB register accesses
GAISLER_GRP_CI_DMA_REGACC	PCIDMA APB register accesses
GAISLER_GRP_CI_DMA	GRPCI DMA accesses on the AHB bus
GAISLER_GRP_CI_TARGET_ACC	GRPCI target accesses
GAISLER_GRP_CI_INIT	Print summary on startup

### 9.6.4. PCI bus model API

The structure `struct grpci_input` models the PCI bus. It is defined as:

```
struct grpci_input {
    struct input_inp_b;

    int (*acc)(struct grpci_input *ctrl, int cmd, unsigned int addr,
              unsigned int *data, unsigned int *abort, unsigned int *ws);

    int (*target_acc)(struct grpci_input *ctrl, int cmd, unsigned int addr,
                    unsigned int *data, unsigned int *mexc);
};
```

The `acc` callback should be set by the PCI user module at startup. It is called by the UT700 module whenever it reads/writes as a PCI bus master.

*Table 9.7. acc callback parameters*

Parameter	Description
<code>cmd</code>	Command to execute, see Section 9.6.2 details.
<code>addr</code>	PCI address.
<code>data</code>	Data buffer. The user module should return the read data in <code>*data</code> for read commands or write the data in <code>*data</code> for write commands.

Parameter	Description
wsiz	0: 8-bit access 1: 16-bit access, 2: 32-bit access. Is always 2 for read accesses.
ws	Set <i>*ws</i> to the number of PCI clocks it takes to complete the transaction.
abort	Set <i>*abort</i> to 1 to generate target abort, or 0 otherwise.

The return value of `acc` determines if the transaction terminates successfully (1, `GRPCI_ACC_OK`) or with master abort (0, `GRPCI_ACC_MASTER_ABORT`).

The callback `target_acc` is installed by the UT700 AHB module. The PCI user dynamic library can call this function to initiate an access to the UT700 PCI target.

Table 9.8. `target_acc` parameters

Parameter	Description
cmd	Command to execute, see Section 9.6.2 for details. I/O cycles are not supported by the UT700 target.
addr	PCI address. Should always be word aligned for read accesses.
data	Data buffer. The read data is returned in <i>*data</i> for read commands or the data in <i>*data</i> is written for write commands.
wsiz	0: 8-bit access 1: 16-bit access, 2: 32-bit access. Should always be 2 for read accesses.
mexc	0 if access is successful, 1 in case of target abort.

If the address matched `MEMBAR0`, `MEMBAR1` or `CONFIG` `target_acc` will return 1 otherwise 0.

See the `ut700/examples/input` for example implementations.

## 9.7. GPIO interface

### 9.7.1. Connecting a user GPIO model with the UT700 module

See Section 9.2 for details on how to connect the user GPIO model to the UT700 module.

### 9.7.2. Commands

#### GPIO Commands

##### **gpio0\_status**

Print status for the GPIO core.

##### **gpio0\_dbg** [*flag* / *subcommand*]

Toggle, set, clear, list debug flags for the GPIO core.

### 9.7.3. Debug flags

The following debug flags and debug subcommands are available for GPIO interfaces. The `GAISLER_GPIO_*` flags can be used with the `gpio0_dbg` command to toggle individual flags for individual GPIO cores and with the `ut700_dbg` command to toggle individual flags for all GPIO cores. The subcommands can be used with the `gpio0_dbg` command to change and list the settings of all flags for individual GPIO cores.

Table 9.9. GPIO debug flags

Flag/subcommand	Trace
<code>GAISLER_GPIO_ACC</code>	GPIO register accesses
<code>GAISLER_GPIO_IRQ</code>	GPIO interrupts
<code>all</code>	Set all GPIO debug flags for the core

Flag/subcommand	Trace
clean	Set none of the GPIO debug flags for the core
list	List the current setting of the debug flags for the core

### 9.7.4. GPIO model API

The structure `struct gpio_input` models the GPIO pins. It is defined as:

```
/* GPIO input provider */
struct gpio_input {
    struct input_inp _b;
    int (*gpioout)(struct gpio_input *ctrl, unsigned int out);
    int (*gpioin) (struct gpio_input *ctrl, unsigned int in);
};
```

The `gpioout` callback should be set by the user module at startup. The `gpioin` callback is set by the UT700 AHB module. The `gpioout` callback is called by the UT700 module whenever a GPIO output pin changes. The `gpioin` callback is called by the user module when the input pins should change. Typically the user module would register an event handler at a certain time offset and call `gpioin` from within the event handler.

Table 9.10. *gpioout* callback parameters

Parameter	Description
out	The values of the output pins

Table 9.11. *gpioin* callback parameters

Parameter	Description
in	The input pin values

The return value of `gpioin/gpioout` is ignored.

See the `ut700/examples/input` for an example implementation.

## 9.8. CAN interface

The UT700 AHB module contains 2 CAN\_OC cores which models the CAN\_OC cores available in the UT700. For core details and register specification please see the UT700 manual.

### 9.8.1. Start up options

*CAN core start up options*

- can\_ocX\_connect host:port  
Connect CAN\_OC core X to packet server to specified server and TCP port.
- can\_ocX\_server port  
Open a packet server for CAN\_OC core X on specified TCP port.
- can\_ocX\_ack [0|1]  
Specifies whether the CAN\_OC core will wait for a acknowledgment packet on transmission. This option must be put after `-can_ocX_connect`.

X in the above options is in the range 1-2.

### 9.8.2. Commands

*CAN core TSIM commands*

- can\_ocX\_connect host:port**  
Connect CAN\_OC core X to packet server to specified server and TCP port.

**can\_ocX\_server port**

Open a packet server for CAN\_OC core X on specified TCP port.

**can\_ocX\_ack <0|1>**

Specifies whether the CAN\_OC core will wait for a acknowledgment packet on transmission. This command should only be issued after a connection has been established.

**can\_ocX\_status**

Prints out status information for the CAN\_OC core.

**can\_ocX\_dbg**

Toggle, set, clear, list debug flags for the CAN\_OC core.

X in the above commands is in the range 1-2.

### 9.8.3. Debug flags

The following debug flags and debug subcommands are available for CAN interfaces. The *GAISLER\_CAN\_OC\_\** flags can be used with the **can\_ocX\_dbg** command to toggle individual flags for individual CAN\_OC cores and with the **ut700\_dbg** command to toggle individual flags for all CAN\_OC cores. The subcommands can be used with the **can\_ocX\_dbg** command to change and list the settings of all flags for individual CAN\_OC cores.

Table 9.12. CAN debug flags

Flag	Trace
GAISLER_CAN_OC_ACC	CAN_OC register accesses
GAISLER_CAN_OC_RXPACKET	CAN_OC received messages
GAISLER_CAN_OC_TXPACKET	CAN_OC transmitted messages
GAISLER_CAN_OC_ACK	CAN_OC acknowledgements
GAISLER_CAN_OC_IRQ	CAN_OC interrupts
all	Set all debug flags for the core
clean	Set none of the debug flags for the core
list	List the current setting of the debug flags for the core

### 9.8.4. Packet server

Each CAN\_OC core can be configured independently as a packet server or client using either `-can_ocX_server` or `-can_ocX_connect`. When acting as a server the core can only accept a single connection.

### 9.8.5. CAN packet server protocol

The protocol used to communicate with the packet server is described below. Four different types of packets are defined according to the table below.

Table 9.13. CAN packet types

Type	Value
Message	0x00
Error counter	0xFD
Acknowledge	0xFE
Acknowledge config	0xFF

#### 9.8.5.1. CAN message packet format

Used to send and receive CAN messages.



31

0

0x0	LENGTH
31:0	LENGTH, specifies the length of the rest of the packet

CAN message

Byte #	Description	Bits (MSB-LSB)							
		7	6	5	4	3	2	1	0
4	Protocol ID = 0	Prot ID 7-0							
5	Control	FF	RTR	-	-	DLC (max 8 bytes)			
6-9	ID (32 bit word in network byte order)	ID 10-0 (bits 31 - 11 ignored for standard frame format) ID 28-0 (bits 31-29 ignored for extended frame format)							
10-17	Data byte 1 - DLC	Data byte <i>n</i> 7-0							

Figure 9.9. CAN message packet format

### 9.8.5.2. Error counter packet format

Used to write the RX and TX error counter of the modelled CAN interface.

31

0

0x0	LENGTH
31:0	LENGTH, specifies the length of the rest of the packet

Error counter packet

Byte #	Field	Description
4	Packet type	Type of packet, 0xFD for error counter packets
5	Register	0 - RX error counter, 1 - TX error counter
6	Value	Value to write to error counter

Figure 9.10. Error counter packet format

### 9.8.5.3. Acknowledge packet format

If the acknowledge function has been enabled through the start up option or command the CAN interface will wait for an acknowledge packet each time it transmits a message. To enable the CAN receiver to send acknowledge packets (either NAK or ACK) an acknowledge configuration packet must be sent. This is done automatically by the CAN interface when **can\_ocX\_ack** is issued.

31

0

0x0	LENGTH
31:0	LENGTH, specifies the length of the rest of the packet

Acknowledge packet

Byte #	Field	Description
4	Packet type	Type of packet, 0xFE for acknowledge packets
5	Ack payload	0 - No acknowledge, 1 - Acknowledge

Figure 9.11. Acknowledge packet format

### 9.8.5.4. Acknowledge packet format

This packet is used for enabling/disabling the transmission of acknowledge packets and their payload (ACK or NAK) by the CAN receiver. The CAN transmitter will always wait for an acknowledge if started with `-can_ocX_ack` or if the `can_ocX_ack` command has been issued.

31	0
0x0	LENGTH
31:0	LENGTH, specifies the length of the rest of the packet

Acknowledge configuration packet

Byte #	Field	Description	
4	Packet type	Type of packet, 0xFF for acknowledge configuration packets	
5	Ack configuration	bit 0	Unused
		bit 1	Ack packet enable, 1 - enabled, 0 - disabled
		bit 2	Set ack packet payload, 1 - ACK, 0 - NAK

Figure 9.12. Acknowledge configuration packet format

## 9.9. SPI interface

### 9.9.1. Connecting a user SPI model with the UT700 module

See Section 9.2 for details on how to connect the user SPI model to the UT700 module.

### 9.9.2. Commands

#### SPI Commands

##### `spi0_status`

Print status for the SPI core.

##### `spi0_dbg [flag/subcommand]`

Toggle, set, clear, list debug flags for the SPI core.

### 9.9.3. Debug flags

The following debug flags and debug subcommands are available for SPI interfaces. The `GAISLER_SPI_*` flags can be used with the `spi0_dbg` command to toggle individual flags for individual SPI cores and with the `ut700_dbgon` command to toggle individual flags for all SPI cores. The subcommands can be used with the `spi0_dbg` command to change and list the settings of all flags for individual SPI cores.

Table 9.14. SPI debug flags

Flag/subcommand	Trace
<code>GAISLER_SPI_ACC</code>	SPI register accesses
<code>GAISLER_SPI_IRQ</code>	SPI interrupts
<code>all</code>	Set all SPI debug flags for the core
<code>clean</code>	Set none of the SPI debug flags for the core
<code>list</code>	List the current setting of the debug flags for the core

### 9.9.4. SPI bus model API

The structure `struct spi_input` models the SPI bus. It is defined as:

```
/* Spi input provider */
```

```

struct spi_input {
    struct input_inp_b;
    int (*spishift)(struct spi_input *ctrl, uint32 select, uint32 bitcnt,
        uint32 out, uint32 *in);
};

```

The spishift callback should be set by the SPI user module at startup. It is called by the UT700 module whenever it shifts a word through the SPI bus.

Table 9.15. spishift callback parameters

Parameter	Description
select	Slave select bits
bitcnt	Number of bits set in the MODE register, if bitcnt is -1 then the operation is not a shift and the call is to indicate a <i>select</i> change, i.e. if the core is disabled.
out	Shift out (tx) data
in	Shift in (rx) data

The return value of spishift is ignored.

See the `ut700/examples/input` directory for an example implementation.

## 10. Cobham Gaisler GR712RC emulation

To emulate the GR712RC chip the `-gr712rc` should be used. That sets up parameters for core TSIM2 to match GR712RC. In addition, the GR712RC loadable AHB module implements emulation models for additional cores of the GR712RC. Apart from an overview of what TSIM supports for GR712RC emulation, this chapter is mainly about the GR712RC AHB module.

The following table lists which cores in the GR712RC are modelled by TSIM or not. Some supported cores are modelled by the core TSIM2 and some in the GR712RC AHB module. The table contains some notes of some unsupported features for otherwise supported cores, but is not necessarily exhaustive in this respect. See Chapter 4 for details on the builtin simulation models and the rest of the chapter for the AHB module models.

Table 10.1. Simulation models for GR712RC

Core	Status	Notes
LEON3FT	Supported by core TSIM2	Only one CPU is modelled. No FT features are modelled.
GRFPU	Supported by core TSIM2	
AHBSTAT	Supported by core TSIM2	
APBCTRL	Supported by core TSIM2	
APBUART	Supported by core TSIM2	
FTMCTRL	Supported by core TSIM2	No FT features are modelled
GPTIMER	Supported by core TSIM2	
GRTIMER	Supported by core TSIM2	
IRQMP	Supported by core TSIM2	
CAN_OC	Supported by AHB module	
FTAHBRAM	Supported by AHB module	No FT features are modelled.
GRETH	Supported by AHB module	
GRGPIO	Supported by AHB module	
GRSPW2	Supported by AHB module	
SPICTRL	Supported by AHB module	
CANMUX	Dummy in AHB module	Functionality-less registers only
CLKGATE	Dummy in AHB module	Functionality-less registers only
GRGPREG	Dummy in AHB module	Functionality-less registers only
B1553BRM	Not supported	
GRASCS	Not supported	
GRSLINK	Not supported	
GRTC	Not supported	
GRTM	Not supported	
I2CMST	Not supported	
AHBJTAG	Not supported	Debug link
DSU3	Not supported	Debug unit

TSIM supports running several AHB modules. User defined models for unsupported cores can be used in parallel with the GR712RC AHB module. User defined models can also override the simulation models (such as for dummy models) in the GR712RC AHB module.

### 10.1. Overview of the GR712RC AHB module

The GR712RC AHB module is a loadable AHB module that implements GR712RC peripherals in addition to what is emulated by core TSIM as listed in Table 10.1. The interfaces are modelled at packet/transaction/message

level and provides an easy way to connect the simulated GR712RC to a larger simulation framework. See also Section 5.4.1 on some limitations of some features when using this module. The GR712RC AHB module is only supported for TSIM2 LEON3.

The following files are delivered with the GR712RC TSIM module:

Table 10.2. Files delivered with the GR712RC TSIM module

File	Description
gr712/linux/gr712.so	GR712RC AHB module for Linux
gr712/win32/gr712.dll	GR712RC AHB module for Windows
gr712/examples/input	The input directory contains two examples of user modules
gr712/examples/input/README.txt	Description of the user module examples
gr712/examples/input/Makefile	Makefile for building the user modules
gr712/examples/input/spi.c	SPI user module example emulating a Intel SPI flash
gr712/examples/input/gpio.c	GPIO user module emulating GPIO bit toggle
gr712/examples/input/gr712inputprovider.h	Interface between the GR712RC module and the user module

## 10.2. Loading the module

The module is loaded using the TSIM2 option `-ahbm`. A user input module for SPI and GPIO can optionally be declared, between `-designinput` and `-designinputend` options. For example:

On Linux:

```
tsim-leon3 -gr712rc -ahbm gr712/linux/gr712.so
          -designinput ./input.so -designinputend
```

On Windows:

```
tsim-leon3 -gr712rc -ahbm gr712/win32/gr712.dll
          -designinput input.dll -designinputend
```

The option `-gr712rc` needs to be given to TSIM to enable the GR712RC processor configuration. The above line loads the GR712RC AHB module `gr712.so` which in turn loads the user input module `./input.so`. The user input module `./input.so` communicates with `gr712.so` using the user module interface described in `gr712inputprovider.h`, while `gr712.so` communicates with TSIM via the AHB interface.

Example user input modules can be found in `gr712/examples/input/`.

### 10.2.1. User input module interface

The SPI and GPIO models in the GR712RC module uses a user supplied user input module, in the form of a dynamic loadable library, that models the outside world. This section describes the general interface for hooking up the user module to the GR712RC module. The details on the interfaces to the particular cores, see their respective sections.

A user supplied dynamic library should expose a public symbol `gr712inputsystem` of type `struct gr712_subsystem *`. The struct `gr712_subsystem` is defined in `gr712inputprovider.h` as:

```
struct gr712_subsystem {
    void (*gr712_inp_setup) (int id,
                           struct gr712_inp_layout * l,
                           char **argv, int argc);
    void (*gr712_inp_restart) (int id,
                              struct gr712_inp_layout * l);
    struct sim_interface *simif;
};
```

The callback `gr712_inp_restart` will be called every time the simulator restarts. At initialization the callback `gr712_inp_setup` will be called once, supplied with a pointer to structure `struct gr712_inp_layout` defined in `gr712inputprovider.h`.

The user module can access the global TSIM `struct sim_interface` structure through the `simif` member. See Chapter 5 for more details.

The user supplied dynamic library should, in its `gr712_inp_setup` function, “claim” the input structs it uses using the `INPUT_CLAIM` macro. For example `INPUT_CLAIM(l->gpio[0])` as in the example below.

A user supplied dynamic library that only sets up a model for GPIO could look like this:

```
#include <stdio.h>
#include <string.h>
#include "tsim.h"
#include "gr712inputprovider.h"

extern struct gr712_subsystem *gr712inputsystem;
static struct gr712_inp_layout *lay = 0;

static void Change(struct gpio_input *ctrl) {
    ...
}

int gpioout(struct gpio_input *ctrl, unsigned int out) {
    ...
}

static void gr712_inp_setup (int id,
                            struct gr712_inp_layout * l,
                            char **argv, int argc) {
    lay = l;
    printf("User-dll: gr712_inp_setup:Claiming %s\n", l->gpio[0]._b.name);
    INPUT_CLAIM(l->gpio[0]);
    l->gpio[0].gpioout = gpioout;
    gr712inputsystem->simif->event(Change, (unsigned long)&l->gpio[0], 10000000);
}

static struct gr712_subsystem gr712_gpio = {
    gr712_inp_setup, 0, 0
};

struct gr712_subsystem *gr712inputsystem = &gr712_gpio;
```

A Makefile that would build a user supplied dynamic library `gpio.(dll|so)` could look like this:

```
M_DLL_FIX=$(if $(strip $(shell uname|grep MINGW32)),dll,so)
M_LIB=$(if $(strip $(shell uname|grep MINGW32)),-lws2_32 -luser32 -lkernel32 -lwinmm,)

all: gpio.$(M_DLL_FIX)

gpio.$(M_DLL_FIX) : gpio.o
$(CC) -shared -g gpio.o -o gpio.$(M_DLL_FIX) $(M_LIB)

gpio.o: gpio.c
$(CC) -fPIC -c -g -O0 gpio.c -o gpio.o

clean:
-rm -f *.o *.so
```

The user can then specify the user module to be loaded by the `gr712.so` AHB module using the `-designinput` and `-designinputend` command line options. The first argument after `-designinput` is the user module. Arguments after that are passed to the user input module in the call to `gr712_inp_setup`.

For example: `-designinput gr712/examples/input/gpio.so -gpioverbose -designinputend` will specify that the example user input module `gpio.so` should be used and that it should receive the argument `-gpioverbose`.

### 10.3. Debugging

To enable printout of debug information the `-gr712_dbgon flag` switch can be used. Alternatively one can issue the `gr712_dbgon flag` command on the TSIM2 command line to toggle the on/off state of a flag. The debug flags that are available are described for each core in the following sections and can be listed by `gr712_dbgon help`.

Many cores also have their own debug commands on the format **coreX\_dbg** that targets single cores instead of all of one kind and that have support to set all or none of the debug flags options and list the current setting for the debug flags. See the sections on the respective cores for details.

## 10.4. CAN interface

The GR712RC AHB module contains 2 CAN\_OC cores which models the CAN\_OC cores available in the GR712RC. For core details and register specification please see the GR712RC manual.

### 10.4.1. Start up options

*CAN core start up options*

- can\_ocX\_connect host:port  
Connect CAN\_OC core X to packet server to specified server and TCP port.
- can\_ocX\_server port  
Open a packet server for CAN\_OC core X on specified TCP port.
- can\_ocX\_ack [0|1]  
Specifies whether the CAN\_OC core will wait for a acknowledgment packet on transmission. This option must be put after -can\_ocX\_connect .

X in the above options is in the range 0-1.

### 10.4.2. Commands

*CAN core TSIM commands*

- can\_ocX\_connect host:port**  
Connect CAN\_OC core X to packet server to specified server and TCP port.
- can\_ocX\_server port**  
Open a packet server for CAN\_OC core X on specified TCP port.
- can\_ocX\_ack <0|1>**  
Specifies whether the CAN\_OC core will wait for a acknowledgment packet on transmission. This command should only be issued after a connection has been established.
- can\_ocX\_status**  
Prints out status information for the CAN\_OC core.
- can\_ocX\_dbg**  
Toggle, set, clear, list debug flags for the CAN\_OC core.

X in the above commands is in the range 0-1.

### 10.4.3. Debug flags

The following debug flags and debug subcommands are available for CAN interfaces. The *GAISLER\_CAN\_OC\_\** flags can be used with the **can\_ocX\_dbg** command to toggle individual flags for individual CAN\_OC cores and with the **gr712\_dbgon** command to toggle individual flags for all CAN\_OC cores. The subcommands can be used with the **can\_ocX\_dbg** command to change and list the settings of all flags for individual CAN\_OC cores.

*Table 10.3. CAN debug flags*

Flag	Trace
GAISLER_CAN_OC_ACC	CAN_OC register accesses
GAISLER_CAN_OC_RXPACKET	CAN_OC received messages
GAISLER_CAN_OC_TXPACKET	CAN_OC transmitted messages
GAISLER_CAN_OC_ACK	CAN_OC acknowledgements
GAISLER_CAN_OC_IRQ	CAN_OC interrupts
all	Set all debug flags for the core
clean	Set none of the debug flags for the core
list	List the current setting of the debug flags for the core

#### 10.4.4. Packet server

Each CAN\_OC core can be configured independently as a packet server or client using either `-can_ocX_server` or `-can_ocX_connect`. When acting as a server the core can only accept a single connection.

#### 10.4.5. CAN packet server protocol


The protocol used to communicate with the packet server is described below. Four different types of packets are defined according to the table below.

Table 10.4. CAN packet types

Type	Value
Message	0x00
Error counter	0xFD
Acknowledge	0xFE
Acknowledge config	0xFF

##### 10.4.5.1. CAN message packet format

Used to send and receive CAN messages.




CAN message

Byte #	Description	Bits (MSB-LSB)							
		7	6	5	4	3	2	1	0
4	Protocol ID = 0	Prot ID 7-0							
5	Control	FF	RTR	-	-	DLC (max 8 bytes)			
6-9	ID (32 bit word in network byte order)	ID 10-0 (bits 31 - 11 ignored for standard frame format) ID 28-0 (bits 31-29 ignored for extended frame format)							
10-17	Data byte 1 - DLC	Data byte <i>n</i> 7-0							

Figure 10.1. CAN message packet format

##### 10.4.5.2. Error counter packet format

Used to write the RX and TX error counter of the modelled CAN interface.



Error counter packet

Byte #	Field	Description
4	Packet type	Type of packet, 0xFD for error counter packets
5	Register	0 - RX error counter, 1 - TX error counter
6	Value	Value to write to error counter

Figure 10.2. Error counter packet format



### 10.4.5.3. Acknowledge packet format

If the acknowledge function has been enabled through the start up option or command the CAN interface will wait for an acknowledge packet each time it transmits a message. To enable the CAN receiver to send acknowledge packets (either NAK or ACK) an acknowledge configuration packet must be sent. This is done automatically by the CAN interface when `can_ocX_ack` is issued.

	31		0
0x0	LENGTH		
31:0	LENGTH, specifies the length of the rest of the packet		

Acknowledge packet

Byte #	Field	Description
4	Packet type	Type of packet, 0xFE for acknowledge packets
5	Ack payload	0 - No acknowledge, 1 - Acknowledge

*Figure 10.3. Acknowledge packet format*

### 10.4.5.4. Acknowledge configuration packet format

This packet is used for enabling/disabling the transmission of acknowledge packets and their payload (ACK or NAK) by the CAN receiver. The CAN transmitter will always wait for an acknowledge if started with `-can_ocX_ack` or if the `can_ocX_ack` command has been issued.

	31		0
0x0	LENGTH		
31:0	LENGTH, specifies the length of the rest of the packet		

Acknowledge configuration packet

Byte #	Field	Description	
4	Packet type	Type of packet, 0xFF for acknowledge configuration packets	
5	Ack configuration	bit 0	Unused
		bit 1	Ack packet enable, 1 - enabled, 0 - disabled
		bit 2	Set ack packet payload, 1 - ACK, 0 - NAK

*Figure 10.4. Acknowledge configuration packet format*

## 10.5. 10/100 Mbps Ethernet Media Access Controller interface

The Ethernet core simulation model is designed to functionally model the 10/100 Ethernet MAC available in the GR712RC. For core details and register specification please see the GR712RC manual.

The following features are supported:

- Direct Memory Access
- Interrupts

### 10.5.1. Start up options

*Ethernet core start up options*

```
-grethconnect host[:port]
```

Connect Ethernet core to a packet server at the specified host and port. Default port is 2224.

## 10.5.2. Commands

*Ethernet core TSIM commands*

**greth\_connect host[:port]**

Connect Ethernet core to a packet server at the specified host and port. Default port is 2224.

**greth\_status**

Print Ethernet register status

## 10.5.3. Debug flags

The following debug flags are available for the Ethernet interface. Use the them in conjunction with the **gr712\_dbgon** command to enable different levels of debug information.

*Table 10.5. Ethernet debug flags*

Flag	Trace
GAISLER_GRETH_ACC	GRETH accesses
GAISLER_GRETH_L1	GRETH accesses verbose
GAISLER_GRETH_TX	GRETH transmissions
GAISLER_GRETH_RX	GRETH reception
GAISLER_GRETH_RXPACKET	GRETH received packets
GAISLER_GRETH_RXCTRL	GRETH RX packet server protocol
GAISLER_GRETH_RXBDCTRL	GRETH RX buffer descriptors DMA
GAISLER_GRETH_RXBDCTRL	GRETH TX packet server protocol
GAISLER_GRETH_TXPACKET	GRETH transmitted packets
GAISLER_GRETH_IRQ	GRETH interrupts

## 10.5.4. Ethernet packet server

The simulation model relies on a packet server to receive and transmit the Ethernet packets. The packet server should open a TCP socket which the module can connect to. The Ethernet core is connected to a packet server using the `-grethconnect` start-up parameter or using the **greth\_connect** command.

An example implementation of a packet server, named `greth_config`, is included in TSIM distribution. It uses the TUN/TAP interface in Linux, or the WinPcap library on Windows, to connect the GRETH core to a physical Ethernet LAN. This makes it easy to connect the simulated GRETH core to real hardware. It can provide a throughput in the order of magnitude of 500 to 1000 KiB/sec. See its distributed README for usage instructions.

## 10.5.5. Ethernet packet server protocol

Ethernet data packets have the following format. Note that each packet is prepended with a one word length field indicating the length of the packet to come (including its header).

Packet length at offset 0x0:

31 0

LEN
-----

31:0 LEN Length of rest of packet: 4 + number of data bytes

Header at offset 0x4:

31 16 15 8 7 5 4 0

R	IPID	TYPE	R
---	------	------	---

31:16 R Reserved for future use. Must be set to 0.

15:8 IPID IP core ID: 1 for Ethernet

7:5 TYPE Packet type: 0 for data packets

4:0 R Reserved for future use. Must be set to 0.

Offset 0x8: The rest of the packet is the encapsulated Ethernet packet

Figure 10.5. Ethernet data packet

## 10.6. SpaceWire interface with RMAP support

The GR712RC AHB module contains 6 GRSPW2 cores which models the GRSPW2 cores available in the GR712RC. For core details and register specification please see the GR712RC manual.

Supported features include:

- Transmission and reception of SpaceWire packets
- Transmission and reception of Time codes
- RMAP
- Server side link state model
- Link errors
- Link error injection

All GRSPW2 register fields with underlying functionality in the GR712RC are supported except for:

- The link model is only in `error reset` state or `run` state.
- The RMAP buffer disable (RD) bit in the control register with underlying functionality is not modelled.
- The limitations of the No spill (NS) DMA control register as noted in the section on Flow control limitations below.

### 10.6.1. Start up options

*SpaceWire core start up options*

- `grspwX_connect host:port`  
Connect GRPSW core *X* to packet server at specified server and port.
- `grspwX_server port`  
Open a packet server for core *X* on specified port.
- `grspw_spwfreq freq`  
Sets the SpaceWire input clock frequency. Combined with the clock divisor register, this determines the startup frequency and TX frequency.
- `grspw_clkdiv value`  
Sets the reset value for the clock divisor register for all GRSPW2 cores.
- `grspw_tx_max_part_len len`  
Sets up all GRSPW2 cores to transmit any SpaceWire packet longer than *len* in data part packets with no more than *len* bytes of data.

- grspw\_simple 1  
Set all GRSPW2 cores to “simple mode”. This can be used for backward compatibility with TSIM 2.0.44 and backwards. See the separate section on simple mode for details. Note the needed 1 argument.
- grspw\_simple\_rxfreq *freq*  
Sets the RX frequency in MHz for all GRSPW2 cores to *freq*. This is only valid together with the -grspw\_simple 1 option.

X in the above options has the range 0-5.

## 10.6.2. Commands

*SpaceWire core TSIM commands*

- grspwX\_connect** *host:port*  
Connect GRSPW2 core X to packet server at specified server and TCP port.
- grspwX\_server** *port*  
Open a packet server for GRSPW2 core X on specified TCP port.
- grspwX\_status**  
Print status for GRSPW2 core X.
- grspwX\_dbg** [*argument*]  
Sets, clears, lists, toggles debug options for individual GRSPW2 cores. Using **grspwX\_dbg** without any arguments will list all available options. The **list** argument will list current debug option settings. The **all** argument will turn on all debug options. The **clean** argument will turn off all debug options. Using one of the available debug options as argument will toggle that debug option. See the section below.

X in the above commands has the range 0-5.

## 10.6.3. Debug flags

The following debug flags and debug subcommands are available for SpaceWire interfaces. The *GAISLER\_GRSPW\_\** flags can be used with the **grspwX\_dbg** command to toggle individual flags for individual SpaceWire cores and with the **gr712\_dbg** command to toggle individual flags for all SpaceWire cores. The subcommands can be used with the **grspwX\_dbg** command to change and list the settings of all flags for individual SpaceWire cores.

Table 10.6. SpaceWire debug flags

Flag	Trace
GAISLER_GRSPW_ACC	GRSPW accesses
GAISLER_GRSPW_RXPACKET	GRSPW received packets
GAISLER_GRSPW_RXCTRL	GRSPW rx protocol
GAISLER_GRSPW_TXPACKET	GRSPW transmitted packets
GAISLER_GRSPW_TXCTRL	GRSPW tx protocol
GAISLER_GRSPW_RMAP	GRSPW RMAP accesses
GAISLER_GRSPW_RMAPPACKET	GRSPW RMAP packet dumps
GAISLER_GRSPW_RMAPPACKDE	GRSPW RMAP packet decoding
GAISLER_GRSPW_DMAERR	GRSPW DMA errors
GAISLER_GRSPW_LINK	Link changes
GAISLER_GRSPW_PART	TX/RX of GRSPW data part packets
all	Set all debug flags for the core
clean	Set none of the debug flags for the core
list	List the current setting of the debug flags for the core

### 10.6.4. SpaceWire packet server

Each SpaceWire core can be configured independently as a packet server or client using either `-grspwX_server` or `-grspwX_connect`. TCP sockets are used for establishing the connections. When acting as a server the core can only accept a single connection.

A connection should be set up before starting simulation for the first time, and must not be broken after that. Restarting the simulation will not tear down the connection, nor emptying any socket buffers.

The server side contains a link model that gets control information from the models at each end of the link, determines the link state and communicates frequencies and link errors to the two models at each ends of the link. It also supports error injection via two error injection packet types that can be sent from a custom client. See the following sections for details.

For more flexibility, such as custom routing, an external packet server can be implemented using the protocol specified in the following sections. Each core should then be connected to that server. That server would also have to implement a link model that at least reacts to link control packets and sends out link state packets and RX frequency packets.

### 10.6.5. SpaceWire packet server protocol

The protocol used to communicate with the packet server is described below. The different types of packets are defined according to the table below.

Table 10.7. Packet types

Type	Value	Direction	Notes
Data part	0	Both	Only when in run state
Time code	1	Both	Only when in run state
Link state	2	Server to client	
Link control	3	Client to server	Must be sent for model to reach run state
RX frequency	4	Server to client	
Error injection	5	Client to server	Optional
Packet error request	6	Client to server	Optional

All packets begin with a 32-bit big endian word length field which specifies the length of the rest of the packet, including header and other fixed fields. For most packet types this length is fixed for the particular type. Apart from the data part packet type, where data follows the header byte-wise, all fields are 32-bit big endian words if not otherwise specified.

All packets received by the GRSPW2 model are handled sequentially, and all packets sent by the GRSPW2 model and the server side link model are supposed to be handled sequentially by the client. SpaceWire packets can be split into multiple data parts, transferred in data part packets. Between such parts other packets such as for time codes, link state changes, link control changes, etc., can be handled. During the simulated time span for the reception of a data part, the receiver will not/should not handle any other packet types. Use the `-grspw_tx_max_part_len` to set up GRSPW2 model to split up SpaceWire packets into data parts in order for such events to be able to happen during the data stream.

#### 10.6.5.1. Flow control limitations

Flow control in terms of credit is not modeled between two ends of a link. A transmitter gets no notice if the other end cannot give more credit. If the no-spill bit in the GRSPW2 core is set and an enabled receiving DMA channel has no enabled descriptors, the data part packet will be held on the receiving side until a descriptor is available. Due to the sequential nature of the packet model a link error, time code, etc. will not be handled at all by the GRSPW2 model during this time.

### 10.6.5.2. Data part packet format

A SpaceWire packet is represented by one or more data parts. A data part packet represents one such a part. For the data parts of a multi part SpaceWire packet, only the last data part should have an EOP or EEP end marker, i.e. the *END* field set to 0 or 1. The other parts should have no end marker, i.e. the *END* field set to 2. Each data part is delivered in its entirety or not at all. A link error occurring between data parts on the other hand cuts the SpaceWire packet short and is considered the end of that SpaceWire packet.

A data part packet is sent at the beginning of transmission of the corresponding part of the SpaceWire packet, so that the receiver can start reacting to it as soon as the transmission starts. Therefore, the receiver should delay for the amount of simulated time it takes to receive the part before handling the next packet in the socket.

Packet length at offset 0x0:

31 0



31:0    LEN    Length of rest of packet: 4 + number of data bytes in the part

Header at offset 0x4:

31 16 15 8 7 5 4 2 1 0



31:16    *R*    Reserved for future use. Must be set to 0.

15:8    IPID    IP core ID: 0 for SpaceWire

7:5    TYPE    Packet type: 0 for data part packets

4:2    *R*    Reserved for future use. Must be set to 0.

1:0    END    End marker: 0: Normal End of Packet, 1: Error End of Packet, 2: No end marker

Offset 0x8: The data bytes of the part starts here

*Figure 10.6. SpaceWire data part packet*

### 10.6.5.3. Time code packet format

Packet length at offset 0x0:

31 0

LEN
-----

31:0    LEN    Length of rest of packet: 8

Header at offset 0x4:

31 16 15 8 7 5 4 0

<i>R</i>	IPID	TYPE	<i>R</i>
----------	------	------	----------

31:16    *R*    Reserved for future use. Must be set to 0.

15:8    IPID    IP core ID: 0 for SpaceWire

7:5    TYPE    Packet type: 1 for time code packets

4:0    *R*    Reserved for future use. Must be set to 0.

Payload at offset 0x8:

31 8 7 6 5 0

<i>R</i>	CT	CN
----------	----	----

31:8    *R*    Reserved for future use. Must be set to 0.

7:6    CT    Time control flags

5:0    CN    Value of time counter

*Figure 10.7. SpaceWire time code packet*

### 10.6.5.4. Link state packet format

Link state packets are sent out by the server side link model when the link state changes. The only states currently simulated are `Error Reset` and `Run`. A link state packet with state `Error Reset` can have the `ERROR` field set to an error seen at the receiver. Other link state packets has only `None` in the `ERROR` field.

Packet length at offset 0x0:

31 0

LEN
-----

31:0    LEN    Length of rest of packet: 4

Header at offset 0x4:

31 19 18 16 15 8 7 5 4 3 2 0

<i>R</i>	ERROR	IPID	TYPE	<i>R</i>	LS
----------	-------	------	------	----------	----

- 31:19    *R*        Reserved for future use. Must be set to 0.
- 18:16    ERROR    Link error: 0: None, 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8     IPID     IP core ID: 0 for SpaceWire
- 7:5     TYPE    Packet type: 2 for link state packets
- 4:3     *R*        Reserved for future use. Must be set to 0.
- 2:0     LS        Link State: 0: Error reset, 1: Error wait, 2: Ready, 3: Started, 4: Connecting, 5: Run

*Figure 10.8. SpaceWire link state packet*

**10.6.5.5. Link control packet format**

A link control packet must be sent from a client to the server side link model to inform if that side of the link is in start mode, autostart mode, and/or has the link disabled. In addition, the control packet contains information on the startup frequency and the TX frequency that will be used once run state is reached. A new link control packet should be sent from a client any time any of these parameters change.

If the startup frequencies of the two ends differ by more than a factor 1.1/0.9, the link model will reach run state. This limit is chosen based on the limits on timeout periods in the SpaceWire standard that must be within 10% up or down from nominal frequency. So even though the startup frequency should be 10 MHz, run state can be reached if startup frequencies are close enough.



Packet length at offset 0x0:

31 0



31:0 LEN Length of rest of packet: 12

Header at offset 0x4:

31 16 15 8 7 5 4 3 2 1 0



31:16 R Reserved for future use. Must be set to 0.

15:8 IPID IP core ID: 0 for SpaceWire

7:5 TYPE Packet type: 3 for link control packets

4:3 R Reserved for future use. Must be set to 0.

2 AS Link autostart.

1 LS Link start.

0 LD Link disable.

Startup frequency in MHz at offset 0x8:

31 0



31:0 SFREQ Startup frequency in MHz, big endian IEEE-754 32-bit float

TX frequency in MHz at offset 0xc:

31 0



31:0 TFREQ TX frequency in MHz, big endian in IEEE-754 32-bit float

*Figure 10.9. SpaceWire link control packet*

**10.6.5.6. RX frequency packet format**

The server side link model sends out this packet type to inform the client of with what frequency the other side transmits with when in run state. A new packet of this type is sent any time the transmitter on the other side changes its TX frequency.

Packet length at offset 0x0:

31 0

LEN
-----

31:0 LEN Length of rest of packet: 8

Header at offset 0x4:

31 16 15 8 7 5 4 0

<i>R</i>	IPID	TYPE	<i>R</i>
----------	------	------	----------

31:16 *R* Reserved for future use. Must be set to 0.

15:8 IPID IP core ID: 0 for SpaceWire

7:5 TYPE Packet type: 4 for rx frequency packets

4:0 *R* Reserved for future use. Must be set to 0.

RX frequency in MHz at offset 0x8:

31 0

RFREQ
-------

31:0 RFREQ RX frequency in MHz, big endian IEEE-754 32-bit float

*Figure 10.10. SpaceWire rx frequency packet*

### 10.6.5.7. Link error injection packet format

A client can send a packet of this kind to the server side link model to request that a link error will occur. The error specified is the link error that is seen at the targeted end. The *OE* bit determines which end of the link is the targeted end, i.e. will see the error.

If the *OE* bit is set to 1, the error will be seen at the receiver of the simulation model on the other end. The simulation model on the client side will see a disconnect error via a link state packet. In order for this error to happen during reception of a SpaceWire packet at the other end, the client can send a data part packet with no end marker followed by a link error injection packet.

If the *OE* bit is set to 0, the error will be seen at the receiver on the client end. The simulation model at the client end will see the requested error via a link state packet. The simulation model at the other end will see a disconnect error. Note that due to the nature of the model, this cannot in general be relied upon to inject an error during the reception of a SpaceWire packet, even if split up in multiple data parts. The link state packet will not be sent by the server side link model until all previous packets have been handled, and the client should handle all other packets queued up before that link state packet can be handled. To inject a link error during the reception of a SpaceWire packet at the client side, the packet error request packet should be used instead.

Packet length at offset 0x0:


31 0



31:0 LEN Length of rest of packet: 4

Header at offset 0x4:

31 21 20 19 18 16 15 8 7 5 4 0



- 31:21 R Reserved for future use. Must be set to 0.
- 20 OE Other end: 1: other end gets the error, 0: my end gets error
- 19 R Reserved for future use. Must be set to 0.
- 18:16 ERROR Link error: 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8 IPID IP core ID: 0 for SpaceWire
- 7:5 TYPE Packet type: 5 for link error injection packets
- 4:0 R Reserved for future use. Must be set to 0.

*Figure 10.11. SpaceWire link error injection packet*

**10.6.5.8. Packet error request packet format**

A client can send a packet of this kind to the server side link model to request that a link error will occur during reception of a certain data packet by the client. The error specified is the link error that is seen, via a link state packet, by the client as a result. The other side will see a disconnect error. A 64-bit packet number, counting from 0, indicates during which SpaceWire packet sent from the other side to the client the link error should happen. Note that this number is indexing SpaceWire packets, not individual data part packets, and does not take SpaceWire packets sent from the client to the server side into account in the numbering. There can only be one outstanding packet error request per targeted GRSPW2 core at a time.

The **grspwX\_status** command can be issued for the targeted GRSPW2 core to see how many SpaceWire packets have currently been sent by that core. This includes started but aborted SpaceWire packets, due to link error, core reset or active aborting using the Abort TX (AT) bit in the DMA control register of the GRSPW2 core.

Packet length at offset 0x0:


31 0



31:0 LEN Length of rest of packet: 16

Header at offset 0x4:

31 19 18 16 15 8 7 5 4 0



- 31:19 R Reserved for future use. Must be set to 0.
- 18:16 ERROR Link error: 1: Disconnect, 2: Parity, 3: Escape, 4:Credit
- 15:8 IPID IP core ID: 0 for SpaceWire
- 7:5 TYPE Packet type: 6 for packet error request packets
- 4:0 R Reserved for future use. Must be set to 0.

Packet number to request error for, most significant word at offset 0x8:

31 0



31:0 MSW Bits 63:32 of unsigned 64-bit big endian integer

Packet number to request error for, least significant word at offset 0xc:


31 0



31:0 LSW Bits 31:0 of unsigned 64-bit big endian integer

Reserved field at offset 0x10:

31 0



31:0 R Reserved for future use. Must be set to 0.

Figure 10.12. SpaceWire packet error request packet

### 10.6.6. Simple Mode

For backwards compatibility with TSIM 2.0.44 and older, the GRSPW2 models can be set up in “simple mode” with the `-grspw_simple 1` option. This makes the following changes to the simulation model for all GRSPW2 cores:

- The *only* supported packet types are data part packets and time code packets. The model sends out no other packet types and accepts no other packet types.
- Data part packets should *always* contain full SpaceWire packets. The `-grspw_tx_max_part_len` should not be used together with simple mode and data part packets without end marker should be sent to a GRSPW2 model when using simple mode.
- The link state that a GRSPW2 core perceives is solely determined by its own link control setting. The other end is assumed to try to start the link. In other words, run state is achieved once the GRSPW2 is set to start or autostart without having link disable set. Moreover, startup frequencies are ignored and run state is achieved without any delay.

- The RX frequency is determined primarily by the `-grspw_simple_rxfreq` option. If that is not used, the RX frequency is taken by the `-grspw_spwfreq` option. If none of those options are set the CPU frequency is used. No cases take any clock divisors into account. The TX frequency is determined in the usual way as when not in simple mode, which includes taking the clock divisor register into account.

## 10.7. SPI interface

### 10.7.1. Connecting a user SPI model with the GR712RC module

See Section 10.2 for details on how to connect the user SPI model to the GR712RC module.

### 10.7.2. Commands

*SPI Commands*

#### **spi0\_status**

Print status for the SPI core.

#### **spi0\_dbg** [*flag/subcommand*]

Toggle, set, clear, list debug flags for the SPI core.

### 10.7.3. Debug flags

The following debug flags and debug subcommands are available for SPI interfaces. The `GAISLER_SPI_*` flags can be used with the `spi0_dbg` command to toggle individual flags for individual SPI cores and with the `gr712_dbgon` command to toggle individual flags for all SPI cores. The subcommands can be used with the `spi0_dbg` command to change and list the settings of all flags for individual SPI cores.

*Table 10.8. SPI debug flags*

Flag/subcommand	Trace
GAISLER_SPI_ACC	SPI register accesses
GAISLER_SPI_IRQ	SPI interrupts
all	Set all SPI debug flags for the core
clean	Set none of the SPI debug flags for the core
list	List the current setting of the debug flags for the core

### 10.7.4. SPI bus model API

The structure `struct spi_input` models the SPI bus. It is defined as:

```
/* Spi input provider */
struct spi_input {
    struct input_inp_b;
    int (*spishift)(struct spi_input *ctrl, uint32 select, uint32 bitcnt,
                   uint32 out, uint32 *in);
};
```

The `spishift` callback should be set by the SPI user module at startup. It is called by the GR712RC module whenever it shifts a word through the SPI bus.

*Table 10.9. spishift callback parameters*

Parameter	Description
select	Slave select bits
bitcnt	Number of bits set in the MODE register, if bitcnt is -1 then the operation is not a shift and the call is to indicate a <i>select</i> change, i.e. if the core is disabled.
out	Shift out (tx) data
in	Shift in (rx) data

The return value of `spishift` is ignored.

See the `gr712/examples/input` directory for an example implementation.

## 10.8. GPIO interface

### 10.8.1. Connecting a user GPIO model with the GR712RC module

See Section 10.2 for details on how to connect the user GPIO model to the GR712RC module.

### 10.8.2. Commands

#### *GPIO Commands*

##### **gpioX\_status**

Print status for the GPIO core.

##### **gpioX\_dbg** [*flag* / *subcommand*]

Toggle, set, clear, list debug flags for the GPIO core.

### 10.8.3. Debug flags

The following debug flags and debug subcommands are available for GPIO interfaces. The `GAISLER_GPIO_*` flags can be used with the **gpioX\_dbg** command to toggle individual flags for individual GPIO cores and with the **gr712\_dbgon** command to toggle individual flags for all GPIO cores. The subcommands can be used with the **gpioX\_dbg** command to change and list the settings of all flags for individual GPIO cores.

*Table 10.10. GPIO debug flags*

Flag/subcommand	Trace
GAISLER_GPIO_ACC	GPIO register accesses
GAISLER_GPIO_IRQ	GPIO interrupts
all	Set all GPIO debug flags for the core
clean	Set none of the GPIO debug flags for the core
list	List the current setting of the debug flags for the core

### 10.8.4. GPIO model API

The structure `struct gpio_input` models the GPIO pins. It is defined as:

```
/* GPIO input provider */
struct gpio_input {
    struct input_inp_b;
    int (*gpiout)(struct gpio_input *ctrl, unsigned int out);
    int (*gpiin) (struct gpio_input *ctrl, unsigned int in);
};
```

The `gpiout` callback should be set by the user module at startup. The `gpiin` callback is set by the GR712RC AHB module. The `gpiout` callback is called by the GR712RC module whenever a GPIO output pin changes. The `gpiin` callback is called by the user module when the input pins should change. Typically the user module would register an event handler at a certain time offset and call `gpiin` from within the event handler.

*Table 10.11. gpiout callback parameters*

Parameter	Description
out	The values of the output pins

*Table 10.12. gpiin callback parameters*

Parameter	Description
in	The input pin values

The return value of `gpioin/gpioout` is ignored.

See the `gr712/examples/input` for an example implementation.

## 10.9. Clock Gating Unit, CANMUX and GRGPREG

The Clock Gate Unit, CANMUX and GRGPREG I/O registers and AMBA Plug & Play area are present in the GR712RC module. Some of the logic to control which bits are implemented, readable and writable etc. is implemented. However the register bits has no functionality. The current register values can be used by custom I/O modules in SW validation. For example checking that accessing a specific address are has not been clock gate disabled or that the SpW clock PLL match with the expect value after initialization.

## 11. Atmel AT697 emulation

To emulate the AT697E chip the `-at697e` should be used. That sets up parameters for core TSIM2 to match AT697E. In addition, the AT697 loadable AHB module implements emulation models for the PCI core of the AT697E. Apart from an overview of what TSIM supports for AT697 emulation, this chapter is mainly about the AT697 AHB module.

The following table lists which cores in the AT697 are modelled by TSIM or not. Some supported cores are modelled by the core TSIM2 and some in the AT697 AHB module. The table contains some notes of some unsupported features for otherwise supported cores, but is not necessarily exhaustive in this respect. See Chapter 4 for details on the builtin simulation models and the rest of the chapter for the AHB module models.

Table 11.1. Simulation models for AT697

Core	Status	Notes
LEON2FT	Supported by core TSIM2	No FT features are modelled.
FPU	Supported by core TSIM2	
LEON2 system registers	Supported by core TSIM2	
Interrupt controller	Supported by core TSIM2	
Memory controller	Supported by core TSIM2	No FT features are modelled
UART	Supported by core TSIM2	
PCI	Supported by AHB module	
I/O port	Not supported	Easily modelled in user module
JTAG	Not supported	Debug link
Debug UART	Not supported	Debug link
DSU	Not supported	Debug unit

TSIM supports running several AHB modules. User defined models for unsupported cores can be used in parallel with the AT697 AHB module. User defined models can also override the simulation models in the AT697 AHB module.

### 11.1. Overview of the AT697 AHB module

The PCI emulation is implemented as a AT697 AHB module that will process all accesses to memory region 0xa0000000 - 0xf0000000 (AHB slave mode) and the APB registers starting at 0x80000100. The AT697 AHB module implements all registers of the PCI core. It will in turn load the PCI user modules that will implement the devices. The AT697 AHB module is supposed to be the PCI host. Both PCI Initiator and PCI Target mode are supported. The interface to the PCI user modules is implemented on bus level. Two callbacks model the PCI bus.

See also Section 5.4.1 on some limitations of some features when using this module. The AT697 AHB module is only supported for TSIM2 LEON2.

The following files are delivered with the AT697 TSIM module:

Table 11.2. Files delivered with the AT697 TSIM module

File	Description
at697/linux/at697.so	AT697 AHB module for Linux
at697/win32/at697.dll	AT697 AHB module for Windows
<i>Input</i>	The input directory contains two examples of PCI user modules
at697/examples/input/README.txt	Description of the user module examples
at697/examples/input/Makefile	Makefile for building the user modules
at697/examples/input/pci.c	PCI user module example that makes AT697 PCI initiator accesses



File	Description
at697/examples/input/pci_target.c	PCI user module example that makes AT697 PCI target accesses
at697/examples/input/at697inputprovider.h	Interface between the AT697 module and the user defined PCI module
at697/examples/input/pci_input.h	AT697 PCI input provider definitions
at697/examples/input/input.h	Generic input provider definitions
at697/examples/input/tsim.h	TSIM interface definitions
at697/examples/input/end.h	Defines the endian of the local machine

## 11.2. Loading the module

The module is loaded using the TSIM2 option `-ahbm`. All core specific options described in the following sections need to be surrounded by the options `-designinput` and `-designinputend`, e.g:

On Linux:

```
tsim-leon -ahbm ./at697/linux/at697.so
          -designinput ./at697/examples/input/pci.so -designinputend
```

On Windows:

```
tsim-leon -ahbm ./at697/win32/at697.dll
          -designinput ./at697/examples/input/pci.dll -designinputend
```

This loads the AT697 AHB module `./at697.so` which in turn loads the PCI user module `./pci.so`. The PCI user module `./pci.so` communicates with `./at697.so` using the PCI user module interface, while `./at697.so` communicates with TSIM via the AHB interface.

## 11.3. AT697 initiator mode

The PCI user module should supply the the callback function `acc()`. The AT697 AHB module will call this function to emulate AHB slave mode accesses or DMA accesses that are forwarded via `acc()`. The `cmd` parameter determines which command to use. Configuration cycles have to be handled by the PCI user module.

## 11.4. AT697 target mode

The AT697 AHB module supplies the callback `target_acc()` to the PCI user modules to implement target mode accesses from the PCI bus to the AHB bus. The PCI user module should trigger access events itself by inserting itself into the event queue.

## 11.5. Definitions

```
#define ESA_PCI_SPACE_IO      0
#define ESA_PCI_SPACE_MEM    1
#define ESA_PCI_SPACE_CONFIG 2
#define ESA_PCI_SPACE_MEMLINE 3

#define ESA_PCI_ACC_OK        0
#define ESA_PCI_ACC_MASTER_ABORT 1

struct esa_pci_input {
    struct input_inp_b;

    int (*acc)(struct esa_pci_input *ctrl,
               int cmd,
               unsigned int addr,
               unsigned int wsize,
               unsigned int *data,
               unsigned int *abort,
               unsigned int *ws);

    int (*target_acc)(struct esa_pci_input *ctrl,
```

```

        int cmd,
        unsigned int addr,
        unsigned int wsize,
        unsigned int *data,
        unsigned int *mexc);
};

```

### 11.5.1. PCI command table

```

0000: "IRQ acknowledge",
0001: "Special cycle",
0010: "I/O Read",
0011: "I/O Write",
0100: "Reserved",
0101: "Reserved",
0110: "Memory Read",
0111: "Memory Write",
1000: "Reserved",
1001: "Reserved",
1010: "Configuration Read",
1011: "Configuration Write",
1100: "Memory Read Multiple",
1101: "Dual Address Cycle",
1110: "Memory Read Line",
1111: "Memory Write And Invalidate"

```

### 11.6. Read/write function installed by PCI module

This function should be set by the PCI user module:

```

int (*acc)(struct esa_pci_input *ctrl,
           int cmd,
           unsigned int addr,
           unsigned int wsize,
           unsigned int *data,
           unsigned int *abort,
           unsigned int *ws);

```

If set, this function is called by the AT697 module whenever PCI bus master reads. Called for AHB-slave mapped accesses as well as AHB-Master/APB DMA.

Table 11.3. *acc* callback parameters

Parameter	Description
cmd	Command to execute, see Section 11.5.1.
addr	PCI address
wsize	0: 8-bit access 1: 16-bit access, 2: 32-bit access. Is always 2 for read accesses.
data	Data buffer. The user module should return the read data in <i>*data</i> for read commands or write the data in <i>*data</i> for write commands.
ws	Set <i>*ws</i> to the number of PCI clocks it takes to complete the transaction.
abort	Set <i>*abort</i> to 1 to generate target abort, or 0 otherwise.

The return value of *acc* determines if the transaction terminates with master abort (1, `ESA_PCI_ACC_MASTER_ABORT`), or not (0, `ESA_PCI_ACC_OK`).

### 11.7. Read/write function installed by AT697 module

The following function is installed by the AT697 AHB module:

```

int (*target_acc)(struct esa_pci_input *ctrl,
                 int cmd,
                 unsigned int addr,
                 unsigned int wsize,
                 unsigned int *data,
                 unsigned int *mexc);

```

The PCI user module can call this function to emulate a PCI target mode read access to the AT697.

Table 11.4. *target\_acc* parameters

Parameter	Description
cmd	Command to execute, see Section 11.5.1. Configuration cycles are not supported, the AT697 module is supposed to be the host.
addr	PCI address. Should always be word aligned for read accesses.
wsiz	0: 8-bit access 1: 16-bit access, 2: 32-bit access. Should always be 2 for read accesses.
data	Data buffer. The read data is returned in <i>*data</i> for read commands or the data in <i>*data</i> is written for write commands.
mexc	The AT697 PCI models sets <i>*mexc</i> to 0 if access is successful, or to 1 in case of target abort.

If a supported command hits MEMBAR0, MEMBAR1 or IOBAR, *target\_acc()* will return 1 otherwise it will return 0.

## 11.8. Registers

Table 11.5 contains a list of implemented and not implemented fields of the AT697F PCI Registers. Only register fields that are relevant for the emulated PCI module is implemented.

Table 11.5. *PCI register support*

Register	Implemented	Not implemented
PCIID1	device id, vendor id	
PCISC	stat 13, stat 12, stat 11, stat 7, stat 6 stat 5, stat 4, com2, com 1, com1	stat15 stat14 stat10_9 stat8 com10 com9 com8 com7 com6 com5 com4 com3
PCIID2	class code, revision id	
PCIBHDLC	[bist, header type, latency timer, cache size] config-space only	
PCIMBAR1	base address, pref, type, msi	
PCIMBAR2	base address, pref, type, msi	
PCIIOBAR3	io base address, ms	
PCISID	subsystem id, svi	
PCICP	pointer	
PCILI	[max_lat min_gnt int_pin int_line] config-space-only	
PCIRT	[ retry trdy ] config-space-only	
PCICW		ben
PCISA	start address	
PCIW		ben
PCIDMA	wdcnt, com	b2b
PCIS	act, xff, xfe, rfe	dmas, ss
PCIIC	mod, commsb	dwr, dww, perr
PCITPA	tpa1, tpa2	
PCITSC		errmem, xff, xfe, rfe, tms
PCIITE	dmaer, imier, tier	cmfer, imper, tbeer, tper, syser

Register	Implemented	Not implemented
PCIITP	dmaer, imier, tier	cmfer, imper, tbeer, tper, syser
PCIITF	dmaer, imier, tier, cmfer, imper, tbeer, tper, syser	
PCID	dat	
PCIBE	dat	
PCIDMAA	addr	
PCIA		p0, p1, p2, p3

## 11.9. Debug flags

The switch `-designdbg` on flags can be used to enable debug output. The possible values for flags are as follows:

Table 11.6. Debug flags

ESAPCI_REGACC	Trace accesses to the PCI registers
ESAPCI_ACC	Trace accesses to the PCI AHB-slave address space
ESAPCI_DMA	Trace DMA
ESAPCI_IRQ	Trace PCI IRQ

## 11.10. Commands

### **pci**

Displays all PCI registers.

## 12. TPS VxWorks AHB Module

### 12.1. Overview

The TPS VxWorks Module is a loadable module that simplifies communication between TSIM and the VxWorks Workbench. It provides a virtual core that acts similar to a basic Ethernet controller, but does not require a packet server.

The module is only useful in conjunction with VxWorks. See also Section 5.4.1 on some limitations of some features when using this module.

*Table 12.1. Files delivered with the TPS VxWorks TSIM module*

File	Description
tps/linux/tps-vxworks.so	TPS VxWorks module for Linux
tps/win32/tps-vxworks.dll	TPS VxWorks module for Windows

### 12.2. Loading the module

The module is loaded using the TSIM2 option `-ahbm`. It can be used in conjunction with other modules, such as the UT699 and GR712RC modules.

On Linux (together with the UT699 design):

```
tsim-leon3 -ut699 -ahbm ./tps/linux/tps-vxworks.so -ahbm ./ut699/linux/ut699.so
```

On Windows (together with the GR712RC design):

```
tsim-leon3 -gr712rc -ahbm ./tps/win32/tps-vxworks.dll -ahbm ./gr712/win32/gr712.dll
```

### 12.3. Configuration

By default the module uses IRQ 5 and UDP port 0x4321. This can be changed by using the following command line arguments:

- tps\_vxworks\_irq irq**  
Uses IRQ `irq` instead of the default.
- tps\_vxworks\_port port**  
Uses UDP port `port` instead of the default.

Use the following command line to make the TPS module use IRQ 10 and port 5000 on Linux together with the UT699 design:

```
tsim-leon3 -ut699 -ahbm ./tps/linux/tps-vxworks.so -ahbm ./ut699/linux/ut699.so  
-tps_vxworks_port 5000 -tps_vxworks_irq 10
```

## 13. Support

For support contact the Cobham Gaisler support team at [support@gaisler.com](mailto:support@gaisler.com).

When contacting support, please identify yourself in full, including company affiliation and site name and address. Please identify exactly what product that is used, specifying if it is an IP core (with full name of the library distribution archive file), component, software version, compiler version, operating system version, debug tool version, simulator tool version, board version, etc.

The support service is only for paying customers with a support contract.

**Cobham Gaisler AB**  
Kungsgatan 12  
411 19 Gothenburg  
Sweden  
[www.cobham.com/gaisler](http://www.cobham.com/gaisler)  
[sales@gaisler.com](mailto:sales@gaisler.com)  
T: +46 31 7758650  
F: +46 31 421407

Cobham Gaisler AB, reserves the right to make changes to any products and services described herein at any time without notice. Consult Cobham or an authorized sales representative to verify that the information in this document is current before using this product. Cobham does not assume any responsibility or liability arising out of the application or use of any product or service described herein, except as expressly agreed to in writing by Cobham; nor does the purchase, lease, or use of a product or service from Cobham convey a license under any patent rights, copyrights, trademark rights, or any other of the intellectual rights of Cobham or of third parties. All information is provided as is. There is no warranty that it is correct or suitable for any purpose, neither implicit nor explicit.

Copyright © 2018 Cobham Gaisler AB